400 & 500 Series Semi-Mounted Plow

Parts Catalog

A1313

MidWestTech | Case 400 & 500 Series Semi-Mounted Plow Parts Catalog | Publication A1...

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

ILLUSTRATION AND TEXT

The arrangement of this parts catalog is for easy identification of Case parts. All parts are illustrated in "Exploded Views." This places each part in normal reference to each other. Reference numbers are used in the illustrations. These numbers are in reference to those on the text pages. The text pages list reference number, part number, part description and the amount required.

NSS "Not Serviced Separately" in the part number column is an indication this part is not available for repairs.

UAR "Use As Required" in the amount required column is an indication the number of parts used is controlled by service.

REF "Reference " in the parts number column is an indication this part has many applications or has special service information. The page this information can be found on is listed in the part description column.

INDEX

An alphabetical index and serial number information is on the front pages of this catalog. A numerical index which lists the part number, page number and reference number is on the last pages of this catalog.

CATALOG CHANGES

Changes to the product will make it necessary to revise or add pages to this catalog. Each new or revised page will have a new issue date. A cover sheet will be attached to each revision. The cover sheet will list all pages released for each revision. All revised and new pages must be put into the parts book as soon as they are received.

PARTS ORDER

Orders must give the complete description, correct part number, the total amount required, the product model, all the necessary serial numbers, the method of shipment and the shipping address.

TEXT DESCRIPTION

An assembly may contain many service items. The component parts of an assembly will be indented. The amount required column will list the number of components required for a complete assembly or sub-assemblies. See example.

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 77303	VALVE ASSEMBLY - PTO control	1
2	REF	BODY ASSEMBLY - (See Page 99)	1
3	NSS	SPOOL - control valve (Order A77303)	1
4	A 61985	PLUG ASSEMBLY - valve spool	1
5	218- 5007	O-RING - plug 3/4 x 15/16 x 3/32" (19.05 x 23.81 x 2.38mm)	2
6	NSS	PIN - spring guide	1
7	B 51407	SPRING - detent 5/8" free length (15.87mm)	1
8	211- 11	BALL - detent 3/8" dia. steel (9.52mm)	UAR

RIGHT-HAND AND LEFT-HAND IDENTIFICATION

The reference to right-hand (RH) and left-hand (LH) as used in this publication is identified by the operator standing at the rear of the unit, looking toward the front of the machine.

MidWestTech | Case 400 & 500 Series Semi-Mounted Plow Parts Catalog | Publication A1... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Axle - Furrow Wheel (On Land) 11, 13
Axle - Gauge Wheel 59
Axle - Rear Wheel 55, 57

B

Beam - Shear Bolt and Cushion Trip (400 Series) 15, 17
Beam - Shear Bolt and Cushion Trip (500 Series) 21, 23
Beam - Spring Automatic Reset (400 Series) 19
Beam - Spring Automatic Reset (500 Series) 25
Bottom - 16 Inch General Purpose (400 Series) 37
Bottom - 16 Inch High Speed (400 Series) 43
Bottom - 16 Inch Slat (400 Series) 41
Bottom - 16 Inch Stubble (400 Series) 39
Bottom - 18 Inch General Purpose (Regular) 45
Bottom - 18 Inch General Purpose (Heavy Duty) 47
Bottom - 18 Inch Slat 51
Bottom - 18 Inch Stubble 49
Bottom - 20 Inch General Purpose (500 Series) 53

C

Coulter - Rigid 61
Coulter - Cushion 63
Coulter - Concave Cushion 65

D

Decals 67

E

Extension - Beam 27

H

Hillside Attachment (In Furrow) 61
Hitch - In Furrow 3, 5
Hitch - On Land 7, 9
Hitchbar - Category Two and Three (In Furrow) 3, 5
Hitchbar - Category Two and Three (On Land) 7, 9

P

Pipes - Steering 29

R

Reflectors and SMV Symbol 67

T

Trashboards 67
Trip Beam - Cushion 33
Trip Beam - Shear Bolt 31
Trip Beam - Spring Automatic Reset 35

W

Wheel - Furrow (On Land) 11, 13
Wheel - Gauge 59
Wheel - Rear 55, 57

Printed in U.S.A. Issued November, 1978

MidWestTech | Case 400 & 500 Series Semi-Mounted Plow Parts Catalog | Publication A1... Order the manual at mid-west-tech.com >