450 / 455B Crawler

Parts Catalog

A1372

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner and Mounting 39-41B
Alarm - backup 73
Alternator and Mounting 57, 69
Antirollback - loader 225

B

Backhoe - See Model 35 Backhoe Parts Catalog
Backup Alarm 73
Battery and Cables 67
Belts
  Drive - fan 37
  Seat 259
Blades - angle tilt dozer 233
Block - engine cylinder 21
Brake Assembly - transmission 113
Brake Cylinders 143, 145
Brake - parking 149
Brake Pedals 143
Brush Guard 251, 263, 265
Brush Sweeps 265
Buckets
  1 cu yd 227
  Clam (4-in-1) 229
  Teeth (See individual buckets)

C

Camshaft - engine 19
Chain - track 137
Clutch - transmission 103-109
Cold Start System 77
Connecting Rods - engine 27
Control Levers
  Brake pedals 143
  Engine throttle 45
  Equipment 197-201
  Forward, reverse and steering 79
  Four spool control valve 201
  Fuel shutoff 65
  Optional brake system 145
  Three spool control valve 199
  Two spool control valve 197
  Transmission 79
Control Tower - transmission 79
Cooling system - transmission 85
Counterweights 241
Cowl 221, 243
Crankshaft - engine 23
Crossmember - main frame 243
Cushions - seat and arm 259, 261
Cylinders - brake, master 143, 145

C

Cylinders - hydraulic
  Clam Bucket 187
  Dozer - angle 191
  Dozer - lift 189
  Dozer - tilt 193
  Loader - bucket tilt 183
  Loader - lift 181
  Loader - hydra-leveling 185
  Ripper 195
Cylinder Block - engine 21
Cylinder Head - engine 15

D

Decals - crawler 271, 273
Dipstick
  Engine 21
  Fuel 257
  Hydraulic oil 257
  Transmission 97
Dozer
  Blade 233
  C-frame 231
  Leveling Beam 233
Drawbars 237, 239
Drive - final 115, 117
Drive Shaft 95

E

Electrical System
  Crawler 67, 69
  Backup Alarm 73
  Horn 75
  Instrument panel 63, 65
  Loader return-to-dig 225
Engine
  Frame 243
  Mounting Parts 35
Engine - turbocharged, See 207 Turbocharged Diesel Engine Catalog 8-1380
Engine Subassemblies - models without turbocharger
  Camshaft 19
  Crankshaft 23
  Cylinder block assembly 21
  Cylinder head and cover 15
  Engine gasket kits 31
  Fuel injection filter system 49
  Fuel filter 51
  Fuel injection pump and drive 53, 55
  Fuel injection system 49
  Fuel injector 51

MidWestTech | Case 450, 455B Crawler Parts Catalog | Publication A1372 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

E

Engine Subassemblies, cont'd.
- Manifolds 13
- Oil pump, filter, pan 29
- Piston assembly and connecting rods 27
- Valves and valve mechanism 17
- Water pump and attaching parts 11

Equipment Control Valves 203-207
Exhaust - pipe and mufflers 43, 43B

F

Fan - radiator 37
Filters
- Fuel 51
- Oil, engine 29
- Oil, hydraulic 155, 257
- Oil, transmission 87

Final Drive 115, 117
Flood Lamp - rear 71
Floor Plates 255
Flywheel - engine 25, 35
Frames
- Dozer - C-frame 231
- Loader 221
- Loader Lift Arm 223
- Main and Engine 243
- Seat, tank, and reservoir 249
- Track 127

Fuel Injection System 49
Fuel Lines - engine 47
Fuel Shutoff 65
Fuel Tank Assembly 257

G

Gaskets - engine (service kits) 31
Gauges - engine and crawler 65
Gears - final drive 115, 117
Gears - transmission (see transmission)
Grille - radiator 251
Guards
- Brush Sweeps 265
- Hydraulic - See Specific Hydraulic Circuit Pages
- Roll Over Protective Structure 263
- Side Panels 253
- Screens 251, 263, 265
- Track Guides (Rock Guards) 135
- Transmission - rear 249
- Undercarriage 245, 247

H

Head - engine cylinder 15
Head Lamps 71
Heater - engine block 21
Hood 253

H

Hook - pull 245, 247
Horn 75
Hose - see fuel lines or hydraulic circuits
Hose - radiator 37
Hose and Fitting Chart 274
Housing - flywheel 25
Hydraulic Circuits
- Backhoe Connecting 175
- Bucket, clam (4-in-1) 161, 163
- Cooling System 85
- Dozer Angle Circuit - Angle Tilt Dozer 167, 171
- Dozer Lift Circuit - Angle Tilt Dozer 165
- Dozer Tilt Circuit - Angle Tilt Dozer 169, 171
- Equipment 151
- Loader Bucket Tilt 159
- Loader Clam 161, 163
- Loader Hydra-Leveling 159
- Loader Lift 157
- Pump to Torque Converter 81
- Ripper 173
- Torque Converter to Transmission 83
- Transmission 121

Hydraulic Oil Filters 155, 257
Hydraulic Pump 153
Hydraulic Reservoir 257

I

Idler Wheel - track 129
Index - numerical 275
Injection - fuel 49-55
Instrument - gauges 65
Instrument Panel 63-65B

L

Levers - see controls
Lamps - head and flood 71
Lamp - instrument panel (See instrument panel)
Loader
- Antirollback 225
- Buckets 227, 229
- Cowl 221
- Hydraulic Circuits - See Hydraulic Circuits
- Lift Frame 223
- Main Frame 221
- Return-to-Dig 225

M

Manifold - intake and exhaust 13
Manual Box - operators 269
Mufflers 43, 43B

Printed in U.S.A.

Issued January, 1981

MidWestTech | Case 450, 455B Crawler Parts Catalog | Publication A1372 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

N

Neutral Start Switch 79
Noise Reduction Pads 267
Nozzle - fuel injector 51
Numerical Index 275

O

Oil Filter, Pump and Pan - engine 29

P

Pads - noise reduction 267
Pan - oil, engine 29
Parking Brake 149
Pedals - brake 143
Piston Assemblies 27
Plates - floor 255
Pulley - alternator 37, 57
Pulley - fan drive 23
Pull Hook 245, 247
Pump
- Fuel injection 53, 55
- Oil, engine 29
- Oil, hydraulic (equipment) 153
- Oil, torque converter 93
- Water, engine 11

R

Radiator - engine coolant 37
Recoil System - track 127
Regulators - voltage 57
Return-To-Dig - loader 225
Rings - piston 27
Ripper 235
Rock Guards, see Track Guides
Rocker Arms - engine 17
Rods - connecting, engine 27
Rods - push, engine 17
Roll-Over Protective Structure 263
Roller - track 131
Roller - track carrier 133

S

Screen - fuel 257
Screen - guard, brush 251, 263, 265
Seat Assemblies 259, 261
Serial Number Locations 4
Shafts - Engine - see engine subassemblies
Shafts - Transmission - see transmission subassemblies
Shields - engine 253
Shoes - track 139, 141
Shroud - radiator 251
Sleeve - piston 27
Slow Moving Vehicle Emblem 269
Solenoid - starter 61

S

Spools - control valves 209-213
Sprocket - drive 127
Steps 255, 263
Strainer - fuel 257
Starter - engine 59, 61, 67
Switch - neutral start 79

T

Tank Assemblies - fuel and hydraulic reservoir 257
Teeth - buckets 227, 229
Thermostat - engine water temperature 11
Timing Gear Cover 33
Torque Converters 35, 89, 91
Track
- Adjuster, hydraulic 129
- Carrier roller 133
- Chain 137
- Chain Service Kits 137
- Frame 127
- Guides (Rock Guards) 135
- Idler Wheel 129
- Recoil System 127
- Rollers 131
- Shoes 139, 141
- Sprocket 127

Transmission Subassemblies
- Bevel pinion and shaft 111
- Clutch - forward and reverse 109
- Clutch - high and low speed 107
- Control valve 123
- Final drive and housing 115, 117
- High and low clutch shafts 105
- Hydraulic brakes 113
- Mechanical range shift 101
- Pinion Gear and shaft 119
- Seal Kits 125
- Transmission housing and covers 97, 99
- Transmission hydraulics 121

U

Undercarriage Guards 245, 247

V

Valve Mechanism - engine 17
Valves - equipment control
- Air, inlet and outlet (Hydraulic oil and fuel) 257
- Hydraulic, dozer, 3 spool 205
- Hydraulic, dozer, 4 spool 207
- Hydraulic, loader, 2 spool 203
- Hydraulic, loader, 3 spool 203
- Hydraulic, loader, 4 spool 207
- Load Check 219
- Main Relief 215
- Secondary Relief and Check 217
- Transmission 123

W

Water Pump - engine 11
Winch - See Model 19 Winch Parts Catalog
Wires - See electrical systems

Order the manual at mid-west-tech.com >