# 1150 Crawler
# S/N 7108999-7110300
# (Includes Rev. 1)

## Parts Catalog

**B1100**

CASE
CONSTRUCTION


Order the manual at mid-west-tech.com >

# GENERAL INFORMATION

## Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

## Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

## Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

## Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.


## Indented Description

Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

| REF. | PART NO. | DESCRIPTION | REQ'D. |
|---|---|---|---|
| | A 55159 | CYLINDER ASSY. - rear steering | 1 |
| 28 | A 56208 | SOCKET ASSY. - rear cylinder | 1 |
| 29 | A 55956 | PLUG - adjusting, socket assy. | 1 |
| 30 | A 55957 | SEAT - socket ball | 2 |
| 31 | A 56210 | SPRING - socket | 1 |
| 32 | A 56209 | SEAT - socket spring | 1 |
| 33 | G 45175 | CLAMP ASSY. - socket assy. | 1 |
| 34 | 16- 836 | HHCS - 1/2" - 20 NF x 2-1/4" | 1 |
| 35 | 132- 104 | PIN - cotter, 3/16" dia. x 3" | 1 |

## Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of the crawler are determined by sitting in the operator's seat facing the direction of forward travel. "Right Hand" and "Left Hand" sides of the backhoe are determined by sitting in the operator's seat facing the backhoe.





Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## - ENGINE SECTION -


### A

Alternator - electrical ..... 49

### C

Camshaft - engine ..... 11
Connecting Rods - engine ..... 17
Cooler System - oil, engine ..... 5,7
Crankshaft - engine ..... 15
Cylinder Block - engine ..... 13
Cylinder Head - engine ..... 9

### F

Filter - fuel injection ..... 23,23B
Filter - oil, engine ..... 7
Flywheel and Housing - engine ..... 15
Fuel Injection Pump and Drive - engine ..... 27
Fuel Injection System - engine ..... 23-25
Fuel Injector - engine ..... 25

### G

Gaskets - engine (Service Kits) ..... 21

### I

Index - numerical ..... 233-256

### M

Manifold - exhaust ..... 7
Manifold - intake ..... 7

### O

Oil Cooler - engine ..... 5,7
Oil Filter - engine ..... 7
Oil Pan - engine ..... 19
Oil Pump - engine ..... 19

### P

Pan - oil, engine ..... 19
Piston Assembly - engine ..... 17
Pump - fuel injection ..... 27
Pump - oil, engine ..... 19
Pump - water, engine ..... 5

### R

Rods - connecting, engine ..... 17

### S

Solenoid - starter ..... 51D

### V

Valve Mechanism - engine ..... 11


## - CRAWLER SECTION -


### A

Air Cleaner - dry type ..... 31,33
Air Cleaner - extensions ..... 33
Air Cleaner - oil bath ..... 35
Air Cleaner - pre-cleaner ..... 35

### B

Brake Cylinder - hydraulic, master ..... 81
Brake Cylinder - hydraulic, slave ..... 73
Brake Pedals - crawler ..... 81
Brakes - hydraulic ..... 71
Brush Guards - crawler ..... 113

### C

Clutch - forward and reverse ..... 67
Clutch - high and low ..... 67
Control Tower - transmission ..... 79
Control Valve - transmission ..... 77B
Cowl - crawler ..... 111
Cushions - seat ..... 119

### D

Decals ..... 123
Driveshaft - crawler ..... 61
Dual Range Linkage - transmission ..... 79


MidWestTech | Case 1150 Crawler Parts Catalog | Publication B1100 Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## - CRAWLER SECTION -


### E

Electrical System - crawler . . . . . 41
Engine Frame - crawler . . . . . 37,37B

### F

Fan - radiator . . . . . 39
Filter - oil, transmission . . . . . 89
Final Drive - crawler . . . . . 75,75B
Floor Plates - crawler . . . . . 111
Frame - main . . . . . 91
Frame - track . . . . . 95
Fuel Line And Strainer - crawler . . . . . 29

### G

Gear - bevel pinion . . . . . 73-75B
Grille - crawler . . . . . 109
Grille - crawler, heavy duty . . . . . 109B
Guards - undercarriage . . . . . 37,37B
Guide Levers - track . . . . . 91

### H

Headlight - crawler . . . . . 43
Hood - crawler . . . . . 109
Hook - pull . . . . . 37,37B
Hose - radiator . . . . . 39
Housing And Covers - transmission . . . . . 63
Hose And Fitting Assembly Conversion Part Numbers . . . . . 232
Hydraulics - basic tractor . . . . . 85
Hydraulics - transmission . . . . . 77

### I

Idler Wheel - track . . . . . 103
Index - numerical . . . . . 233-256
Instrument Panel - crawler, hose type . . . . . 45B
Instrument Panel - crawler, tube type . . . . . 45
Instrument Panel - wiring . . . . . 47

### L

Levers - guide, track . . . . . 91
Levers - control, transmission . . . . . 79
Linkage - throttle control . . . . . 53
Lock Up Parts - crawler . . . . . 121

### M

Mechanical Range Shift - transmission . . . . . 69
Muffler - exhaust . . . . . 31,31B,35
Muffler - spark arresting . . . . . 31B

### P

Parking Brake - crawler . . . . . 83
Pedals - brake . . . . . 81
Pre-Cleaner - air . . . . . 35
Pre-Heater - engine . . . . . 43
Pump - torque converter . . . . . 59,59B

### R

Radiator - engine . . . . . 39,39B
Recoil System - track . . . . . 95

### S

Seat And Tank - crawler . . . . . 117
Seat Cushions - crawler . . . . . 119
Seat Frame - crawler . . . . . 119
Shroud - crawler . . . . . 109
Side Shields And Brush Guard - crawler . . . . . 113

### T

Taillight - crawler . . . . . 43
Throttle Control - linkage . . . . . 53
Tools - service . . . . . 231
Torque Converter - crawler . . . . . 55
Torsion Bar - suspension . . . . . 91
Track Adjuster - hydraulic . . . . . 103
Track Carrier Roller - crawler . . . . . 101
Track Chain - crawler . . . . . 105
Track Frame - crawler . . . . . 95
Track Guides - crawler . . . . . 99
Track Recoil System - crawler . . . . . 95
Track Rollers - crawler . . . . . 101B-101D
Track Shoes - crawler . . . . . 107
Transmission - housing and covers . . . . . 63
Transmission - hydraulics . . . . . 77
Transmission - mechanical range shift . . . . . 69
Transmission - shafts, clutches and gears . . . . . 65

### V

Valve - control, transmission . . . . . 77B


Printed in U.S.A.

711176 Issued October, 1971

MidWestTech | Case 1150 Crawler Parts Catalog | Publication B1100 Order the manual at mid-west-tech.com >