870
Tractor

Parts Catalog

B1116

CASE

MidWestTech | Case 870 Tractor Parts Catalog | Publication B1116

Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.	PART NO.	DESCRIPTION	REQ'D
	A 55159	CYLINDER ASSY. - rear steering	1
28	A 56208	SOCKET ASSY., rear cylinder	1
29	NSS	PLUG - adjusting, socket assy	1
30	NSS	SEAT - socket ball	2
31	NSS	SPRING - socket	1
32	NSS	SEAT - socket spring	1
33	G 45175	CLAMP ASSY. - socket assy.	1
	16- 836	BOLT - 1/2" x 2-1/4" N.F. hex.	1
34	132- 104	PIN - cotter, 3/16" x 3"	UAR
35	A 55889	STUD - ball, socket & cylinder	2
36	13- 410	BOLT - 1/4" x 5/8" N.C., hex	4
37	92- 4	LOCKWASHER - 1/4" SAE	4

NOTE **NSS** IN PART NO. COLUMN INDICATES THIS PART IS NOT SERVICED SEPARATELY.
UAR IN AMT. REQ'D COLUMN INDICATES THIS PART IS USED AS REQUIRED.

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.

Order the manual at mid-west-tech.com >

CASE 870 AGRI-KING TRACTORS

ALPHABETICAL INDEX

ENGINE SECTION

DIESEL

Air Intake and Exhaust Section
- Air Cleaner 11
- Manifold 13
- Muffler 13
- Pre-Cleaner 11

Cold Weather Starting Aids
- Block Heater 103B
- Manifold Heater 13

Cooling Section
- Oil Cooler 7
- Radiator Baffles 5B
- Radiator 5
- Water Manifold and Thermostat 9
- Water Pump and Attaching Parts 9

Engine Section
- Camshaft 17
- Connecting Rods and Bearings 23
- Crankshaft and Bearings 21
- Cylinder Block 19,19B
- Cylinder Head Cover 15
- Cylinder Head 15
- Engine Gasket Kits 29,29B
- Flywheel 21
- Manifolds 13
- Pistons and Rings 23
- Rocker Shaft and Arms 17
- Timing Gear Cover 67
- Timing Gear 67
- Valve Train 17

Fuel Section
- Fuel Injection Filter System 65,65B
- Fuel Injection Pump and Drive 67,67B
- Fuel Injection System 63
- Fuel Injectors 63B
- Fuel Lines 63
- Fuel Tank 61
- Throttle and Linkage 31,31B

Lubrication Section
- Balancer and Oil Pump 25-25D
- Oil Filter 27
- Oil Pan 27

Order the manual at mid-west-tech.com >

CASE 870 AGRI-KING TRACTORS

ALPHABETICAL INDEX

ENGINE SECTION

SPARK IGNITION

Air Intake and Exhaust Section
- Air Cleaner 35
- Manifold 37
- Muffler 37
- Pre-Cleaner 35

Cold Weather Starting Aid
- Block Heater 103B

Cooling section
- Oil Cooler 7
- Radiator Baffles 5B
- Radiator 5
- Water Manifold and Thermostat 33
- Water Pump and Attaching Parts 33

Engine Section
- Camshaft 41
- Connecting Rods and Bearings 47
- Crankshaft and Bearings 45
- Cylinder Block 43,43B
- Cylinder Head Cover 39
- Cylinder Head 39
- Engine Gasket Kits 53,53B
- Flywheel 45
- Governor 59
- Manifold 37
- Pistons and Rings 47
- Rocker Shaft and Arms 41
- Timing Gear Cover 57
- Timing Gears 57
- Valve Train 41

Fuel Section
- Carburetor 73,73B
- Fuel Lines 71
- Fuel Pump 71
- Fuel Shut-Off 69
- Fuel Tank 69
- Governor and Linkage 57
- Throttle Linkage 55,55B

Lubrication Section
- Balancer and Oil Pump 49-49D
- Oil Filter 51
- Oil Pan 51
- Oil Pump 49

Order the manual at mid-west-tech.com >