W7E
Loader

Parts Catalog

B1142

CASE CONSTRUCTION

MidWestTech | Case W7E Loader Parts Catalog | Publication B1142

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.	PART NO.	DESCRIPTION	REQ'D
A	55159	CYLINDER ASSY. - rear steering	1
28 A	56208	SOCKET ASSY. rear cylinder	1
29	NSS	PLUG - adjusting, socket assy	1
30	NSS	SEAT - socket ball	2
31	NSS	SPRING - socket	1
32	NSS	SEAT - socket spring	1
33 G	45175	CLAMP ASSY. - socket assy.	1
16-	836	BOLT - 1/2" x 2-1/4" N.F. hex.	1
34 132-	104	PIN - cotter, 3/16" x 3"	UAR
35 A	55889	STUD - ball, socket & cylinder	2
36 13-	410	BOLT - 1/4" x 5/8" N.C., hex	4
37 92-	4	LOCKWASHER - 1/4" SAE	4

NOTE **NSS** IN PART NO. COLUMN INDICATES THIS PART IS NOT SERVICED SEPARATELY.
UAR IN AMT. REQ'D COLUMN INDICATES THIS PART IS USED AS REQUIRED.

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.

MidWestTech | Case W7E Loader Parts Catalog | Publication B1142 Order the manual at mid-west-tech.com >

MODEL W7E LOADER
ALPHABETICAL INDEX
-ENGINE SECTION-

A

Air Cleaners - Engine, Diesel 93, 95
Air Cleaners - Engine, Gasoline 97
Alternator - Electrical, Diesel 63
Alternator - Electrical, Gasoline 65

B

Balancer - Engine, Diesel 25
Balancer - Engine, Gasoline 45
Belt - Drive, Fan and Alternator 75, 79
Block - Cylinder, Diesel 17
Block - Cylinder, Gasoline 39

C

Camshaft - Engine, Diesel 15
Camshaft - Engine, Gasoline 37
Carburetor - Engine, Gasoline 55, 57
Coil - Electrical, Gasoline Engine 59
Crankshaft - Engine, Diesel 19
Crankshaft - Engine, Gasoline 41

D

Distributor - Electrical, Gasoline Engine 59, 61
Dipstick - Engine Oil, Diesel 17
Dipstick - Engine Oil, Gasoline 39

E

Electrical System - Diesel 75, 77, 87
Electrical System - Gasoline 59, 79, 81

F

Fan - Engine Cooling 7, 7B
Filter - Engine Oil, Diesel 25
Filter - Engine Oil, Gasoline 47
Filter - Fuel, Diesel 31
Flywheel - Engine, Diesel 19
Flywheel - Engine, Gasoline 41
Fuel Tanks - Engine 145, 147

G

Gasket Kits - Engine, Diesel 27
Gasket Kits - Engine, Gasoline 49
Gauges - Instrument Panel 83
Governor - Engine, Gasoline 53

H

Head - Cylinder, Diesel 13
Head - Cylinder, Gasoline 35

I

Ignition System - Engine, Gasoline 59
Index - Basic Tractor 5A
Index - Loader 5B
Index - Numerical 254
Injection System - Fuel, Diesel 29
Injection - Fuel, Diesel 29

K

Kits - Piston and Sleeve, Diesel Engine 21
Kits - Piston and Sleeve, Gasoline Engine 43
Kits - Starting Aid, Diesel 11B

L

Linkage - Throttle Control, Diesel 99
Linkage - Throttle Control, Gasoline 101

M

Manifold - Exhaust 9, 11
Manifold - Intake 9, 11
Manifold - Water 7, 7B
Muffler - Exhaust 9, 11

P

Pan - Engine Oil, Diesel 25
Pan - Engine Oil, Gasoline 47
Panel - Instrument 83, 85
Pistons - Engine, Diesel 21
Pistons - Engine, Gasoline 43
Pump - Fuel Injection, Diesel 33
Pump - Engine Oil, Diesel 23
Pump - Engine Oil, Gasoline 45
Pump - Water, Diesel 7
Pump - Water, Gasoline 7B

R

Radiator - Engine Cooling 135
Rings - Piston, Diesel 21
Rings - Piston, Gasoline 43
Rocker Arm - Engine, Diesel 15
Rocker Arm - Engine, Gasoline 37
Rod - Connecting, Diesel 21
Rod - Connecting, Gasoline 43
Rod - Push, Diesel 15
Rod - Push, Gasoline 37
Rotor - Distributor, Gasoline Engine 61

S

Sleeve - Engine, Diesel 21
Sleeve - Engine, Gasoline 43
Solenoid - Starter 73
Spark Plug - Ignition, Gasoline Engine 59
Starter - Engine, Diesel 67, 69
Starter - Engine, Gasoline 71

T

Thermostat - Coolant Temperature 7, 7B
Timing Gear Cover - Engine, Diesel 33
Timing Gear Cover - Engine, Gasoline 51

V

Valve Cover - Engine, Diesel 13
Valve Cover - Engine, Gasoline 35
Valve Guides - Engine, Diesel 15
Valve Guides - Engine, Gasoline 37
Valves - Engine, Diesel 15
Valves - Engine, Gasoline 37
Ventilation - Crankcase 11B

MidWestTech | Case W7E Loader Parts Catalog | Publication B1142 Order the manual at mid-west-tech.com >

MODEL W7E LOADER
ALPHABETICAL INDEX
-BASIC TRACTOR SECTION-

A

Accumulator - Hydraulic 239
Alternator - Electrical 63
Axle - Rigid, Front 177,183,187
Axle - Steering, Rear 179-187

B

Batteries - Electrical 87
Battery Cables - Electrical 87
Brake - Parking, Transmission 163
Brake Controls - Foot 113
Brake Controls - Parking 133
Brake System - Hydrovac, Diesel 119
Brake System - Hydrovac, Gasoline 123

C

Cab - Operator 243-249
Cable - Fuel Shut-off, Diesel 147
Chassis - Tractor 141
Cleaner - Air, Hydrovac 131
Clutch - High Gear, Transmission 163
Clutches - Forward, Reverse and Low Gear, Transmission 161
Clutch Control - Brake 113
Converter - Torque 169
Cooling System - Converter and Transmission 155
Counterweights - Rear 141
Cylinder - Hydrovac 127
Cylinder - Master, Brake 125
Cylinder - Wheel, Brake 125

D

Decals - Tractor 253
Differential - Tractor 183
Drive Shafts - Transmission and Axle 189
Drum - Brake 187

E

Electrical System - Cab 247
Electrical System - Tractor, Diesel 75,77
Electrical System - Tractor, Gasoline 79,81

F

Fenders - Tractor 143
Filter - Air, Hydrovac 131
Filter - Converter Oil 157
Filter - Hydraulic Oil 149
Floor Plates - Tractor 139

G

Gauges - Instrument Panel 83
Grill - Radiator Guard 135

H

Horn - Tractor 91
Hood - Engine 137
Hydraulics - Power Steering 107

I

Index - Engine 5
Index - Loader 5B
Index - Numerical 254
Instrument Panel - Tractor 83,85

L

Lights - Dash 91
Lights - Front and Rear 89
Lights - Stop 89
Lights - Turn Signal 251
Linkage - Steering 105

M

Mounts - Engine 141
Muffler - Exhaust 9,11

P

Panel - Instrument 83,85
Panels - Engine Side 137
Pedal - Throttle Control 99-101
Pedals - Brake, Hydrovac 113
Plates - Floor 139
Platform - Operator Compartment 139
Pump - Charging, Torque Converter 173
Pump - Power Steering 111
Pump - Vacuum, Hydrovac 131

R

Radiator - Engine Cooling 135
Reservoir - Power Steering 111

S

Seat - Operator 139
Shaft - Input, Transmission 161
Shaft - Output, Transmission 165
Shift Controls - Transmission 151
Shift-Out - Rear Axle 165
Shutter - Radiator 135
Side Panels - Engine 137
Starter - Electrical, Diesel 67,69
Starter - Electrical, Gasoline 71
Steering Cylinder - Hydraulic 109
Steering Gear - Tractor 103
Steering Hydraulics - Tractor 107
Steering Wheel - Tractor 105

T

Tank - Fuel 145,147
Tank - Hydraulic Oil 149
Tank - Reserve, Hydrovac 121,123
Transmission Controls - Tractor 151

U

Universal Joints - Drive Shaft 189

V

Valve - Accumulator 241
Valve - Check, Hydrovac 131
Valve - Clutch Control 133
Valve - Control, Transmission 167
Valve - Power Steering Cylinder 109
Valve - Regulating, Torque Converter 175

W

Wheels - Drive 187

Order the manual at mid-west-tech.com >