ILLUSTRATED PARTS LIST

KUBOTA

B2710HSD

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

PTO GEAR SHIFT LEVER

S.No.;<=15496

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C070-42700	LEVER PTO SHIFT	1				0.92	2.024
020	08511-01825	BUSH	1				0.01	0.022
030	6A320-42780	GRIP LEVER	1				0.034	0.0748
040	6C040-42760	CUSHION	1				0.003	0.0066
050	6C070-42740	ROD PTO	1				0.19	0.418
060	05525-61000	PIN SNAP	4				0.002	0.0044
070	6C040-42720	LEVER SHIFT ARM	1				0.1	0.22
080	05411-00832	PIN SPRING	1				0.035	0.077
090	6C070-42800	LEVER MID PTO SHIFT	1				1.05	2.31
100	08511-01825	BUSH	1				0.01	0.022
110	6A320-42780	GRIP LEVER	1				0.034	0.0748
120	6C040-42760	CUSHION	1				0.003	0.0066
130	6C050-42840	ROD MID PTO	1				0.23	0.506
140	05525-61000	PIN SNAP	2				0.002	0.0044
150	05511-52520	PIN SPLIT	1				0.001	0.0022
160	04011-50100	WASHER PLAIN	2	<=15232			0.002	0.0044
160	04011-50100	WASHER PLAIN	1	>=15233			0.002	0.0044
170	6C050-18610	ROD FORK	1				0.108	0.2376
180	6C040-18620	FORK PTO SHIFT	1				0.09	0.198
190	62061-18260	SPRING STOPPER	1				0.002	0.0044
200	07715-01605	BALL	1				0.003	0.0066
210	04613-50120	CIR CLIP EXTERNAL	1				0.001	0.0022
220	6C040-18710	ARM PTO SHIFT	1				0	0
230	04811-00160	O RING	2				0	0
230	04816-00160	O RING	2		↔		0.003	0.0066

MidWestTech | Kubota B2710HSD Tractor Parts Manual | Publication B2710HSD Order the manual at mid-west-tech.com >

HYDRAULIC OIL LINE(OIL COOLER)

S.No.:>=50101

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C170-39320	PIPE RETURN	1				0.6	1.32
020	6C050-39410	CLAMP PIPE	1				0.013	0.0286
030	04013-60100	WASHER PLAIN	1				0.003	0.0066
040	04811-00120	O RING	2				0	0
040	04816-00120	O RING	2		←		0.001	0.0022
050	01123-60816	BOLT	1				0.01	0.022
060	6C150-39350	PIPE	1				0.2	0.44
070	04811-00120	O RING	2				0	0
070	04816-00120	O RING	2		←		0.001	0.0022
080	01123-60816	BOLT	1				0.01	0.022
090	6C170-39360	PIPE	1	<=50195		NOT SALE ORDER BY REF No.180	0	0
090	6C170-39362	PIPE	1	>=50196	←	NOT SALE ORDER BY REF No.180	0.45	0.99
090	6C170-39364	PIPE	1	>=54055	≠		0.56	1.232
100	06013-51203	JOINT PIPE	1				0.035	0.077
110	6C140-39250	CUSHION	1				0.014	0.0308
120	6C140-39240	CLAMP	1				0.065	0.143
130	01135-51030	BOLT	1				0.03	0.066
140	6C150-58710	PIPE COOLER	1				1.7	3.74
150	01125-60816	BOLT	2	<=50195			0.01	0.022
150	01125-50818	BOLT	2	>=50196	≠		0.015	0.033
160	06013-51203	JOINT PIPE	2				0.035	0.077
170	01123-60816	BOLT	1	<=55054			0.01	0.022
170	3F740-83450	BUSH	1	>=54055	≠		0.001	0.0022
180	6C170-93910	ASSY PIPE	1				0.45	0.99

MidWestTech | Kubota B2710HSD Tractor Parts Manual | Publication B2710HSD Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C070-47210	MARK MAIN SWITCH	1	<=51135			0	0
010	6C070-47212	MARK MAIN SWITCH	1	>=51136	←		0.001	0.0022
020	6C070-47270	MARK MODEL LH	1				0.02	0.044
030	6C070-47280	MARK MODEL RH	1				0.02	0.044
040	6C140-47520	MARK PS	2				0.001	0.0022
050	6C040-47530	MARK 4WD	1	<=55854			0.001	0.0022
050	6C040-47530	MARK 4WD	1	>=55855			0.001	0.0022
060	6C050-47550	MARK HST	2				0.001	0.0022
070	6C070-47250	MARK PILLAR LH	1				0.001	0.0022
080	6C070-47260	MARK PILLAR RH	1				0.001	0.0022
090	6C040-47510	LABEL PARKING	1	<=51135			0	0
090	6C040-47512	LABEL PARKING	1	>=51136	←		0.001	0.0022
100	TA040-49370	MARK ACCEL.GRIP	1				0.001	0.0022
110	6C090-49650	LABEL START CAUTION	1				0.005	0.011
120	6C070-47420	LABEL SAFETY	1	<=53854			0	0
120	6C070-47422	LABEL SAFETY	1	>=53855	←		0.005	0.011
130	6C140-47440	LABEL DRAWBAR	1				0.001	0.0022
135	6C140-47460	LABEL ROPS WARNING	1			RIGID ROPS TYPE	0.001	0.0022
135	3A111-95540	LABEL ROPS CAUTION	1			FOLDABLE ROPS TYPE	0.003	0.0066
140	TA040-49320	LABEL ROPS WARNING	1			RIGID ROPS TYPE	0.001	0.0022
140	TA240-98480	LABEL ROPS WARNING	1			FOLDABLE ROPS TYPE	0.005	0.011
150	6C040-47412	LABEL FILLER CAUTION	1				0.001	0.0022
160	32751-49580	LABEL FAN BELT	2				0.001	0.0022
170	TA040-49580	LABEL MUFFLER	1				0.001	0.0022
180	6C050-47480	LABEL PEDAL	1				0.002	0.0044
190	6C070-47310	LABEL LEVER LH	1				0.07	0.154
200	6C070-47320	LABEL LEVER RH	1				0.07	0.154
210	6C050-47310	LABEL HST	1	<=51135			0	0
210	6C050-47312	LABEL HST	1	>=51136	←		0.001	0.0022
220	6C150-47430	LABEL PARKING	1				0.002	0.0044
230	32721-58282	LABEL CAUTION	1				0.001	0.0022
240	6C040-55590	LABEL BATTERY	1				0.001	0.0022
250	TA040-49590	LABEL PTO WARNING	1				0.002	0.0044
260	6C070-47332	LABEL	1				0.001	0.0022
270	99999-99999	NAME PLATE	1				0	0

MidWestTech | Kubota B2710HSD Tractor Parts Manual | Publication B2710HSD
Order the manual at mid-west-tech.com >