ILLUSTRATED PARTS LIST

KUBOTA

B6100E-P

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0			ASSY REAR WHEEL 7-16 REF.No.002 003 OBTA	0	0
002	99999-99999	BLANK	0			ASSY REAR WHEEL LH REF.No.004 TO 014 OBT	0	0
003	99999-99999	BLANK	0			ASSY REAR WHEEL RH REF.No.004 TO 014 OBT	0	0
004	99999-99999	BLANK	0			WHEEL OBTAINED LOCALLY	0	0
005	99999-99999	BLANK	0			TUBE OBTAINED LOCALLY	0	0
006	99999-99999	BLANK	0			TIRE OBTAINED LOCALLY	0	0
007	99999-99999	BLANK	0			ASSY VALVE OBTAINED LOCALLY	0	0
008	99999-99999	BLANK	0			CORE VALVE OBTAINED LOCALLY	0	0
009	99999-99999	BLANK	0			CAP OBTAINED LOCALLY	0	0
010	66704-17100	ASSY HUB WHEEL	2			REF.No.011 TO 015	0	0
010	66704-17200	ASSY HUB WHEEL	2	>=10001		REF.No.011 TO 014	2.95	6.49
011	66704-17300	ASSY WHEEL HUB BOLT	2			REF.No.012 013	0	0
012	66704-17150	HUB WHEEL	2	>=10001			2.6	5.72
013	01073-51435	BOLT	12				0.063	0.1386
013	66704-17310	BOLT	12	>=10001			0	0
014	02076-50140	NUT	12				0.022	0.0484
014	35340-11390	NUT	12	>=10001			0.03	0.066
015	04512-50140	WASHER SPRING	12				0	0
016	04013-50140	WASHER PLAIN	12				0	0
017	63733-17250	BOLT WHEEL HAB SET	2				0.08	0.176
018	63512-17230	SPRING SET BOLT	2				0.014	0.0308
019	66621-17160	PIN AXLE	2				0.05	0.11
020	62131-17290	PIN SNAP	2				0.004	0.0088

MidWestTech | Kubota B6100E-P Tractor Parts Manual | Publication B6100E-P Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	66711-45900	ASSY SEAT	1			REF.No.002 003	4.8	10.56
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001 OR 018	0	0
004	66711-45930	SUPPORT SEAT FRONT	1				0.7	1.54
005	66711-36440	BOLT	2				0.045	0.099
006	04512-50120	WASHER SPRING	2				0	0
007	66591-41540	CUSHION	4				0.01	0.022
008	66591-41550	COLLAR	2				0.02	0.044
009	05122-51045	PIN JOINT	2				0	0
010	05516-51000	PIN SNAP	2				0	0
011	66711-45940	SUPPORT SEAT REAR	1				0.527	1.1594
012	32240-18440	CUSHION SEAT	2				0.043	0.0946
013	01120-50820	BOLT	2				0	0
013	01123-50825	BOLT	2				0.013	0.0286
014	01150-50816	BOLT	2				0.01	0.022
015	04013-50080	WASHER PLAIN	2				0	0
016	04512-50080	WASHER SPRING	2				0	0
017	02114-50080	NUT	2				0.005	0.011
018	66704-83500	ASSY COVER SEAT	1			REF.No.003 019 AND 020	0.4	0.88
019	35110-85050	EYE-LET	4			2 PIECES ARE SPARE	0.005	0.011
020	35110-85060	PROTECTOR	3				0.01	0.022
021	66704-54950	BRACKET SMV	1			AMERICA CANADA	0	0
022	01050-50616	BOLT	2			AMERICA CANADA	0	0
023	04013-50060	WASHER PLAIN	2			AMERICA CANADA	0	0
024	04512-50060	WASHER SPRING	2			AMERICA CANADA	0	0
025	02014-50060	NUT	2			AMERICA CANADA	0.003	0.0066

MidWestTech | Kubota B6100E-P Tractor Parts Manual | Publication B6100E-P Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15261-43010	ASSY FILTER FUEL	1			REF.No.002 TO 014	0	0
001	19204-43010	ASSY FILTER FUEL	1	>=10001		REF.No.002 TO 014 AND 027	0.37	0.814
001	15372-43010	ASSY FILTER FUEL	1	>=10001		REF.No.002 TO 015 AND 027	0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	14301-43520	LEVER COCK	1				0	0
004	15231-43810	VALVE TAPER	1				0.002	0.0044
005	14301-43820	SPRING VALVE	1				0.001	0.0022
006	14301-43830	SCREW LEVER	1				0.001	0.0022
007	14301-43840	O RING IEVER	1				0.001	0.0022
008	15231-43580	CUP FILTER	1				0	0
008	15000-34830	CUP FILTER	1				0	0
009	14301-43590	RETERING RING	1				0.054	0.1188
010	14301-43650	O RING FILTER	1				0.001	0.0022
011	15231-43560	ASSY ELEMENT	1				0.03	0.066
012	04811-00100	O RING FILTER	1				0.001	0.0022
013	15231-43282	PLUG BREATHER	2				0.004	0.0088
014	04810-00060	O RING	2				0.001	0.0022
015	15000-34840	SPRING	1				0.003	0.0066
016	01150-50865	BOLT	1				0	0
017	04512-50080	WASHER SPRING	1				0	0
018	15371-42050	ASSY PIPE FUEL O/F	1			REF.No.019 AND 020	0.016	0.0352
019	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
020	10244-42320	CLIP PIPE	2				0.001	0.0022
021	15371-42020	ASSY PIPE FUEL 1	1			REF.No.022 AND 023	0.034	0.0748
022	99999-99999	BLANK	0			ORDER BY REF.No.021	0	0
023	14301-42750	CLIP PIPE	2				0.005	0.011
024	15371-42030	ASSY PIPE FUEL 2	1			REF.No.025 AND 026	0	0
025	99999-99999	BLANK	0			ORDER BY REF.No.024	0	0
026	14301-42750	CLIP PIPE	2				0.005	0.011
027	15567-87460	LABEL	1	<=11600			0.001	0.0022
027	66706-58310	LABEL	1	>=10001			0.001	0.0022

MidWestTech | Kubota B6100E-P Tractor Parts Manual | Publication B6100E-P Order the manual at mid-west-tech.com >