ILLUSTRATED PARTS LIST

KUBOTA

B7100HST-E NEW TYPE

TRACTOR



Kubota

MidWestTech | Kubota B7100HST-E New Type Tractor Parts Manual | Publication B7100H... Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66204-41102	ASSY STEERING	1				6.8	14.96
020	66204-41110	CASE STEERING GEAR	1	<=20045			0	0
020	66204-41113	CASE STEERING GEAR	1	>=20046	←		2.7	5.94
030	34150-16640	PLUG	1				0.015	0.033
040	06331-35010	PLUG	1	<=20045			0.012	0.0264
050	04717-01000	WASHER WITH RUBBER	1	<=20045			0.001	0.0022
060	66811-41200	COMP.NUT BALL	1				1	2.2
070	66811-41140	BEARING THRUST BALL	2	<=20057			0.045	0.099
070	66811-41140	BEARING THRUST BALL	1	>=20058			0.045	0.099
071	66811-91110	BEARING OUTER	1	>=20058			0.031	0.0682
080	66811-41150	SHAFT SECTOR	1				0.52	1.144
090	09500-22358	SEAL OIL	1				0.01	0.022
100	66811-41160	COVER SIDE	1				0.3	0.66
110	66811-41170	GASKET	1				0	0
120	01123-50822	BOLT	3				0.012	0.0264
130	66811-41180	SCREW ADJUSTING	1				0.013	0.0286
140	66811-41190	COLLAR ADJUSTING	1			1.515 TO 1.535MM	0.002	0.0044
140	66811-41210	COLLAR ADJUSTING	1			1.545 TO 1.565MM	0.001	0.0022
140	66811-41220	COLLAR ADJUSTING	1			1.575 TO 1.595MM	0.001	0.0022
140	66811-41230	COLLAR ADJUSTING	1			1.605 TO 1.625MM	0.001	0.0022
140	66811-41240	COLLAR ADJUSTING	1			1.635 TO 1.655MM	0.001	0.0022
150	61011-18140	PLUG RUBBER	1				0.002	0.0044
160	66811-41250	NUT	1				0.027	0.0594
170	04714-00080	GASKET	1				0.001	0.0022
180	66204-41122	POST STEERING	1				0.5	1.1
190	01513-50822	STUD	4				0.01	0.022
200	04512-50080	WASHER SPRING	4				0	0
210	02114-50080	NUT	4				0.005	0.011
220	66811-41320	SHIM	1			0.05MM	0.001	0.0022
220	66811-41340	SHIM	1			0.08MM	0.001	0.0022
220	66811-41350	SHIM	1			0.10MM	0.001	0.0022
220	66811-41360	SHIM	1			0.20MM	0.003	0.0066
220	66811-41370	SHIM	1			0.50MM	0.007	0.0154
230	09500-16287	SEAL OIL	1				0.01	0.022
240	67211-41150	BUSH POST	1				0.016	0.0352
250	66204-41410	ARM PITMAN	1				0.4	0.88
260	02172-50160	NUT	1				0.017	0.0374
270	04512-50160	WASHER SPRING	1				0	0
280	01517-51028	STUD	4				0.022	0.0484
290	02118-50100	NUT	4				0.005	0.011
300	04512-50100	WASHER SPRING	4				0	0
310	32400-16800	ASSY WHEEL STEERING	1				1.96	4.312
320	32400-16820	PAD STEERING	1				0.05	0.11
330	04013-50120	WASHER PLAIN	1				0	0
340	04512-50120	WASHER SPRING	1				0	0
350	02172-50120	NUT	1				0.01	0.022

MidWestTech | Kubota B7100HST-E New Type Tractor Parts Manual | Publication B7100H... Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66404-36600	ASSY CAP CYLINDER	1				1.17	2.574
020	04811-00120	O RING	1				0	0
030	04811-00160	O RING	1				0	0
040	96319-01430	WASHER THRUST	1				0.002	0.0044
050	96319-01440	SPRING	1				0.002	0.0044
060	96319-01450	KNOB	1				0.04	0.088
070	05411-00520	PIN SPRING	1				0.002	0.0044
080	04810-50550	O RING	1				0.002	0.0044
090	04810-05110	O RING	1				0.001	0.0022
100	66711-36440	BOLT	4				0.045	0.099
110	04512-50120	WASHER SPRING	4				0	0
120	66611-36413	STAY	1				0.14	0.308
130	01123-51025	BOLT	2				0.02	0.044
140	04013-50100	WASHER PLAIN	2				0	0
150	06311-25040	PLUG	1				0.09	0.198
160	66611-36420	GASKET	1				0.006	0.0132
170	67211-36410	PISTON HYD.	1				0.55	1.21
180	04810-08500	O RING	1				0	0
190	67211-36420	RING BACK UP	1				0.003	0.0066
200	66591-36640	ROD HYD.PISTON	1				0.31	0.682
210	66591-36650	ARM HYDRAULIC	1				0.8	1.76
220	66591-36660	PIN ARM	1				0.045	0.099
230	66591-36670	STOPPER	1				0.01	0.022
240	01202-50614	BOLT	2				0.006	0.0132
250	66621-36750	PLATE HYD.ARM	1				0.34	0.748
260	67211-36610	BOLT	2				0.015	0.033

MidWestTech | Kubota B7100HST-E New Type Tractor Parts Manual | Publication B7100H... Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66727-52710	FENDER LH	1				4.25	9.35
020	66727-52720	FENDER RH	1				5.5	12.1
030	01123-50818	BOLT	8				0.012	0.0264
040	66612-52730	FENDER EXTENSION LH	1				0.58	1.276
050	66612-52740	FENDER EXTENSION RH	1				0.6	1.32
060	04013-50060	WASHER PLAIN	6				0	0
070	01202-50614	BOLT	6				0.006	0.0132
080	66612-52750	RAIL LH	1				0.24	0.528
090	66612-52760	RAIL RH	1				0.24	0.528
100	01123-50820	BOLT	4				0.011	0.0242
110	04013-50080	WASHER PLAIN	4				0	0
120	38240-29570	PLUG	6				0.001	0.0022
130	66204-53110	COVER SUB	1				1.95	4.29
140	01820-50615	BOLT KNOB	4				0.017	0.0374
150	66204-53130	STAY FRONT	1				0.165	0.363
160	66204-53140	STAY REAR	1				0.09	0.198
170	01123-50820	BOLT	2				0.011	0.0242
180	66204-53150	TRIM SASH	1				0.02	0.044
190	66204-47140	LABEL	1				0.001	0.0022

MidWestTech | Kubota B7100HST-E New Type Tractor Parts Manual | Publication B7100H... Order the manual at mid-west-tech.com >