ILLUSTRATED PARTS LIST

KUBOTA

B7300HSD

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C040-97910	ASSY DIFFERENTIAL	1				4.16	9.152
020	6C040-97920	ASSY GEAR BEVEL	1			6-37T	1.97	4.334
030	6C040-14970	CASE DIFFERENTIAL	1				0.7	1.54
040	67711-14912	SHAFT DIFF.PINION	1				0.14	0.308
050	67711-14920	PINION DIFF.	2				0.11	0.242
060	6C040-14930	GEAR DIFF.SIDE	2				0.165	0.363
070	67211-15160	SHIM	2			1.0MM	0.01	0.022
070	67211-15170	SHIM	2			0.8MM	0.008	0.0176
070	67211-15180	SHIM	2			1.2MM	0.01	0.022
080	66591-14792	PIN KNOCK	1				0.003	0.0066
090	66591-14783	PIN STRAIGHT	1				0.01	0.022
100	67810-56680	BOLT UBS	6				0.013	0.0286
110	08101-06009	BEARING BALL	1				0.22	0.484
120	08101-06010	BEARING BALL	1				0.262	0.5764
130	66591-14980	SHIM DIFF.SIDE	1			0.5MM	0.005	0.011
130	66591-14990	SHIM DIFF.SIDE	1			0.2MM	0.002	0.0044
140	66611-15140	SHIM DIFF.SIDE	1			0.5MM	0.006	0.0132
140	66611-15150	SHIM DIFF.SIDE	1			0.2MM	0.002	0.0044
150	04611-00750	CIR CLIP INTERNAL	1				0.019	0.0418
160	6C040-14940	SHAFT DIFF.GEAR LH	1				0.62	1.364
170	6C040-14950	SHAFT DIFF.GEAR RH	1				0.72	1.584
180	08101-06306	BEARING BALL	2				0.335	0.737

MyTractorForum.com

MidWestTech | Kubota B7300HSD Tractor Parts Manual | Publication B7300HSD Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C040-56370	CASE GEAR LH	1	<=10011			7.8	17.16
010	6C040-56372	CASE GEAR LH	1	>=10012	≠		8	17.6
020	6C040-56360	CASE GEAR RH	1	<=10011			7.3	16.06
020	6C040-56363	CASE GEAR RH	1	>=10012	≠		7.4	16.28
030	06331-35010	PLUG	4	<=14989			0.012	0.0264
030	01774-51010	BOLT FLANGE	4	>=14990	←		0.08	0.176
040	04717-01000	WASHER WITH RUBBER	4				0.001	0.0022
050	6C040-56340	COVER GEAR CASE	2	<=17617			0	0
050	6C040-56345	COVER GEAR CASE	2	>=17618	←		0.84	1.848
060	01133-51028	BOLT	20				0.027	0.0594
070	6A100-57320	SHAFT FRONT AXLE	2				1.7	3.74
075	6C040-57330	BOLT	12				0.035	0.077
080	6C040-57310	GEAR BEVEL	2				2.79	6.138
090	08101-06206	BEARING BALL	2				0.196	0.4312
100	08101-06305	BEARING BALL	2				0.23	0.506
110	67156-56820	COLLAR SET	4				0.004	0.0088
120	37410-57340	SEAL OIL	2				0	0

MyTractorForum.com

MidWestTech | Kubota B7300HSD Tractor Parts Manual | Publication B7300HSD Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C090-53510	COVER PANEL	1				4	8.8
020	6C040-53522	COVER FRAME	1				0.14	0.308
030	37410-61720	SCREW	1				0.001	0.0022
040	6C090-54210	PILLAR CENTER	1	<=16202			1.55	3.41
040	6C090-54213	PILLAR CENTER	1	>=16203	←		1.6	3.52
050	01133-51022	BOLT	2				0.025	0.055
060	6C090-54200	KIT PILLAR CENTER	1				6	13.2
070	6C040-54610	BOLT	2				0.014	0.0308
080	6C090-54230	STAY PILLAR	1				0.355	0.781
090	01023-50616	BOLT	1				0.005	0.011
095	01023-50625	BOLT	1				0.007	0.0154
100	6C040-54283	BRACKET	1				0.09	0.198
110	6C090-54550	COVER HEAT PROOF	1	<=12526			0	0
110	6C090-54554	COVER HEAT PROOF	1	>=12527	←		0.21	0.462
120	52300-26210	NUT	4				0.002	0.0044
125	6C090-54570	PLATE	1				0.072	0.1584
126	05525-50800	PIN SNAP	1				0.001	0.0022
130	6C090-54320	COMP.COVER SIDE	1				1	2.2
140	6C040-54333	COVER	1				0.24	0.528
150	55611-44190	NUT	7				0.004	0.0088
160	6C090-54350	COMP.COVER SIDE	1				0	0
170	6C040-54383	COVER	1				0.24	0.528
180	55611-44190	NUT	7				0.004	0.0088
190	6C040-54364	SPRING	4				0.004	0.0088
200	66591-54580	RUBBER RELEASE ROD	2				0.003	0.0066
210	6C090-49650	LABEL START CAUTION	1			ENGLISH	0.005	0.011
210	6C091-49650	LABEL START CAUTION	1			FRENCH	0.01	0.022
220	6C040-47412	LABEL FILLER CAUTION	1				0.001	0.0022
230	37300-33450	COLLAR	1				0.005	0.011

MyTractorForum.com

MidWestTech | Kubota B7300HSD Tractor Parts Manual | Publication B7300HSD Order the manual at mid-west-tech.com >