310B/M420/430/44 Forklifts

Parts Catalog

B904

CASE CONSTRUCTION

MidWestTech | Case 310B, M420, M430, M44 Forklift Parts Catalog | Publication B904

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Angling Dozer - Attachment 73,75
Attachments 47,83

B

Box - Weight 5
Bucket - Loader, Attachment 51,53

C

Cement Bucket - Attachment 69
Chain 17,21,23
Control Tower 9
Crane Boom - Attachment 71
Cylinder - Bucket 45,47
Cylinder - Mast Lift 43
Cylinder - Mast Tilt 45
Cylinder - Side Shifter 47
Cylinder - Tilt Fork 45

D

Dozer - Angling (Attachment) 73,75
Drive - Hydraulic Pump 33

F

Filter - Oil, Hydraulic 33
Floor Plate 9
Forks - Cement Block 27
Forks - Pallet 27
Frame - Fork Lift 5

G

Guard - Overhead 7

H

Hydraulics - Auxiliary 55,57
Hydraulics - Basic 29,31
Hydraulics - Log Forks 81
Hydraulics - Side Shifter 61-67
Hydraulics - Tilt Fork 49

I

Instruments and Wiring 11

L

Levers - Control 55,57,61-67
Log Clamp - Attachment 77,81

M

Masts 19-25,83

P

Pedals - Foot 13
Pump - Hydraulic 35

S

Seat 7
Side Shifter 59
Steering 9,13,17

T

Tilt Fork - Attachment 49
Tower - Control 9
Truss Rod - Attachment 79

V

Valve - Control, Hydraulic 37,39,41

Printed in U.S.A.

Issued January, 1965

MidWestTech | Case 310B, M420, M430, M44 Forklift Parts Catalog | Publication B904 Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.		PART NO.	DESCRIPTION	REQ'D
	A	55159	CYLINDER ASSY - rear steering	1
28	A	56208	SOCKET ASSY - rear cylinder	1
29	A	55956	PLUG - adjusting, socket assy	1
30	A	55957	SEAT - socket ball	2
31	A	56210	SPRING - socket	1
32	A	56209	SEAT - socket spring	1
33	G	45175	CLAMP ASSY - socket assy	1
	16-	836	BOLT - 1/2" x 2-1/4" N.F.hex.	1
34	132-	104	PIN - cotter, 3/16" x 3"	1
35	A	55889	STUD - ball,socket & cylinder	2
36	13-	410	BOLT - 1/4" x 5/8" N.C.,hex.	4
37	92-	4	LOCKWASHER - 1/4" SAE	4

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of the basic Tractor are determined by standing at the rear of the unit and facing in direction of forward travel of the machine (small wheels in front).

In this Catalog "Right Hand" and "Left Hand" sides of the Fork Lift are determined by sitting in the operator's seat and facing in direction of forward travel of the Fork Lift (large wheels in front).

Order the manual at mid-west-tech.com >