530CK Forklift


Parts Catalog

B918


CASE CONSTRUCTION

MidWestTech | Case 530CK Forklift Parts Catalog | Publication B918

Order the manual at mid-west-tech.com >



1. Trim along the dotted line
2. Slide into the pocket on the Binder spine



1. Trim along the dotted line
2. Slide into the pocket on the Binder spine

Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description


Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.		PART NO.	DESCRIPTION	REQ'D.
	A	55159	CYLINDER ASSY. - rear steering	1
28	A	56208	SOCKET ASSY. - rear cylinder	1
29	A	55956	PLUG - adjusting, socket assy.	1
30	A	55957	SEAT - socket ball	2
31	A	56210	SPRING - socket	1
32	A	56209	SEAT - socket spring	1
33	G	45175	CLAMP ASSY. - socket assy.	1
34	16-	836	HHCS - 1/2" - 20 NF x 2-1/4"	1
35	132-	104	PIN - cotter, 3/16" dia. x 3"	1

Terms "Right Hand" and "Left Hand" "Front" and "Rear"

The terms "Right Hand" and "Left Hand" sides of the fork lift are determined by sitting in the operator's seat facing the mast.

The terms "Front" and "Rear" of the fork lift are also determined by sitting in the operator's seat facing the mast.



Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accessory Attachments - Optional 21-33
Accessory Hydraulics - Loader Bucket (Standard 10' 6" and 14' 3" Masts) 53
Accessory Hydraulics - Loader Bucket (Standard 21' 6" Mast) 55
Accessory Hydraulics - Log Clamp 25,27
Accessory Hydraulics - Side Shifter (Standard 10' 6" and 14' 3" Masts) 21
Accessory Hydraulics - Side Shifter (Standard 21' 6" Mast) 23

B

Blade - Dozer 31
Boom - Crane 31
Bucket - Cement 33
Bucket - Loader 33
Brake - Pedals and Linkage 37

C

Chain - lift 9-19
Clutch - Pedal and Linkage 39
Control Tower 35
Counterweight - Fork Lift 5
Counterweight - Hydraulic Hose 23,55
Cylinder - Lift (10' 6" Mast) 57
Cylinder - Lift (12' Mast) 57
Cylinder - Lift (14' 3" Mast) 59
Cylinder - Lift (21' 6" Mast) 59
Cylinder - Loader Bucket 61,71
Cylinder - Log Clamp 65-69,77,79
Cylinder - Side Shifter 63,75
Cylinder - Tilt 61,65,71,73

D

Decal Kit 88
Drive - Pump 45

F

Filter - Hydraulic Oil 45
Forks - Cement Block 29
Forks - Logging 29
Forks - Pallet 29
Frame - Fork Lift Sub 5

G

Guard - Overhead 7

H

Hose and Fitting Conversion Part Numbers 89
Hydraulics - Fork Lift Primary 45,47
Hydraulics - Lift Cylinder 49
Hydraulics - Loader Bucket (Standard 10' 6" and 14' 3" Masts) 53
Hydraulics - Loader Bucket (Standard 21' 6" Mast) 55
Hydraulics - Log Clamp 25,27
Hydraulics - Side Shifter (Standard 10' 6" and 14' 3" Mast) 21

H

Hydraulics - Side Shifter (Standard 21' 6" Mast) 23
Hydraulics - Steering 41
Hydraulics - Tilt Cylinder 51

I

Index - numerical 89
Instruments and Wiring 43

L

Lamps - Head 43
Lever - Accessory Control 21-25,53-55
Levers - Fork Lift Control 35
Linkage - Brakes 37
Linkage - Clutch 39
Linkage - Foot Throttle 37-39
Linkage - Shuttle 39

M

Mast and Related Parts (Standard 10' 6") 9
Mast and Related Parts (Heavy Duty 12') 17
Mast and Related Parts (Standard 14' 3") 11
Mast and Related Parts (Heavy Duty 14' 3") 19
Mast and Related Parts (Standard 21' 6") 13-15

N

Numerical Index 89

P

Pedals - Foot 37-39
Pump - Drive 45
Pump - Hydraulic 81-83

S

Seat - Fork Lift, Operator's 41
Shuttle - Lever, Control 35
Shuttle Linkage 39
Side Shifter (Standard 10' 6" and 14' 3" Masts) 21
Side Shifter (Standard 21' 6" Mast) 23
Steering - Hydraulics 41
Subframe - Fork Lift 5

T

Tanks - fuel 41
Tool Box 37
Tower - Control 35
Truss Rod Parts 7

V

Valve - Hydraulic Control 85-87

Order the manual at mid-west-tech.com >