430 CK Tractor

Parts Catalog

B923

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.	PART NO.	DESCRIPTION	REQ'D
A	55159	CYLINDER ASSY. - rear steering	1
28 A	56208	SOCKET ASSY. rear cylinder	1
29	NSS	PLUG - adjusting, socket assy	1
30	NSS	SEAT - socket ball	2
31	NSS	SPRING - socket	1
32	NSS	SEAT - socket spring	1
33 G	45175	CLAMP ASSY. - socket assy.	1
16-	836	BOLT - 1/2" x 2-1/4" N.F. hex.	1
34 132-	104	PIN - cotter, 3/16" x 3"	UAR
35 A	55889	STUD - ball, socket & cylinder	2
36 13-	410	BOLT - 1/4" x 5/8" N.C., hex	4
37 92-	4	LOCKWASHER - 1/4" SAE	4

NOTE **NSS** IN PART NO. COLUMN INDICATES THIS PART IS NOT SERVICED SEPARATELY.
UAR IN AMT. REQ'D COLUMN INDICATES THIS PART IS USED AS REQUIRED.

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.

Order the manual at mid-west-tech.com >