500
LOAD KING

Parts Catalog

B953

CASE CONSTRUCTION

MidWestTech | Case 500 Load King Wheel Loader Parts Catalog | Publication B953

Order the manual at mid-west-tech.com >

CASE "500" LOAD KING

ALPHABETICAL INDEX

ENGINE SECTION

	DIESEL	GAS
AIR INTAKE & EXHAUST SECTION:		
AIR CLEANER	7	31
EXHAUST PIPE	7	31
HEATER, MANIFOLD	53F,55	-
MANIFOLDS	7	31
MUFFLER	7	31
COOLING SECTION:		
RADIATOR	5	29
THERMOSTAT	5	29
WATER PUMP, BELT & FAN	5	29
ENGINE SECTION:		
CAMSHAFT & BUSHINGS	13B	33B
CONNECTING RODS & BRGS.	21	41
CRANKSHAFT & BRGS.	17	39
CYLINDER BLOCK	13D-15B	35
CYLINDER HEAD & COVER	11B,13	33
CYLINDER SLEEVES	21	41
FLYWHEEL & HOUSING	17B	39
GASKET KITS	23	45
GOVERNOR	-	43
HEATER, MANIFOLD	53F,55	-
MOUNTS	105	105
OIL FILTER	19	37
OIL PAN	19	37
OIL PUMP	19	37
PISTONS AND RINGS	21	41
ROCKER ARMS & SHAFT	13B	33B
TIMING GEAR COVER	9B	29
VALVE MECHANISM	13B	33B
WATER PUMP	5	29
FUEL SECTION:		
CARBURETOR	-	49,51
FUEL FILTER, FINAL STAGE	11	-
FUEL FILTER, PRIMARY	11	-
FUEL INJECTION LINES	7B,9	-
FUEL INJECTION PUMP	11	-
FUEL INJECTORS	7B,9	-
FUEL STRAINER	-	47
FUEL TANK & LINES	25	47
THROTTLE & CONTROLS	25	43,43B
LUBRICATION SECTION:		
OIL FILTER	19	37
OIL PAN	19	37
OIL PUMP	19	37

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

BASIC TRACTOR SECTION

AXLE SECTION:
- DIFFERENTIAL 95
- FRONT AXLE 87B
- HOUSING, FRONT AXLE. . . . 87B
- REAR AXLE 103
- SPINDLES 103
- TIE RODS 103

BRAKE SECTION:
- BRAKE ASSY 95
- BRAKE CONTROLS 93,95
- BRAKE PEDALS 93

CHASSIS SECTION:
- BUCKETS, LOADER 123
- CHASSIS 105
- COUNTERWEIGHT. 105
- ENGINE MOUNTING 105
- LIFT ARM 123
- RAD. FRAME & GRILLE 107
- SEAT, OPERATOR'S 107

ELECTRICAL SECTION:
- ALTERNATOR 71
- BATTERY & CABLES. 53D
- DISTRIBUTOR 73,75
- ELEC.EQUIP. &WIRING . . 53D-59
- END. TROUBLE IND. LAMP . . 61
- FRONT & REAR LAMPS. 61
- GENERATOR 53,61B
- INSTRUMENT PANEL 53.105
- LIGHTING EQUIPMENT 61
- STARTER MOTOR 61D,65
- STOP & TAIL LAMP 61
- WIRING - CHASSIS 53D-59
- WIRING, INSTRUMENTS 53B

FORK LIFT SECTION:
- FORK LIFT 125

HYDRAULIC SECTION:
- CYLINDER, LIFT 121
- CYLINDER, TILT 119
- HOSES & LINES 113,115
- HYD. CONTROLS. 113
- OIL FILTER. 115
- OIL RESERVOIR 115
- PUMP, HYD. 111
- VALVE, CONTROL 117

SHEET METAL SECTION:
- DECALS 125
- HOOD 107
- PANEL, INSTRUMENT 105
- PLATFORMS 107B
- RAD. FRAME & GRILLE 107
- SIDE PANELS 107
- TRAY, BATTERY 107B

STEERING SECTION:
- ARMS, STEERING 103
- CYLINDER, STR. 99,101
- HOSES & TUBES 99
- PUMP, POWER STR. 99
- STR. WHEEL & GEAR 97
- TIE ROD 103

TRANSMISSION SECTION:
- CLUTCH,FRWD & REV. . 83B,83D
- CONVERTER COOLER HOSES . 85
- CONVERTER & TRANS. . . . 79-91
- COUNTERSHAFT, TRANS. . . . 91
- DIPSTICK, TRANS. 81
- FILTER SCREEN, TRANS. . . . 81
- GASKETS, TRANS 85
- GEAR SHIFT 87
- HOUSING, CONV. 79
- MAIN SHAFT, TRANS. 91
- MANUAL TRANS. 91
- POWER SHUTTLE TRANS. . . . 81
- PUMP, CONVERTER 79
- SHAFT, DRIVE 85
- TORQUE CONV. ASSY. 79
- TRANS. CASE & COVERS 89
- TRANS. MOUNTS 81
- VALVE CONTROLS, CONV. . . . 77
- VALVE, CONV. CONTROL . . . 83

WHEEL SECTION:
- FRONT WHEELS 109
- REAR WHEELS 109

Order the manual at mid-west-tech.com >