ILLUSTRATED PARTS LIST

KUBOTA

BX1500D

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

NEUTRAL HOLDER LINK

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2561-42410	ARM HST TRUNNION	1				0	0
020	K2561-42420	BOLT HST TRUNNION	1				0.017	0.0374
030	02014-50060	NUT	1				0.003	0.0066
040	04512-50060	WASHER SPRING	1				0	0
050	6C050-43450	BUSH	1				0.005	0.011
060	04612-00220	CIR CLIP EXTERNAL	1				0.001	0.0022
070	K2561-42450	PLATE HST NEUTRAL	1				0	0
080	01123-50825	BOLT	2				0.013	0.0286
090	K2561-42470	LEVER NEUTRAL	1				0	0
100	K2561-42480	COLLAR	1				0	0
110	01125-50825	BOLT	1				0.018	0.0396
120	02054-50080	NUT	1				0.005	0.011
130	K2561-42513	ARM HST NEUTRAL	1				0	0
140	K2561-42523	PIN JOINT	1				0	0
150	K2561-42530	BEARING BALL	1				0	0
160	04013-50080	WASHER PLAIN	1				0	0
170	05511-50218	PIN SPLIT	1				0.001	0.0022
180	K2561-42563	SPRING	1				0.13	0.286
190	K2561-42570	ROD ADJUST	1				0	0
200	02114-50080	NUT	2				0.005	0.011

MidWestTech | Kubota BX1500D Tractor Parts Manual | Publication BX1500D Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2561-36360	ROD FEED BACK	1				0	0
020	75599-56003	PIN SNAP	2				0	0
030	K2561-36370	PIN FEED BACK	1				0	0
040	04613-50090	CIR CLIP EXTERNAL	1				0.001	0.0022
050	04011-50120	WASHER PLAIN	2				0.005	0.011
060	K2561-36380	BRACKET FEEDBACK	1				0	0
070	01754-50612	BOLT FLANGE	1				0.005	0.011
080	02054-50080	NUT	2				0.005	0.011
090	02014-50060	NUT	1				0.003	0.0066
100	K2561-36390	SPRING	2				0	0
110	K2561-42810	LEVER HYD.CONTROL	1				0	0
120	K2561-42840	BOSS HYD LEVER	1				0	0
130	05411-00836	PIN SPRING	1				0.008	0.0176
140	05122-50830	PIN JOINT	1				0.014	0.0308
150	K1211-91120	RUE RING COTTER	1				0.001	0.0022
160	K2561-42820	GRIP HYD LEVER	1				0	0
170	K2561-42630	CUSHION	1				0	0
180	K2561-42852	PLATE	1				0	0
190	K1122-91320	BOLT SHORT SQU.NECK	2				0.01	0.022
200	04512-50080	WASHER SPRING	2				0	0
210	02114-50080	NUT	2				0.005	0.011

MidWestTech | Kubota BX1500D Tractor Parts Manual | Publication BX1500D Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2511-95520	KIT FENDER RH	1			ENGLISH	0	0
010	K2517-95520	KIT FENDER RH	1			FRENCH	0	0
015	K2561-65482	LABEL SAFETY	1			ENGLISH	0	0
015	K2567-65482	LABEL SAFETY	1			FRENCH	0	0
020	K2511-95530	KIT FENDER LH	1				0	0
025	K2561-65490	LABEL FUEL FILTER	1				0	0
030	K1122-91320	BOLT SHORT SQU.NECK	4				0.01	0.022
040	04015-50100	WASHER PLAIN	4				0.016	0.0352
050	01153-50816	BOLT	1				0.01	0.022
060	01754-50820	BOLT FLANGE	1				0.015	0.033
070	04512-60080	WASHER SPRING	1				0.002	0.0044
080	02751-50080	NUT	4				0.006	0.0132
090	02552-50080	NUT LOCK	1				0.005	0.011
100	15451-92330	NUT	1				0.015	0.033
110	K2561-55110	BASE TAIL LAMP	2				0	0
120	02054-50040	NUT	6				0.001	0.0022
130	K1122-55280	SCREW TAPPING	4				0.002	0.0044
140	K2561-55210	GUIDE LEVER LH	1				0	0
150	K2561-55220	GUIDE LEVER RH	1				0	0
160	K2561-55270	HOLDER CUP	1				0	0
170	K1122-55280	SCREW TAPPING	6				0.002	0.0044
180	K2561-55280	HANDRAIL	2				0	0
190	K2561-55290	NUT CAP	4				0	0
200	04512-60100	WASHER SPRING	4				0.002	0.0044
210	04011-50100	WASHER PLAIN	4				0.002	0.0044

MidWestTech | Kubota BX1500D Tractor Parts Manual | Publication BX1500D Order the manual at mid-west-tech.com >