ILLUSTRATED PARTS LIST

KUBOTA

BX2230D

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	16861-16023	ASSY CAMSHAFT FUEL	1				0.856	1.8832
020	15875-16173	CAMSHAFT FUEL	1				0.316	0.6952
030	08153-06203	BEARING BALL	1				0.08	0.176
040	16851-51150	GEAR INJECTION PUMP	1				0.2	0.44
050	05712-00515	KEY FEATHER	1				0.003	0.0066
060	15841-55450	SLEEVE GOVERNOR	1				0.05	0.11
070	15841-55690	CASE GOVERNOR BALL	1				0.02	0.044
080	07715-00801	BALL	32				0.001	0.0022
090	15261-55470	CIR-CLIP GOV. SLEEVE	1				0.002	0.0044
100	07715-03217	BALL	8				0.01	0.022
110	16871-97300	BEARING BALL	1				0	0
120	04612-00170	CIR CLIP EXTERNAL	1				0.001	0.0022
130	15841-16320	STOPPER FUEL.C/SHAFT	1				0.015	0.033
140	01023-50612	BOLT	2				0.005	0.011

MidWestTech | Kubota BX2230D Tractor Parts Manual | Publication BX2230D Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	1G962-42500	ASSY PIPE OVER FLOW	1				0.049	0.1078
020	15841-51360	SCREW AIR BREEDER	1				0.008	0.0176
030	15601-96650	GASKET	1				0.001	0.0022
040	16001-53900	KIT HOLDER NOZZLE	3				0.13	0.286
050	16001-53000	ASSY HOLDER NOZZLE	3				0.13	0.286
060	15841-53622	GASKET	3				0.002	0.0044
070	19077-53650	SEAL HEAT	3				0.005	0.011
080	1G460-53710	PIPE INJECTION	1				0.1	0.22
090	1G460-53722	PIPE INJECTION	1				0.18	0.396
100	1G962-53730	PIPE INJECTION	1				0.11	0.242
110	15841-53850	CLAMP PIPE	2				0.01	0.022
120	15841-53860	CLAMP PIPE	2				0.009	0.0198
130	03024-50520	SCREW WITH WASHER	2				0.004	0.0088
140	16851-65510	GLOW PLUG	3				0.02	0.044
150	1G962-65560	CORD GLOW PLUG	1				0.009	0.0198
160	02761-50040	NUT FLANGE	3				0.002	0.0044
170	16809-42030	ASSY TUBE FUEL	1				0.005	0.011
180	09661-40085	TUBE FUEL	1				0.001	0.0022
190	14971-42750	CLIP PIPE	2				0.001	0.0022
200	16809-42500	ASSY TUBE FUEL	1				0.007	0.0154
210	09661-40130	TUBE FUEL	1				0.001	0.0022
220	14971-42750	CLIP PIPE	2				0.001	0.0022
230	1C020-42360	JOINT T-PIPE	1				0.002	0.0044
240	16809-42020	ASSY TUBE FUEL	1				0.002	0.0044
250	09661-40040	TUBE FUEL	1				0.005	0.011
260	14971-42750	CLIP PIPE	2				0.001	0.0022

MidWestTech | Kubota BX2230D Tractor Parts Manual | Publication BX2230D Order the manual at mid-west-tech.com >