TOYOTA

REPAIR MANUAL

7FGU15, 18, 20, 25, 30, 32
7FDU15, 18, 20, 25, 30, 32
7FGCU20, 25, 30, 32

Pub. No. CU027-3

MidWestTech | Toyota 7FGU15, 7FGU18, 7FGU20, 7FGU25, 7FGU30, 7FGU32, 7FDU15... Order the manual at mid-west-tech.com >

GENERAL

Page

EXTERIOR VIEWS 0-2
VEHICLE MODEL 0-3
FRAME NUMBER 0-4
HOW TO USE THIS MANUAL 0-5
- EXPLANATION METHOD 0-5
- TERMINOLOGY 0-6
- ABBREVIATIONS 0-6

OPERATIONAL TIPS 0-7
HOISTING THE VEHICLE 0-8
ATTENTIVE POINTS ON SAS 0-8
CIRCUIT TESTER 0-9
STANDARD BOLT & NUT TIGHTENING TORQUE 0-11
- BOLT STRENGTH TYPE IDENTIFICATION METHOD 0-11
- TIGHTENING TORQUE TABLE 0-12

PRECOAT BOLTS 0-13
HIGH PRESSURE HOSE FITTING TIGHTENING TORQUE 0-13
WIRE ROPE SUSPENSION ANGLE LIST 0-14
SAFE LOAD FOR EACH WIRE ROPE SUSPENSION ANGLE 0-14
COMPONENTS WEIGHT 0-15
RECOMMENDED LUBRICANT QUANTITY & TYPES 0-16
LUBRICATION CHART 0-18
PERIODIC MAINTENANCE 0-19
PERIODIC REPLACEMENT OF PARTS AND LUBRICANTS 0-25

MidWestTech | Toyota 7FGU15, 7FGU18, 7FGU20, 7FGU25, 7FGU30, 7FGU32, 7FDU15... Order the manual at mid-west-tech.com >