1150

Crawler
SN prior to 710900


Parts Catalog


D950


CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

SERIAL NUMBER LOCATIONS







Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.


Indented Description

Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.		PART NO.	DESCRIPTION	REQ'D.
	A	55159	CYLINDER ASSY. - rear steering	1
28	A	56208	SOCKET ASSY. - rear cylinder	1
29	A	55956	PLUG - adjusting, socket assy.	1
30	A	55957	SEAT - socket ball	2
31	A	56210	SPRING - socket	1
32	A	56209	SEAT - socket spring	1
33	G	45175	CLAMP ASSY. - socket assy.	1
34	16-	836	HHCS - 1/2" - 20 NF x 2-1/4"	1
35	132-	104	PIN - cotter, 3/16" dia. x 3"	1

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of the crawler are determined by sitting in the operator's seat facing the direction of forward travel. "Right Hand" and "Left Hand" sides of the backhoe are determined by sitting in the operator's seat facing the backhoe.



Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

CRAWLER SECTION

A

Air Cleaner - dry type 29,31
Air Cleaner - oil bath 31B
Air Cleaner - pre-cleaner 31B
Air Cleaner - extensions 31

B

Brake - parking 85
Brake Pedals - crawler 83
Brakes - hydraulic 71
Brush Guards - crawler 125,127

C

Clutch - forward and reverse 73
Clutch - high and low 73
Control Tower - transmission 81
Control Valve - transmission 79
Cowl - crawler 121
Cushions - seat 133

D

Decals 137
Driveshaft - crawler 63
Dual Range Linkage - transmission 81

E

Electrical System - crawler 37,39
Engine Frame - crawler 33

F

Fan - radiator 35
Filter - oil, transmission 91
Final Drive - crawler 75
Floor Plates - crawler 121
Frame - main 93
Frame - track 97-103
Fuel Line And Strainer - crawler 27

G

Grease Gun - service 135
Grille - crawler 121
Guards - undercarriage 33
Guide Levers - track 93

H

Headlight - crawler 39B
Hood - crawler 121
Hook - pull 33
Hose - radiator 35
Hose and Fitting Assembly Conversion Part Numbers 256
Housing and Covers - transmission 65,65B
Hydraulics - basic tractor 87,89
Hydraulics - transmission 77

I

Idler Wheel - track 111
Index - numerical 257
Instrument Panel - crawler 53
Instrument Panel - wiring 53B

L

Levers - guide, track 93
Levers - control, transmission 81
Linkage - throttle control 55

M

Mechanical Range Shift - transmission 69
Muffler - exhaust 29,31B

P

Parking Brake - crawler 85
Pedals - brake 83
Pre-Cleaner - air 31B
Pre-Heater - engine 39B
Pump - torque converter 61

R

Radiator - engine 35
Recoil System - track 97-103

S

Seat And Tank - crawler 129
Seat Cushions - crawler 133
Seat Frame - crawler 133
Shroud - crawler 121
Side Shields And Brush Guard - crawler 125,127

T

Taillight - crawler 39B
Throttle Control - linkage 55
Torsion Bar - suspension 93
Torque Converter - crawler 57,59
Tools - service 135
Track Adjuster - hydraulic 111
Track Carrier Roller - crawler 109
Track Chain - crawler 113,115
Track Frame - crawler 97-103
Track Guides - crawler 105,107
Track Recoil System - crawler 97-103
Track Rollers - crawler 109-109B
Track Shoes - crawler 117-119B
Transmission - housing and covers 65,65B
Transmission - hydraulics 77
Transmission - mechanical range shift 69
Transmission - shafts, clutches and gears 67

V

Valve - control, transmission 79

Printed in U.S.A. 691478 Issued August, 1969

MidWestTech | Case 1150 Crawler Parts Catalog | Publication D950 Order the manual at mid-west-tech.com >