DG534

Operation & Maintenance Manual

170D

DUMP TRUCK

SERIAL NUMBERS

AFE36-A and up
AFE37-E thru AFE37-X
w/ DDC/CUM 776

KOMATSU®

MidWestTech | Komatsu 170D Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >




FIG. 16. 170D AIR SCHEMATIC

MidWestTech | Komatsu 170D Dump Truck Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >