Haulpak

830E



MidWestTech | Komatsu 830E Haulpak Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

SECTION E

REAR WHEEL & BRAKE GROUP

REAR DISC AND PARKING BRAKE INSTL 74
REAR DISC AND PARKING BRAKE INSTL 76
REAR DISC BRAKE ASSM 78
PARKING BRAKE ASSM 80
REAR BRAKE PIPING 82
DRIVE AXLE & MOUNTING 84
DRIVE WHEEL PIPING 86
DRIVE AXLE BLOWER HOSE 88
REAR HATCH COVER INSTL 90
REAR WHEEL & MOUNTING 92
REAR SUSPENSION & MOUNTING 94
REAR SUSPENSION ASSM 96

SECTION F

STEERING SYSTEM

STEERING COLUMN & CONTROL VALVE INSTL 98
STEERING COLUMN ASSM 100
STEERING CONTROL UNIT 102
STEERING ARMS & LINKAGE 104
STEERING CYLINDER ASSM 106
STEERING ACCUMULATOR INSTL 108
ACCUMULATOR ASSM 110
STEERING CYLINDER PIPING 112
STEERING SYSTEM PIPING - 1 114
BLEEDDOWN MANIFOLD VALVE ASSM 118
STEERING PUMP HOUSING (FRONT) 120
STEERING PUMP ROTATING GROUP 122
STEERING PUMP HOUSING (REAR) 124
STEERING PUMP SEAL INSTL 126
FLOW AMPLIFIER 128
SHUT-OFF VALVE ASSM 132

SECTION G

CAB GROUP

CAB ASSM 134
CAB ASSM 136
DOOR ASSM - L.H. 140
DOOR ASSM - R.H. 142
CAB DOOR LINKAGE 144
DOOR LINKAGE & SLIDING WINDOW 146
OPERATOR'S SEAT INSTL 148
OPERATOR'S SEAT ASSM 150
OPERATOR'S SEAT ASSM 152
OPERATOR'S SEAT ASSM 154
DRIVER'S SEAT ASSM 156

MidWestTech | Komatsu 830E Haulpak Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

SECTION G . . .continued

DRIVER'S SEAT ASSM 158
DRIVER'S SEAT ASSM 160
PASSENGER SEAT INSTL 162
INSTRUMENT PANEL 164
SHIFT CONSOLE INSTL 168
HEATER PIPING & INSTL 170
HEATER CONTROLS 172
HEATER 174
WINDSHIELD WIPER INSTL 176
WINDSHIELD WASHER INSTL 178

SECTION H

BODY GROUP

BODY & BODY PIVOT 180
BODY-UP LOCK PIN INSTL 182
BODY POSITION INDICATOR 184
ROCK EJECTORS INSTL 186
MUD FLAP INSTL 188
MUD FLAP INSTL 190
REAR MUD FLAP INSTL 192

SECTION I

ELECTRIC POWER COMPONENTS & WIRING GROUP

ELECTRIC POWER COMPONENTS WIRING 194
BLOWER INLET INSTL 198
BLOWER INLET WIRING 200
BLOWN GRID MODULE 202
BLOWN GRID MODULE 204
BLOWN GRID MODULE 206
CONTROL CABINET WIRING 210
CONTROL CABINET WIRING 212
CONTROL CABINET WIRING 214
CONTROL CABINET WIRING 218
CONTROL CABINET WIRING 220
CONTROL CABINET WIRING 222
CONTROL CABINET WIRING - REAR 224
CONTROL CABINET ASSM 228
STATEX III CONTROL CABINET 232
CONTROL CABINET ASSM 234
CONTROL CABINET ASSM 238
CONTROL CABINET ASSM 244
CONTROL CABINET ASSM 246
CONTROL CABINET ASSM 248
LOAD TEST INSTL 250
MOTOR SHUNT INSTL 252
RCP/ACC INTERFACE BOX ASSM 254
TERMINAL BLOCK PANEL ASSM 256
CABINET PRESSURE CONTROL 258
PRESSURE REGULATOR VY7272 260

MidWestTech | Komatsu 830E Haulpak Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >