EEBM000804

SHOP MANUAL

KOMATSU®

PC340, PC340LC-6k
PC340NLC-6k

MACHINE MODEL	SERIAL NUMBER
PC340-6k	**K30001 and up**
PC340LC -6k	**K30001 and up**
PC340NLC-6k	**K30001 and up**

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.

- PC340-6K mount the SA6D114E-1 engine.
  For details of the engine, see the Engine Shop Manual.

MidWestTech | Komatsu PC340, PC340LC-6k, PC340NLC-6k Hydraulic Excavator Service Manual | Publication EEBM000804
Order the manual at mid-west-tech.com >

WEIGHT TABLE


Unit: kg

Machine model	PC340-6K	PC340LC-6K	PC340NLC-6K
Serial Number	30001 and up	30001 and up	30001 and up
Engine assembly	1,000	1,000	1,000
• Engine	675	675	675
• Damper	14.7	14.7	14.7
• Hydraulic pump	200	200	200
Radiator, oil cooler assembly	165	165	165
Hydraulic tank, filter assembly (excl. hydraulic oil)	228	228	228
Fuel tank (excl. fuel)	218	218	218
Revolving frame	2,630	2,630	2,630
Operator's cab	287	287	287
Operator's seat	29	29	29
Counterweight	6,320	6,320	6,320
Swing machinery	380	380	380
Control valve (standard)	267	267	267
Swing motor	81	81	81
Travel motor	173 x 2	173 x 2	173 x 2
Center swivel joint	38	38	38
Track frame assembly	7,970	8,560	8,326
• Track frame	4,695	5,182	5,013
• Swing circle	487	487	487
• Idler	166	166	166
• Idler cushion	257 x 2	257 x 2	257 x 2
• Carrier roller	31 x 4	31 x 4	31 x 4
• Track roller	52 x 14	52 x 16	52 x 16
• Final drive (incl. travel motor)	595 x 2	595 x 2	595 x 2

MidWestTech | Komatsu PC340, PC340LC-6k, PC340NLC-6k Hydraulic Excavator Ser... Order the manual at mid-west-tech.com >

CONTROL VALVE

10-spool valve (STD + service valve x 3)



MidWestTech | Komatsu PC340, PC340LC-6k, PC340NLC-6k Hydraulic Excavator Service Manual | Publication EEBM000804

Order the manual at mid-west-tech.com >