EX220-5 EX220LC-5 EX230LC-5 EX230H-5 EX230LCH-5 EQUIPMENT COMPONENTS PARTS

HITACHI

PARTS CATALOG

EX220-5 EX220LC-5 EX230LC-5 EX230H-5 EX230LCH-5 EQUIPMENT COMPONENTS PARTS

PART No. EP15S-E1-4

SERIAL NO. 001001-

PART No. EP15S-E1-4

MidWestTech | Hitachi EX220-5, EX220LC-5, EX230LC-5, EX230H-5, EX230LCH-5 Excavat... Order the manual at mid-west-tech.com >

部品番号 PART NO.	コード CODE	部品名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
ポンプ			PUMP		
9151945	9151945	ポンプ装置	PUMP DEVICE		001
++++++++	9151946	・ポンプ;ユニット	-PUMP;UNIT		003
9151947	9151947	・・レギュレータ	--REGULATOR		005
4276918	04509008	・ポンプ;ギヤ	-PUMP;GEAR		007
モータ；オイル			MOTOR；OIL		
4330233	0677200A	モータ;オイル（旋回）	MOTOR;OIL (SWING)		009
9146471	9146471	モータ;オイル（走行）	MOTOR;OIL (TRAVEL)		011
9145186	9145186	・バルブ;ブレーキ	-VALVE;BRAKE		013
9134147	9134147A	・・バルブ;リリーフ	--VALVE;RELIEF		015
9130524	9130524	・ピストン;サーボ	-PISTON;SERVO		017
バルブ			VALVE		
4367133	--------	バルブ;コントロール	VALVE;CONTROL		---
++++++++	06778008	・バルブ;コントロール（1/5）	-VALVE;CONTROL (1/5)		019
++++++++	0677900A	・バルブ;コントロール（2/5）	-VALVE;CONTROL (2/5)		021
++++++++	06780008	・バルブ;コントロール（3/5）	-VALVE;CONTROL (3/5)		023
++++++++	0678100A	・バルブ;コントロール（4/5）	-VALVE;CONTROL (4/5)		025
++++++++	0678200A	・バルブ;コントロール（5/5）	-VALVE;CONTROL (5/5)		027
9156581	9156581A	バルブ;パイロット（フロント，旋回）	VALVE;PILOT (FRONT & SWING)		029
9151777	9151777	バルブ;パイロット（走行）	VALVE;PILOT (TRAVEL)		031
9137384	9137384	バルブ;パイロット	VALVE;PILOT		033
4367132	0672400A	バルブ;フロウコントロール	VALVE;FC		035
4351142	0670500	バルブ;リリーフ	VALVE;RELIEF		037
9075046	90750468	バルブ;スローリターン	VALVE;SLOW-RETURN		039
4391954	0452600	バルブ;スローリターン	VALVE;SLOW-RETURN		041
4334827	0668300	バルブ;ロック	VALVE;LOCK		043
4311303	0644400	バルブ;ホールディング	VALVE;HOLDING		045
シリンダ			CYLINDER		
9147231	9147231	シリンダ;ブーム（右）[STD][AUS]	CYL.;BOOM (R) [STD][AUS]	001001-098/08	047
9162439	9162439	シリンダ;ブーム（右）[STD][AUS]	CYL.;BOOM (R) [STD][AUS]	098/09-	049
9101315	91013158	シリンダ;ブーム（右）[USA]	CYL.;BOOM (R) [USA]	001001-098/08	051
9177630	9177630	シリンダ;ブーム（右）[USA]	CYL.;BOOM (R) [USA]	098/09-	053

MidWestTech | Hitachi EX220-5, EX220LC-5, EX230LC-5, EX230H-5, EX230LCH-5 Excavat... Order the manual at mid-west-tech.com >

部品番号 PART NO.	コード CODE	部 品 名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
9147232	9147232	シリンダ;ブーム (左) [STD][AUS]	CYL.;BOOM (L) [STD][AUS]	001001-098/08	055
9162440	9162440	シリンダ;ブーム (左) [STD][AUS]	CYL.;BOOM (L) [STD][AUS]	D98/09-	057
9101316	91013168	シリンダ;ブーム (左) [USA]	CYL.;BOOM (L) [USA]	001001-098/08	059
9177631	9177631	シリンダ;ブーム (左) [USA]	CYL.;BOOM (L) [USA]	D98/09-	061
9147233	9147233	シリンダ;アーム [STD][AUS]	CYL.;ARM [STD][AUS]	001001-098/08	063
9162441	9162441	シリンダ;アーム [STD][AUS]	CYL.;ARM [STD][AUS]	D98/09-	065
9101317	91013178	シリンダ;アーム [USA]	CYL.;ARM [USA]	001001-098/08	067
9177632	9177632	シリンダ;アーム [USA]	CYL.;ARM [USA]	D98/09-	069
4380500	0451300	シリンダ;アーム (スーパーロング)	CYL.;ARM (RIVER MAINTENANCE)		071
9147234	9147234	シリンダ;バケット [STD][AUS]	CYL;BUCKET [STD][AUS]		073
9101318	91013188	シリンダ;バケット [USA]	CYL;BUCKET [USA]		075
4371061	0671500A	シリンダ;バケット (スーパーロング)	CYL.;BUCKET (RIVER MAINTENANCE)		077

索　引　　PARTS INDEX　　079

MidWestTech | Hitachi EX220-5, EX220LC-5, EX230LC-5, EX230H-5, EX230LCH-5 Excavat... Order the manual at mid-west-tech.com >