W18 Loader
Includes Revision 1

Parts Catalog

Bur F1169

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accelerator and Linkage 97
Air Cleaner. 91,93
Alternator 45-51B
  Mounting and Adjusting Strap . . . 43-43B
Axle Assemblies
  Axle Brakes 161
  Axle Housing 157,159,167,169
  Differential 145-155,163,165
  Planetary 157,159,167,169
Axle Mounting 159,169

B

Back-Up Alarm 137
Battery 67,73,75,81
  Cables 67,73,75,81
Beacon, rotating 265,267
Belts
  Alternator 41
  Compressor 41
  Seat. 245
Block, engine cylinder. 21,21B
Block Heater. 21,21B
Brake Assemblies and Circuits
  Air Compressor and Related Parts. 179-181D
  Air Pressure Protection Valve. 201
  Alcohol Evaporator 203
  Axle Brake 161
  Brake Valve 195
  Emergency Brake To Safety Chamber .173
  Governor, air compressor. 183
  Master Cylinder. 185,197
  Master Cylinder To Wheel Cylinders .187
  Parking Brake, transmission 119,173,175
  Treadle Assembly 195
  Treadle To Master Cylinder and Reservoir 185
  Treadle To Hydraulic Tank and Horn 189-193,195
Buckets
  Standard 271
  Teeth 271,273
  4-in-1 Bucket 273

C

Cab, operators 247-259D
Camshaft, engine 19
Canopy. 255
Clutch, transmission 109-117
Cold Starting System (Ether injection) 83-87
Compartment, operators 243,245
Compressor, air 179-181D
Connecting Rods, engine 25
Control Levers
  Clutch Cutout 185
  Loader Height and Leveling . . . 311,311B
  Loader Lift and Dump. 307,309
  Pedal, accelerator 97
  Pedal, brake (Treadle) 195
  Transmission 133,135
Crankshaft, engine 23
Cushions, seat 243
Cylinders, brake
  Master 185,197
  Slave 161
Cylinders, hydraulic
  Bucket Clam 301
  Bucket Dump 299,299B
  Loader Lift. 295,297
  Steering 217,219

D

Decals
  Bucket (4-in-1) 273
  Engine Data. 17
  Kit 303,303B
Defroster, cab. 247,247B
Defroster, fan 249
Dipsticks
  Engine Oil 21,21B
  Hydraulic Tank 231,233
  Transmission Oil. 131
Driveshaft
  Center Bearing 139
  Front, axle end 139
  Front, transmission end 141
  Rear 141

Printed in U.S.A. 750560 A Issued May, 1975

MidWestTech | Case W18 Loader Parts Catalog | Publication F1169 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

E

Electrical Systems
- Bucket Height 311,311B
- Cab Wiring 247-253B
- Cold Starting Systems 83-87
- Harnesses 59-81
- Instrument Panels 59,61

Emblem, slow moving vehicle 303D
Emergency Steering 213B
Engine Mounts 41
Engine Subassemblies
- Alternator 45-51B
- Camshaft 19
- Crankshaft and Flywheel 23
- Cylinder Block 21,21B
- Cylinder Head and Cover 17
- Flywheel Housing 23B
- Fuel Filter System 33
- Fuel Injection System 31
- Gasket Kits 29
- Injection Nozzles 39
- Injection Pump 37,37B
- Injection Pump Drive 35
- Oil Filter and Heat Exchanger . . 13-15B
- Oil Pump and Pan 27
- Manifolds, intake and exhaust 11
- Piston and Connecting Rods 25
- Starter 53-55D
- Timing Gear Cover 35
- Valve Mechanism 19
- Water Manifold and Thermostat 9
- Water Pump 9B

Ether Injection Starting Aid 83-87
Evaporator, alcohol 203
Exhaust, pipe and mufflers 95

F

Fan, radiator 41
- Mounting 9B,41

Fenders 239,241
Filters
- Air Cleaner 91,93
- Air, governor 183
- Engine Oil 13-15B
- Fuel 33
- Hydraulic Tank 231,233
- Transmission Oil 127,129

Flasher Lights 253,253B,263,263B
Flywheel, engine 23,23B
Frames
- Articulated, front 241
- Articulated, rear 221
- Loader Lift 269

Fuel Injector 39
Fuel Lines 31,33,227,229
Fuel Tank 227,229

G

Gaskets, engine (Service Kits) 29
Gauges 59-81
Gears
- Engine (See Engine Subassemblies)
- Transmission (See Transmission Subassemblies)

Governor, air compressor 183
Grille 235
Guards
- Engine Side Panels 239
- Roll-Over Protection Structure 255
- Under Carriage 225

H

Head, engine 17
Heater
- Block, engine 21,21B
- Cab 247-247B,251

Hood 235-239
Horn, air 189-193
Hose, radiator 41
Hoses (See Fuel Lines, Brake Assemblies and Hydraulic Circuits)
Hydraulic Circuits
- Emergency Steering Hydraulics . . .213B
- Loader Bucket (Clam) 273,293
- Loader Bucket (Tilt) 291
- Loader Lift 289
- Primary 275,277
- Pump To Loader Valve 279-287
- Steering, pump to cylinders 215
- Steering, pump to reservoir 209-213
- Transmission 127,129

Hydraulic Tank Assemblies 231-233

I

Instrument Panel 59-65B
Instruments (See Gauges)

L

Lights 89,253,253B,263,263B
Loader Arm, mechanical parts 269
Lockup Parts 237,237B

M

Manifold
- Exhaust 11
- Intake 11
- Water 9

Mounts
- Axle 159,169
- Engine 41
- Radiator 41
- Transmission 131

Mufflers 95

N

Nozzle, fuel injector 39

MidWestTech | Case W18 Loader Parts Catalog | Publication F1169 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

O

Oil Cooler, engine 13-15B
Oil Pan, engine 27

P

Parking Brake 119,173,175
Pedal, accelerator 97
Pedal, brake (Treadle) 195
Piston Assemblies, engine 25
Pulleys
  Air Compressor 177,177B
  Alternator 43,43B
  Alternator and Fan Drive 23
  Fan Mounting 9,41
  Pump Drive, water 9B
Pumps
  Engine, oil 27
  Fuel Injection 37,37B
  Fuel, electric 231
  Hydraulic Oil 305
  Steering, manual 207
  Torque Converter 99,101
  Transmission Charging 121
  Water, engine 9B

R

Radiator, cooling 41
Regulator, voltage 45B,51,69,77
Reservoirs
  Air 177,177B
  Fuel 227,229
  Hydraulic Oil 231,233
Rims, wheel 171
Rings, engine piston 25
Rocker Arms, engine 19
Rods, connecting 25
Rods, push 19
Roll-Over Protection Structure 255

S

Safety Chamber 173,199
Seat Assemblies 243,245
Shafts
  Axle (See Axle Assemblies)
  Engine (See Engine Subassemblies)
  Transmission (See Transmission Subassemblies)
Shroud, radiator 235
Side Panels, engine 235
Sleeve, piston 25
Solenoid, starter 57
Starter, engine 53-55D
Starting Aid (Ether Injection) 83-87
Steps 241

T

Thermostat, water temperature 9
Timing Gear and Cover, engine 35
Tire Inflation Kit 177,177B
Tools 303D
Torque Converter 99,101
Transmission Mounts 131
Transmission Subassemblies
  Axle Output Shaft and Parking Brakes 119
  Charging Pump 121
  Control Valve 121,123
  Converter Housing, Gears and Transmission Housing 103,105
  Forward Clutch and Planetary . . 109,111
  Front Cover, Input Shaft and Torque Converter 99,101
  High Range Clutch and Transfer Gear 117
  Hydraulic System 127,129
  Oil Filter 127,129
  Overhaul Kit 125
  Reverse Clutch and Planetary . . 113,115
  Turbine Driven Gears and Freewheel Unit 107
Trunnion, rear frame 221
Turn Signals 253,253B,263,263B

V

Valve Mechanism, engine 19
Valve Parts, hydraulic control 321-239
Valves
  Air Shutoff 189,193
  Air Pressure Protection . . . 189,193,201
  Air Pressure Regulator 189,193,199
  Brake Control 195
  Breather, axle 159,169
  Breather, transmission 105
  Clutch Cutout 185
  Emergency Brake 173,175,199
  Drain, air reservoir 185
  Drain, engine oil cooler 15,15B
  Drain, radiator 41
  Flow Control, steering 209,211,213,213B
  Horn 189,201
  Loader Control, 2 spool 307
  Loader Control, 3 spool 309
  Tire, valve stem 171
  Torque Converter 103
  Transmission Control 121
  Check, double 199

W

Wheel, steering 205
Wheel, tire 171
Wiper, windshield 257,259B
Wire (See Electrical Circuits)

Printed in U.S.A. 750562 A Issued May, 1975

MidWestTech | Case W18 Loader Parts Catalog | Publication F1169 Order the manual at mid-west-tech.com >