33 Loader

Parts Catalog

F966

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.


Indented Description

Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.	PART NO.	DESCRIPTION	REQ'D.
A	55159	CYLINDER ASSY. - rear steering	1
28 A	56208	SOCKET ASSY. - rear cylinder	1
29 A	55956	PLUG - adjusting, socket assy.	1
30 A	55957	SEAT - socket ball	2
31 A	56210	SPRING - socket	1
32 A	56209	SEAT - socket spring	1
33 G	45175	CLAMP ASSY. - socket assy.	1
34	16- 836	HHCS - 1/2" - 20 NF x 2-1/4"	1
35	132- 104	PIN - cotter, 3/16" dia. x 3"	1

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of the loader are determined by sitting in the operator's seat facing the loader. "Right Hand" and "Left Hand" sides of the backhoe are determined by sitting in the operator's seat facing the backhoe.



Printed in U.S.A.

Issued September, 1973

MidWestTech | Case 33 Loader Parts Catalog | Publication F966 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

BACKHOE

B

Boom - backhoe 75,79
Buckets - backhoe 99-105

C

Controls - automatic dig 153-155
Couplings - hydraulic 157,159
Cylinders - hydraulic, backhoe 283-335
Cylinders - backhoe boom 305-313
Cylinders - backhoe bucket 321-329
Cylinders - backhoe dipper 315-319
Cylinders - backhoe dipper extension . . . 331-335
Cylinders - backhoe stabilizer 283-289
Cylinders - backhoe swing 291-303

D

Decals - backhoe. 239,241
Dipper - backhoe, standard 75,79
Dipper - extendable, hydraulic 87-93
Dipper - extendable, mechanical 83-85

E

Emblems - slow moving vehicle 243

F

Filters - hydraulic oil 161
Frost Point - backhoe 77,81

H

Hydraulics - backhoe . . . 83,85,89,93,123-155,251-257
Hydraulics - boom lockout 151
Hydraulics - boom, crowd and bucket . . . 139-149
Hydraulics - extendable dipper 83,85,89,93
Hydraulics - primary, backhoe (For 580 CK) 123-129
Hydraulics - primary, backhoe (For 530 CK) 251-257
Hydraulics - swing and stabilizer (33 Backhoe) 131-133
Hydraulics - swing, stabilizer and locking (33S Backhoe) 135,137
Hydraulics - Hydra-Guide controls 153,155

K

Kits - cylinder packing, backhoe 351-353

L

Levers - control, individual 107,117,119
Levers - control, swing 113
Levers - control, twin 113
Lift Hooks - tractor. 165
Light - dipper 95,97
Light - flood and tail 121
Lock Up Parts - tractor 163

M

Mounting Frame - 33 Backhoe 67,69
Mounting Frame - 33S Backhoe 71,73
Mounting Parts - 33 Backhoe, for 580CK 59-63
Mounting Parts - 33S Backhoe, for 580CK 65
Mounting Parts - 32 loader, special 247-249

P

Pedals - foot swing 111
Pump - hydraulic 205-211

R

Roll Bar - tractor 167

S

Seat - swing down 121
Seat Belts - tractor 167
Stabilizer - 33 Backhoe 67
Stabilizer - 33S Backhoe 71
Swing Tower - backhoe 75,79

T

Tools - service 245

V

Valve - Hydra-Guide control 213
Valves - backhoe control 227-237
Valve Section - boom 237
Valve Section - bucket and crowd 233
Valve Section - inlet 229
Valve Section - outlet 229
Valve Section - stabilizer 231
Valve Section - swing. 235
Valve - boom lockout 209
Valve - diversion 207
Valve - locking, 33S Backhoe 205

LOADER

B

Blade - loader 31
Buckets - loader, clam type 25-29
Buckets - loader. 19-23

C

Counterweights - loader 55,57
Cylinders - hydraulic, loader 259-281
Cylinders - loader clam 275,277
Cylinders - loader grapple 279,281
Cylinders - loader Hydra-Leveling 265-269
Cylinders - loader lift 259-263
Cylinders - loader bucket 271,273

D

Decals 239,241

F

Forks - pallet and logging 31
Frame - loader lift 11,13

G

Grapple - logging 33

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

LOADER

H

Hydraulics - loader 35-45
Hydraulics - loader lift, bucket and Hydra-Leveling 41,43
Hydraulics - loader, optional 45
Hydraulics - loader, primary 35-39

K

Kits - cylinder packing, loader 345-349

L

Levers - loader control 47-53

P

Pump - hydraulic 205-209

R

Return To Dig - loader 15
Return To Dig And Anti-Rollback - loader 17

S

Subframe - loader 7,9

T

Tools - service 245

V

Valves - loader control, 2 spool 215,219-225
Valves - loader control, 3 spool 217-225
Spools - lift 221-223
Spools - bucket and clam 219
Valve - check 225
Valve - main relief 219
Valve - secondary relief 225

3 POINT HITCH

C

Control Levers - 3 Point Hitch 177,179
Cylinders - hydraulic, 3 Point Hitch 337-343
Cylinder - 3 Point Hitch lift 337
Cylinder - 3 Point Hitch pitch 341-343
Cylinder - 3 Point Hitch tilt 339

H

Hydraulics - 3 Point Hitch 171,181,183

K

Kits - cylinder packing, 3 Point Hitch 347

M

Mounting Frame - 3 Point Hitch 175
Mounting Parts - 3 Point Hitch 173

V

Valve - control, 3 Point Hitch 185-195

TRANS—PAC TRAILER

A

Axle - Trans-Pac Trailer 197

B

Brakes - Trans-Pac Trailer 199
Brake Control - Trans-Pac Trailer 203

E

Electrical System - Trans-Pac Trailer 201

H

Hitch - Trans-Pac Trailer 197

L

Lights - Trans-Pac Trailer 203

W

Wheel - Trans-Pac Trailer 199

Printed in U.S.A.

Issued September, 1973

MidWestTech | Case 33 Loader Parts Catalog | Publication F966 Order the manual at mid-west-tech.com >