
ILLUSTRATED PARTS LIST

KUBOTA

G1800

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66101-51116	ASSY FRAME	1	<=12248			0	0
010	66101-51220	FRAME	1	>=12249	←		23	50.6
010	66101-85120	ASSY FRAME	1	>=12695	←		45	99
010	66101-85122	ASSY FRAME	1	>=16460	←		52	114.4
015	67111-44250	NIPPLE GREASE	1	>=12695			0.005	0.011
020	01123-51235	BOLT	8				0.041	0.0902
030	66101-51120	SUPPORT ENGINE RH	1				0.78	1.716
040	66101-51130	SUPPORT ENGINE LH	1				0.68	1.496
050	01133-51022	BOLT	8				0.025	0.055
060	66021-52310	CUSHION RUBBER	4				0.106	0.2332
070	02114-50080	NUT	8				0.005	0.011
080	04512-60080	WASHER SPRING	8				0.002	0.0044
090	04013-50080	WASHER PLAIN	8				0	0
100	66101-51143	SUPPORT SEAT	1	>=11581			0	0
100	66101-51146	SUPPORT SEAT	1	>=11582	←		2.7	5.94
110	01135-61025	BOLT	1				0.04	0.088
120	66021-51210	HITCH	1				0.7	1.54
130	01123-51025	BOLT	4				0.02	0.044
140	67211-51120	PLUG BLIND	10				0.001	0.0022
150	66101-51170	SUPPORT STEP	1				0.4	0.88
160	01123-50820	BOLT	2				0.011	0.0242
170	01133-51035	BOLT	2				0.03	0.066
180	76507-51200	SUPPORTER	2	>=10804		RC54 RC60	0.38	0.836
190	01173-51025	BOLT	4	>=10804		RC54 RC60	0.021	0.0462
200	02118-50100	NUT	4	>=10804		RC54 RC60	0.005	0.011
210	04512-60100	WASHER SPRING	4	>=10804		RC54 RC60	0.002	0.0044
220	04013-50100	WASHER PLAIN	1				0	0
230	66101-59120	STAY	2	>=12366			0.33	0.726
240	01123-60816	BOLT	4	>=12366			0.01	0.022
240	01125-50822	BOLT	4	>=16460			0.015	0.033
250	66101-88710	MANUAL ASSEMBLY	1			OPTION	0.001	0.0022
260	66101-88700	KIT STAY SPRING	1			OPTION	0.76	1.672
270	66101-83650	ASSY SUPPORT SHAFT	1			OPTION	0.27	0.594
280	01123-60816	BOLT	2			OPTION	0.01	0.022
290	01023-50614	BOLT	2			OPTION	0.005	0.011
300	67111-44250	NIPPLE GREASE	1			OPTION	0.005	0.011

MidWestTech | Kubota G1800 Tractor Parts Manual | Publication G1800 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66101-36313	ASSY VALVE CONTROL	1	<=13881			2.76	6.072
010	66101-36314	ASSY VALVE CONTROL	1	>=13882	≠		2.7	5.94
020	05411-00620	PIN SPRING	1				0.002	0.0044
030	66591-36330	SEAT VALVE	1				0.008	0.0176
040	04811-15120	RING	1				0.001	0.0022
050	66611-36222	RETAINER SPRING	1				0.008	0.0176
060	07715-03211	BALL	1				0.003	0.0066
070	66101-36350	SPRING	1				0.03	0.066
080	66591-36360	SCREW ADJUSTING	1				0.012	0.0264
090	04012-50060	WASHER PLAIN	1				0.001	0.0022
100	66591-36370	COLLAR	1				0.016	0.0352
110	66611-36330	SHIM ADJUSTING	1				0.001	0.0022
120	66101-36360	COVER RELIEF	1				0.06	0.132
130	66101-36370	SPRING SPOOL RETURN	1				0.01	0.022
140	66905-36390	GASKET	1				0.005	0.011
160	01202-50622	BOLT	4				0.007	0.0154
170	66591-36430	COVER VALVE	1				0.18	0.396
180	66101-36390	LEVER CONTROL	1				0.26	0.572
190	04811-00100	RING	1				0.001	0.0022
200	66591-36450	ARM VALVE GUIDE	1				0.05	0.11
210	66591-36480	BOLT	1				0.004	0.0088
220	04111-50060	WASHER	1				0.001	0.0022
230	07715-00803	BALL	1				0.004	0.0088
240	62061-18270	SPRING STOPPER	1				0.003	0.0066
250	66591-36460	BOLT	1				0.054	0.1188
260	04714-00300	GASKET	1				0.002	0.0044
270	66905-36470	GASKET	1				0.002	0.0044
280	01053-50650	BOLT	2				0.011	0.0242
290	04512-60060	WASHER SPRING	4				0.001	0.0022
300	01053-50665	BOLT	2				0.015	0.033

MidWestTech | Kubota G1800 Tractor Parts Manual | Publication G1800 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66103-45930	SEAT	1	<=10901			0	0
010	66103-45935	SEAT	1	>=10902	←		0	0
010	K3311-45930	ASSY SEAT	1	>=21209	←		6.8	14.96
015	K3311-45940	ASSY SWITCH SEAT	1	>=21209			0.17	0.374
016	01754-50612	BOLT FRANGE	4	>=21209			0.005	0.011
040	66103-45940	BRACKET SEAT RH	1				0.088	0.1936
050	66103-45950	BRACKET SEAT LH	1				0.16	0.352
060	01123-50820	BOLT	4				0.011	0.0242
070	13824-67580	CLAMP CORD	1				0.006	0.0132
080	01123-60816	BOLT	4				0.01	0.022
090	66101-45910	ASSY ADJUSTER SEAT	1				1.5	3.3
100	66021-45980	CUSHION SEAT	2				0.012	0.0264
110	38240-18470	PIN SEAT	1				0.085	0.187
120	05515-61000	PIN SNAP	1				0.003	0.0066
130	67061-45970	SPRING SEAT	2				0.13	0.286
140	01123-50820	BOLT	2				0.011	0.0242
150	04015-60080	WASHER PLAIN	2				0.01	0.022
160	66301-52820	CAP SPRING	1				0.04	0.088

MidWestTech | Kubota G1800 Tractor Parts Manual | Publication G1800 Order the manual at mid-west-tech.com >