TOYOTA

INDUSTRIAL EQUIPMENT

PARTS CATALOG

FOR MODELS

5FBCU15

30-5FBCU15

G817-1

TOYOTA MOTOR CORPORATION

TOYODA AUTOMATIC LOOM WORKS, LTD.

MidWestTech | Toyota 5FBCU15, 30-5FBCU15 Forklift Parts Catalog | Publication G817-1 Order the manual at mid-west-tech.com >

FIG.1401
DRIVE MOTOR

1401


MAIN 97/05

PART NAME CODE	PART NAME	QTY
1401-01	MOTOR ASSY, DRIVE	1
1401-01A	BEARING, DRIVE MOTOR, NO.1	1
1401-01B	BEARING, DRIVE MOTOR, NO.2	1
1401-10	YOKE ASSY	1
1401-11	HOLDER ASSY, BRUSH	1
1401-12	ARMATURE ASSY, DRIVE	1
1401-19	FAN	1
1401-40	BRUSH, DRIVE MOTOR	2- 4
1401-41	BRACKET, NO.1	1
1401-41A	SEAL, OIL (FOR BRACKET)	1
1401-42	BRACKET, NO.2	1
1401-43	COVER, MOTOR	1
1401-44	COVER, BRUSH	1
1401-45	BRACKET, DRIVE MOTOR MOUNTING, NO.1	1
1401-47	SPRING, DRIVE MOTOR BRUSH	8
1401-50	RUBBER, CUSHION (FOR MOTOR MOUNTING)	2
1401-51	COVER, BRUSH NO.2	1
1401-AA	COLLAR	3
1401-AL	WASHER, PLATE	4
1401-AQ	PLATE, CUSHION RUBBER	1
1401-AP	WASHER, SPRING	4
1401-AT	BOLT	4
1401-AU	BOLT	6
1401-BH	BOLT	3
1401-BJ	BOLT	4
1401-CD	PLUG	1
1401-CG	SCREW	2
1401-CM	SCREW	8
1401-DB	WASHER, SPRING	8
1401-DG	WASHER, SPRING	3
1401-DU	TERMINAL SET	4
1401-DV	SCREW	4
1401-DW	SCREW, W/WASHER	8
1401-DX	HARNESS	1
1401-EZ	BAR, CROSS	1
1401-EA	BAR, CROSS	1


G817-003E

Order the manual at mid-west-tech.com >

FIG. 1402
PUMP DRIVE MOTOR



1402-102



1402-100A

G817-001


Order the manual at mid-west-tech.com >

FIG. 1402
PUMP DRIVE MOTOR

1402

MAIN 97/05

STR (GRUSH WARNING)



1402-101A

PART NAME CODE	PART NAME	QTY
1402-01	MOTOR ASSY, PUMP	1
1402-01A	BEARING, PUMP MOTOR, NO.1	1
1402-01B	BEARING, PUMP MOTOR, NO.2	1
1402-10	YOKE ASSY, PUMP MOTOR	1
1402-11	HOLDER ASSY, PUMP MOTOR	1
1402-12	ARMATURE ASSY, PUMP MOTOR	1
1402-18	MOTOR ASSY, FAN	1
1402-19	FAN	1
1402-35	INSULATOR SUB-ASSY, MOTOR MOUNTING	2
1402-40	BRUSH, PUMP MOTOR	2- 4
1402-41	BRACKET, NO.1	1
1402-42	BRACKET, NO.2	1
1402-43	COVER, MOTOR	1
1402-44	COVER, BRUSH	1
1402-47	SPRING, PUMP MOTOR BRUSH	8
1402-48	PLATE, PUMP MOTOR SET	1
1402-AC	WASHER, PLATE	4
1402-AD	WASHER, SPRING	4
1402-AQ	BOLT	1
1402-AS	NUT	4
1402-AT	BOLT	4
1402-AU	BOLT	4
1402-AV	COVER	1
1402-AX	CLAMP	1
1402-BA	CLAMP	1
1402-CJ	SCREW	4
1402-CP	BOLT	3
1402-CT	WASHER, SPRING	4
1402-CY	PLUG	1
1402-DE	BRACKET, FAN	1
1402-DF	WASHER, SPRING	4
1402-DK	TERMINAL SET	2
1402-DL	SCREW	2
1402-DM	RING	1
1402-DN	SCREW	4
1402-DQ	SCREW, W/WASHER	8
1402-DP	BRACKET, FOOT	1
1402-DS	LEAD SET	1
1402-DS	SCREW	4

G817-002E

Order the manual at mid-west-tech.com >