580 CK Tractor
Prior S/N 8685801

Parts Catalog

G971

CASE

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.		PART NO.	DESCRIPTION	REQ'D
	A	55159	CYLINDER ASSY. - rear steering	1
28	A	56208	SOCKET ASSY. rear cylinder	1
29		NSS	PLUG - adjusting, socket assy	1
30		NSS	SEAT - socket ball	2
31		NSS	SPRING - socket	1
32		NSS	SEAT - socket spring	1
33	G	45175	CLAMP ASSY. - socket assy.	1
	16-	836	BOLT - 1/2" x 2-1/4" N.F. hex.	1
34	132-	104	PIN - cotter, 3/16" x 3"	UAR
35	A	55889	STUD - ball, socket & cylinder	2
36	13-	410	BOLT - 1/4" x 5/8" N.C., hex	4
37	92-	4	LOCKWASHER - 1/4" SAE	4

NOTE **NSS** IN PART NO. COLUMN INDICATES THIS PART IS NOT SERVICED SEPARATELY.
UAR IN AMT. REQ'D COLUMN INDICATES THIS PART IS USED AS REQUIRED.

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

ENGINE SECTION
188 DIESEL

Air Intake & Exhaust Section:
- Air Cleaner 35B
- Manifolds 7
- Muffler 7

Cold Weather Starting Aids:
- Battery Heater 79
- Block Heater 79
- Manifold Heater 7

Cooling Section:
- Fan & Belt 5B, 5D
- Radiator & Baffles 5
- Thermostat 5B, 5D
- Water Pump 5B, 5D

Engine Section:
- Camshaft & Bushings 13
- Connecting Rods & Bearings 17, 17B
- Crankshaft & Bearings 15,15B
- Cylinder Block & Bearing Caps 9-9F
- Cylinder Head & Cover 11, 11B
- Cylinder Sleeves 17, 17B
- Flywheel 15, 15B
- Gasket Kits 21-21D
- Pistons & Rings 17, 17B
- Rocker Arms & Shaft 13
- Timing Gears 13,15,15B,29
- Timing Gear Cover 5B, 5D, 29
- Valve Mechanism 13

Fuel Section:
- Filter 31
- Fuel Shut-Off Control 27, 27B
- Injection Lines 27, 27B
- Injection Pump & Drive 29
- Injectors 27B, 31
- Leak-Off Lines 27, 27B
- Tank & Lines 25
- Throttle Linkage (Lower) 23B
- Throttle Linkage (Upper) 23

Lubrication Section:
- Oil Filter 19, 19B
- Oil Pan & Dipstick 19, 19B
- Oil Pump 19, 19B

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

ENGINE SECTION
159 SPARK IGNITION

Air Intake & Exhaust Section:
- Air Cleaner 35B
- Manifolds 35
- Muffler 35

Cold Weather Starting Aids:
- Battery Heater 79
- Block Heater 79

Cooling Section:
- Fan & Belt 33
- Radiator & Baffles 33
- Thermostat 33
- Water Pump 33

Engine Section:
- Camshaft & Bushings 41
- Connecting Rods & Bearings 45
- Crankshaft & Bearings 43, 43B
- Cylinder Block & Bearing Caps 37
- Cylinder Head & Cover 39
- Cylinder Sleeves 45
- Flywheel 43, 43B
- Gasket Kits 49
- Governor & Controls 51
- Pistons & Rings 45
- Rocker Arms & Shaft 41
- Timing Gears 41, 43, 43B
- Timing Gear Cover 51
- Valve Mechanism 41

Fuel Section:
- Carburetor 57, 57B
- Choke 55
- Filter (Strainer) 55
- Tank & Lines 55
- Throttle Linkage (Lower) 53
- Throttle Linkage (Upper) 53B

Lubrication Section:
- Oil Filter 47, 47B
- Oil Pan & Dipstick 47, 47B
- Oil Pump 47, 47B

Order the manual at mid-west-tech.com >