ILLUSTRATED PARTS LIST

KUBOTA

GR2100

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K1253-11010	ASSY HST	1				0	0
020	K1253-14380	SHAFT GEAR	2				0	0
030	K1253-14810	CASE STEERING CLUTCH	2				0	0
040	K1253-14720	COLLAR CLUTCH	2				0	0
050	K1253-14730	SPRING CLUTCH	2				0	0
060	K1253-14890	SPACER	2				0	0
070	04612-00500	CIR CLIP EXTERNAL	2				0.009	0.0198
080	PL501-14270	PLATE CLUTCH SPLINE	2				0.01	0.022
090	52400-15810	DISK POWER SHIFT	18				0.01	0.022
100	K1253-14880	PLATE CLUTCH	16				0	0
110	K1253-14910	PLATE CLUTCH	2				0	0
120	04611-00650	CIR CLIP INTERNAL	2				0.011	0.0242
130	K1253-14750	BOSS SPLINE CLUTCH	2				0	0
140	K1253-14870	SPACER CLUTCH	2				0	0
150	31353-43370	SHIM	2				0.01	0.022
160	K1253-14370	SHAFT GEAR	1				0	0
170	K1253-14400	SHAFT DRIVE	1				0	0
180	K1253-14390	SHAFT GEAR	2				0	0
190	15471-95360	CIR CLIP EXTERNAL	2				0.004	0.0088
200	K1253-14570	COLLAR	2				0	0
210	08511-02630	BUSH	2				0	0
220	09500-25408	SEAL OIL	2				0.01	0.022
230	K1253-14450	HUB REAR WHEEL	2				0.45	0.99
240	6C040-57330	BOLT	8				0.035	0.077
250	02574-50160	NUT LOCK	2				0.03	0.066
260	K1253-14580	WASHER	2				0	0
270	K1253-14820	LEVER S-CLUTCH LH	1				0	0
280	K1253-14840	LEVER S-CLUTCH RH	1				0	0
290	04816-00140	O RING	4				0.002	0.0044
300	K1253-14830	LEVER WIRE	2				0	0
310	02574-50100	NUT LOCK	2				0.007	0.0154
320	K1253-14430	PIPE TRANSMISSION	1				0	0
330	31220-14290	PLUG	5			NOT SHOWN IN FIG.	0.002	0.0044
340	TA040-36650	PLUG	1			NOT SHOWN IN FIG.	0.005	0.011
350	67211-76170	PLUG	1			NOT SHOWN IN FIG.	0.005	0.011

MidWestTech | Kubota GR2100 Tractor Parts Manual | Publication GR2100 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K1253-15210	CASE FRONT DIFF	1				0	0
020	K1253-15220	CASE FRONT DIFF	1				0	0
030	01754-50835	BOLT FLANGE	26				0.019	0.0418
040	02751-50080	NUT FLANGE	26				0.006	0.0132
050	K1253-15250	GAUGE OIL	1			K1261-15250	0	0
060	01774-51010	BOLT FLANGE	2				0.08	0.176
070	04717-01000	WASHER WITH RUBBER	2				0.001	0.0022
080	37410-38530	CAP	2				0.03	0.066
090	K1253-16370	SEAL OIL	2				0	0
100	08101-06907	BEARING BALL	2				0.073	0.1606
110	04611-00470	CIR CLIP INTERNAL	2				0.006	0.0132
120	08101-06906	BEARING BALL	2				0.04	0.088
130	K1253-15480	COVER GEAR CASE	2				0	0
140	04811-11350	O RING	2				0.033	0.0726
150	01754-50830	BOLT FLANGE	12				0.05	0.11
160	K1253-15710	SHAFT GEAR	1				0	0
170	08101-06303	BEARING BALL	1				0.112	0.2464
180	08101-06304	BEARING BALL	1				0.146	0.3212
190	K1253-15720	COLLAR	1				0	0
200	76611-56430	SHIM	1				0.005	0.011
210	K3351-56560	SHIM	1				0.004	0.0088
220	53465-21230	SHIM	1				0.008	0.0176
230	K3351-56570	SHIM	1				0.006	0.0132
240	66611-14670	SHIM	1				0.008	0.0176
250	09180-17329	SEAL OIL	1				0.012	0.0264
260	K1253-15910	GEAR BEVEL	1				0	0
270	K1253-16010	ASSY DIFF.FRONT	1				0	0
280	K1253-16020	CASE DIFF.FRONT	1				0	0
290	K2511-16120	SHAFT DIFF.PINION	1				0.04	0.088
300	04612-00100	CIR CLIP EXTERNAL	1				0.001	0.0022
310	07711-00002	BALL	1				0.001	0.0022
320	K2511-16130	GEAR BEVEL	2				0.022	0.0484
330	K2511-16052	SHIM	2				0.004	0.0088
340	K2511-16062	SHIM	2				0.003	0.0066
350	K2511-16072	SHIM	2				0.004	0.0088
360	K2511-16082	SHIM	2				0.005	0.011
370	K1253-16140	GEAR BEVEL	2				0	0
380	08101-06006	BEARING BALL	2				0.13	0.286
390	K1253-16510	SHIM	1				0	0
400	K1253-16520	SHIM	1				0	0
410	K1253-16530	SHIM	1				0	0
420	K1253-16540	SHIM	1				0	0
430	K1253-16550	SHIM	1				0	0
440	K1253-16220	SHAFT YOKE LH	1				0	0
450	K1253-16210	SHAFT YOKE RH	1				0	0
460	K1253-16230	GEAR BEVEL F	2				0	0
470	K1253-16710	SHIM	2				0	0
480	K1253-16720	SHIM	2				0	0
490	K1253-16730	SHIM	2				0	0
500	K1253-16740	SHIM	2				0	0
510	K1253-16750	SHIM	2				0	0
520	08101-06004	BEARING BALL	2				0.065	0.143
530	K1253-16280	GEAR BEVEL F	2				0	0
540	K1253-16610	SHIM	2				0	0
550	K1253-16620	SHIM	2				0	0
560	K1253-16630	SHIM	2				0	0
570	K1253-16640	SHIM	2				0	0
580	K1253-16650	SHIM	2				0	0
590	08101-06202	BEARING BALL	2				0.044	0.0968

MidWestTech | Kubota GR2100 Tractor Parts Manual | Publication GR2100 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K1253-54110	BONNET	1				0	0
020	K1253-54210	ASSY LAMP HEAD LH	1				0	0
030	K1253-54220	ASST LAMP HEAD RH	1				0	0
040	K1253-54510	SCREW TAPPING	4				0	0
050	04013-60060	WASHER PLAIN	4				0.001	0.0022
060	K1253-54150	BONNET	1				0	0
070	K1253-54160	BONNET	1				0	0
080	K1253-54350	BRACKET	1				0	0
090	K1253-54360	BRACKET	1				0	0
100	01754-50820	BOLT FLANGE	10				0.015	0.033
110	02751-50080	NUT FLANGE	2				0.006	0.0132
110	01754-50825	BOLT FLANGE	2			NOT SHOWN IN FIG.	0.01	0.022
120	K1253-54410	GRILLE BONNET	1				0	0
130	04013-60050	WASHER PLAIN	1				0.001	0.0022
140	K1122-57140	SCREW TAPPING	1				0.002	0.0044
150	K1122-91800	NUT(M)	2				0.004	0.0088
160	01754-50616	BOLT FLANGE	2				0.006	0.0132
170	K1253-54310	BRACKET BONNET LH	1				0	0
180	K1253-54320	BRACKET BONNET RH	1				0	0
190	01754-50825	BOLT FLANGE	2				0.01	0.022
200	04013-60080	WASHER PLAIN	4				0.002	0.0044
210	K5112-72840	NUT LOCK	2				0.005	0.011
220	K1253-21080	COVER FRONT	1				0	0
230	01754-50835	BOLT FLANGE	4				0.019	0.0418

MidWestTech | Kubota GR2100 Tractor Parts Manual | Publication GR2100 Order the manual at mid-west-tech.com >