CHASSIS INTERNATIONAL 786, 886, 986, 1086, 1486, 1586, and Hydro 186 Tractors

Service Manual

GSS14703

CASE IH AGRICULTURE

Order the manual at mid-west-tech.com >

Section 1


CONTROL CENTER, A/C and TRACTOR SPLITS

Contents


	Page
Control Center	1 - 2
Glass Installation	1 - 5
Isomounts	1 - 6
Door Striker Adjustment	1 - 7
Air Conditioning System	1 - 8
Air Conditioning Components	1 - 12
Windshield Wiper Motor	1 - 14
Recirculation Door And Adjustment Rod Removal	1 - 15
Split Between The Engine And Speed Transmission	1 - 19
Rear Split – Control Center On The Rear Frame	1 - 27
Rear Split – Control Center On The Speed Transmission (Includes Splitting The Axle Housings)	1 - 40
Rear Split – Control Center On The Speed Transmission (Without Splitting The Axle Housings)	1 - 51
Tractor Ballast	1 - 58


NOTE: Refer to GSS-1455-1, Basic Air Conditioning and Heating for Operator's Cab and to GSS-1281-K for Clutch Service.

MidWestTech | Case Chassis 786, 886, 986, 1086, 1486, 1586, Hydro 186 Tractor Service... Order the manual at mid-west-tech.com >



MidWestTech | Case Chassis 786, 886, 986, 1086, 1486, 1586, Hydro 186 Tractor Servi... Order the manual at mid-west-tech.com >





NOTES: (a) ⊙ Indicates ports in cover plate.
(b) Port numbers refer to schematic diagram.
(c) Letters refer to parts or fluid channels in other illustrations.

Oil Cooler
Differential lube
Transmission lube
Power steering return
Pump pressure to steering
Clutch lube
Tractor reservoir return
Direct drive clutch or TA clutch circuit

FESM–10503

Order the manual at mid-west-tech.com >