1190
Mower-Conditioner

Service Manual

GSS-1488-2

CASE IH AGRICULTURE

MidWestTech | Case Chassis 384 Tractor Service Manual | Publication GSS-14882

Order the manual at mid-west-tech.com >

Contents

	Page
Safe Work Rules	IV
Standard Torque Data for Nuts and Bolts	VI
Metric Conversion Tables	VIII
Standard Torque Data for Hydraulic Tubes and Fittings	X
Flangette Bearing Installation	XII
SPECIFICATIONS	1
GEAR CASE	
Overhaul	3
Converting Power Take Off Speeds	8
ROLLS	
Bearing Replacement	9
Upper Roll Replacement	12
Lower Roll Replacement	15
HEADER REMOVAL	16
PIVOT SHAFT REPLACEMENT	17
TONGUE AND DRIVE LINE	
Tongue	21
Drive Line	22
REEL AND REDUCTION DRIVE	
Reel	27
Reduction Drive	30
KNIFE DRIVE AND KNIVES	
Knife Drive	31
Knives	38
HYDRAULIC CYLINDERS	
Lift Cylinders	39
Tongue Dialing Cylinder	45
ADJUSTMENTS	
Float Springs	46
Reel	47
Rolls	49
Drives	51
WHEEL SPINDLE REPLACEMENT	55
GAUGE SHOE REPAIR	56

GSS 1488 2 (Rev No 1)

Printed in United States of America

MidWestTech | Case Chassis 384 Tractor Service Manual | Publication GSS-14882 Order the manual at mid-west-tech.com >