430
SCATBACK

Parts Catalog

H5314

CASE CONSTRUCTION

MidWestTech | Case 430 Scatback Wheel Loader Parts Catalog | Publication H5314

Order the manual at mid-west-tech.com >

GENERAL INFORMATION
DAVIS SCATBACK – 430
MODEL Q52

ILLUSTRATIONS:
All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used on the illustrations. These numbers correspond to those used in the "Reference Number" column, and are followed by the part number, description, and number required.

The repair parts for the available engines are found in the applicable engine manual. Engine parts must be obtained from the engine dealer or distributor.

INDENTED DESCRIPTION:
Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In that case, the quantity shown is the number required for the preceding assembly or sub-assembly. An X in the "Number Required" column indicates the quantity to be used in "as required."

REF. NO.	PART NO.	DESCRIPTION	NO. REQ.
7	554675	Boom End Assembly	1
8	508168	Outer Roller Assembly	2
9	071779	Roller	1
10	747139	Bearing	2
11	080838	Square Shaft	2

NOTICE: Parts are included in this manual as a convenience to the owner. All parts must be ordered through a franchised Davis dealer.

TERMS "RIGHT" AND "LEFT" HAND:
"Right Hand" and "Left Hand" sides of the basic machine are determined by sitting on the operator's seat facing the rear of the loader mounting frame.

ABBREVIATIONS:

HHCS	Hex Head Cap Screw
THCS	Truss Head Cap Screw
RHCS	Round Head Cap Screw
FHCS	Flat Head Cap Screw
NF	Unified National Fine Thread
NC	Unified National Coarse Thread
NPT	Dryseal American Standard Pipe Thread
ORB	American Standard Straight Pipe Thread For Hose Couplings
JIC	Joint Industry Conference
SAE	Society Of Automobile Engineers
Fe. Sw.	Female Swivel Fitting
M. Sw.	Male Swivel Fitting
M.	Male Fitting
HT	Heat Treated
LH	Left Hand
RH	Right Hand
STCS	Self Tapping Cap Screw
CPCS	Cup Point Cap Screw
SHSS	Socket Head Set Screw
FHCS	Flat Head Cap Screw
RHMS	Round Head Machine Screw – Slotted

MidWestTech | Case 430 Scatback Wheel Loader Parts Catalog | Publication H5314 Order the manual at mid-west-tech.com >

INDEX

FRONT FRAME, WHEELS, AND TIRES 4

REAR FRAME, FRAME PIVOT, FUEL TANK, OIL RESERVOIR (Up To Spec. # Q52WS31, Q52HZ32) 6

REAR FRAME, FRAME PIVOT, FUEL TANK, OIL RESERVOIR (Spec. # Q52WS31, Q52HZ32 & Up). 7A

FRONT AND REAR AXLES 8

DRIVE LINE, PARKING BRAKE 10

PUMP AND MOTOR CONTROLS 11A

TRANSMISSION ASSEMBLY, PROPULSION MOTOR REDUCTION 12

CONTROL VALVE ASSEMBLY GEAR CASE AND PUMP DRIVES 14

HYDRAULIC SYSTEM - PROPULSION CIRCUIT 16

HYDRAULIC SYSTEM - TANDEM PUMP SUCTION AND STEERING CIRCUITS 18

HYDRAULIC SYSTEM - RAISE, DUMP, AND SELF-LEVELING CIRCUITS 20

HYDRAULIC SYSTEM - OIL COOLER, VALVE CONTROLS 22

STEERING VALVE 24

BUCKET AND LIFT CYLINDER ASSEMBLIES 26

TANDEM PUMP ASSEMBLY, STEERING CYLINDER ASSEMBLY 27A

PROPULSION PUMP ASSEMBLY, PROPULSION MOTOR ASSEMBLY 28

LOADER ARMS, BUCKETS 30

WISCONSIN ENGINE MOUNTING PARTS AND ACCESSORIES 32

HATZ DIESEL ENGINE MOUNTING PARTS AND ACCESSORIES 34

DECALS 36

MANURE FORK, MANURE BUCKET, CRANE, FORKLIFT 37A

MOWER ATTACHMENT 37C

HYDRAULIC SYSTEM - MOWER ATTACHMENT 37E

MOWER PUMP, VALVE, MOTOR 37G


SNOW BLOWER ATTACHMENT 37J

HYDRAULIC SYSTEM - SNOW BLOWER, GEAR CASE, CONTROL VALVE, CHUTE MOTOR 37M

NUMERICAL INDEX 39

MidWestTech | Case 430 Scatback Wheel Loader Parts Catalog | Publication H5314 Order the manual at mid-west-tech.com >

FRONT FRAME, WHEELS & TIRES



MidWestTech | Case 430 Scatback Wheel Loader Parts Catalog | Publication H5314

Order the manual at mid-west-tech.com >