WHEEL LOADER

SERVICE MANUAL

HL770A

HYUNDAI

MidWestTech | Hyundai HL770A Wheel Loader Service Manual | Publication HL770A

Order the manual at mid-west-tech.com >

CONTENTS

SECTION 1 GENERAL

Group 1 Safety Hints ---------- 1-1
Group 2 Specifications ---------- 1-10
Group 3 Operational Checkout Record Sheet ---------- 1-22

SECTION 2 ENGINE

Group 1 Structure and Function ---------- 2-1

SECTION 3 POWER TRAIN SYSTEM

Group 1 Structure and Function ---------- 3-1
Group 2 Operational Checks and Troubleshooting ---------- 3-59
Group 3 Test and Adjustments ---------- 3-71
Group 4 Disassembly and Assembly ---------- 3-74

SECTION 4 BRAKE SYSTEM

Group 1 Structure and Function ---------- 4-1
Group 2 Operational Checks and Troubleshooting ---------- 4-29
Group 3 Tests and Adjustments ---------- 4-37
Group 4 Disassembly and Assembly ---------- 4-39

SECTION 5 STEERING SYSTEM

Group 1 Structure and Function ---------- 5-1
Group 2 Operational Checks and Troubleshooting ---------- 5-18
Group 3 Tests and Adjustments ---------- 5-28
Group 4 Disassembly and Assembly ---------- 5-36

SECTION 6 WORK EQUIPMENT

Group 1 Structure and Function ---------- 6-1
Group 2 Operational Checks and Troubleshooting ---------- 6-35
Group 3 Tests and Adjustments ---------- 6-46
Group 4 Disassembly and Assembly ---------- 6-62

MidWestTech | Hyundai HL770A Wheel Loader Service Manual | Publication HL770A
Order the manual at mid-west-tech.com >

SECTION 7 ELECTRICAL SYSTEM

Group 1 Component Location ---------- 7-1
Group 2 Electrical Circuit ---------- 7-3
Group 3 Monitoring System ---------- 7-23
Group 4 Electrical Component Specification ---------- 7-35
Group 5 Connectors ---------- 7-44
Group 6 Troubleshooting ---------- 7-61

Order the manual at mid-west-tech.com >