VIBRATORY COMPACTOR BCA24

Bobcat®

Parts Manual

Bobcat S/N 494944050 & Above

NOTE: Serial Numbers listed within this manual are Ingersoll-Rand Serial Numbers.



IR Bobcat

Printed in U.S.A.

CPN IR13226709 (12-02)

®Bobcat Company 2002

MidWestTech | Bobcat BCA24 Vibratory Compactor Parts Manual | Publication IR13226709 Order the manual at mid-west-tech.com >

When the Comm. # is not known - Use the Table of Contents:

- Turn to the **TABLE OF CONTENTS** pages in the front of this manual. These pages show the major systems of the machine divided into **FUNCTIONAL GROUPS** (identified by capital letters).
- Find the **Functional Group** that best describes the area of the machine you are interested in. For example: **Engine**
- See the sample **Table of Contents** shown below:

ENGINE

C

Engine Installation C.1.2
Engine Subassembly C.2.2
Propulsion Pump Assembly C.3.2
Vibration/Steering Pump Assembly C.4.2
Fuel and Drain Lines Installation - Effective With S/N 164467 ..... C.5.2
Fuel and Drain Lines Installation - Prior To S/N 164467 ..... C.6.2
Air Cleaner and Muffler Installation C.7.2
Fuel Tank Installation C.8.2

Listed under the **Functional Group** of **Engine** are **SECTIONS** (identified by numbers that describe major repairable components of that group. Find the listing that refers to the Air Cleaner Installation.

- Since the Air Cleaner **Primary Filter Element** is what needs to be replaced, refer to the parts listing for the Air Cleaner. The Air Cleaner used on your machine is found in **Functional Group C.; Section 7**, this makes up the first part of the page number. Turn to that section of the parts manual and find the parts listing on pages **C.7.3** for the **Air Cleaner (IR59225060).**

When the Comm. # is Known - Use the Numerical Index:

- If you already know the **Comm. Number** (part number) for the item required, a **NUMERICAL INDEX** is provided in the back of the manual to assist you. Look up the **Comm. Number** desired and the **Numerical Index** will show the **Functional Group, Section, and Page Number** where the item can be found.

For our Primary Air Cleaner Filter Element Example: The **Comm. Number for the Air Cleaner Primary Element** IR59144170 is found in the **Numerical Index**, it shows that component will be found on page C.7.3.

NOTE: The serial numbers listed within this manual refer to the Ingersoll-Rand Serial Number.

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS
BCA24

TITLE PAGE

Table of Contents ..... A
Abbreviations Used In This Manual ..... D
Recommended Service Parts ..... E

FRAME

A

Frame Assembly A.1.2
Swivel Link Assembly A.2.2
Arch ROPS Installation A.3.2
Canopy ROPS Installation - Optional A.4.2
Hood and Trim Installation A.5.2
Vandal Cover Installation - Optional A.6.2
Sound Kit Installation - Optional A.7.2

For Internal Breakdowns - See Section I.

DRUM

B

Drum Installation B.1.2
Drum Assembly B.2.2
Vibration Drive Assembly B.3.2
Drive Motor Assembly B.4.2

For Internal Breakdowns - See Section I.

ENGINE

C

Engine Installation C.1.2
Engine Subassembly C.2.2
Propulsion Pump Assembly C.3.2
Vibration/Steering Pump Assembly C.4.2
Fuel and Drain Lines Installation - Effective With S/N 164467 ..... C.5.2
Air Cleaner and Muffler Installation C.6.2
Fuel Tank Installation C.7.2

For Internal Breakdowns - See Section I.

MidWestTech | Bobcat BCA24 Vibratory Compactor Parts Manual | Publication IR13226709 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS
BCA24

TITLE PAGE

CONSOLE

D

Operators Platform Installation D.1.2
Seat Assembly D.2.2
Pedestal Assembly - Effective With S/N 162890 ..... D.3.2
Console Assembly D.4.2
Manual Case Installation D.5.2

For Internal Breakdowns - See Section I.

ELECTRICAL

E

Wiring Harness Installation E.1.2
Fuse Plate Assembly E.2.2
Battery and Horn Installation E.3.2
Backup Alarm Installation - Optional E.3.2
Gauge Installation - Optional E.4.2
Pedestal/Gauge Assembly - Optional E.5.2
Pedestal Assembly - Optional E.6.2
Turn Signal & Hazard Lamp Installation - Optional E.7.2
Arch ROPS Beacon Lamp Installation - Optional E.8.2
Canopy ROPS Beacon Lamp Installation - Optional E.9.2
Arch ROPS Worklight Installation - Optional E.10.2
Canopy ROPS Worklight Installation - Optional E.11.2

For Internal Breakdowns - See Section I.

WATER SYSTEM

F

Water System Installation F.1.2
Spray System Scraper Assembly F.2.2
Water Pump Assembly F.3.2

For Internal Breakdowns - See Section I.

DECALS AND PAINT

G

Decal Installation - USA G.1.2

MidWestTech | Bobcat BCA24 Vibratory Compactor Parts Manual | Publication IR13226709 Order the manual at mid-west-tech.com >