
Bobcat®

DAYLIGHT 6kW

Operation/ Maintenance, Parts Manual



Bobcat

IR22162408(6–02)

Printed in U.S.A.


© Bobcat Company 2002

MidWestTech | Bobcat Daylight 6kW Lighting Attachment Operation/Maintenance, Parts Ma... Order the manual at mid-west-tech.com >

Ref. No.	Part Number	Description	Remarks	Serial Number	Qty.
1	IR36923266	DRAWBAR			1
2	IR36923092	DECAL	Panel		1
3	IR36877579	FENDER			1
4	IR54370259	SHIELD	Heat		1
5	IR36870020	PIN			1
6	IR36923662	HANDLE	Switch		1

MidWestTech | Bobcat Daylight 6kW Lighting Attachment Operation/Maintenance, Parts Ma... Order the manual at mid-west-tech.com >

DRAWBAR ASSEMBLY



MidWestTech | Bobcat Daylight 6kW Lighting Attachment Operation/Maintenance, Parts Ma... Order the manual at mid-west-tech.com >

DRAWBAR ASSEMBLY (CON'T)

Ref. No.	Part Number	Description	Remarks	Serial Number	Qty.
1	IR36923290	COUPLER	2"		1
2	IR36923241	SPACER			1
3	IR95935003	WASHER			1
4	IR35304047	NUT			1
5	IR35610377	CHAIN & HOOK	Assembly		1
6	IR96727896	SCREW			1
7	IR96715065	SCREW			1
8	IR36923415	JACK ASSY			1
9	IR36923266	DRAWBAR			1
10	IR95953998	SCREW			1
11	IR95935060	NUT			1
12	IR36787398	LEVEL			1
13	IR36769743	NUT			1
14	IR36923654	WINCH	Manual		1
15	IR95934998	WASHER			1
16	IR35271162	SCREW			1
17	IR36923407	OUTRIGGER			1
18	IR92368687	SCREW			1
19	IR36848224	PIN			1
20	IR36923506	RUNNING GEAR			1
21	IR35068345	TIRE & WHEEL	Assembly		1
22	IR36773265	TIRE			1
23	IR35292986	WHEEL			1
24	IR35282565	STEM	Valve		1
25	IR36923662	HANDLE	Winch		1
26	IR35279025	SCREW			1
27	IR36796068	TUBE	Mounting		1
28	IR54410600	BRACKET	Support		1

MidWestTech | Bobcat Daylight 6kW Lighting Attachment Operation/Maintenance, Parts Ma... Order the manual at mid-west-tech.com >