ISS-1543

Shop Manual

KOMATSU®

100,125 TD-7,8 SERIES C, E

LOADER/ DOZER

This material is proprietary to Komatsu America Corp. and is not to be reproduced, used, or disclosed except in accordance with written authorization from Komatsu America Corp.

It is our policy to improve our products whenever it is possible and practical to do so. We reserve the right to make changes or improvements at any time without incurring any obligation to install such changes on products sold previously.

Due to this continuous program of research and development, revisions may be made to this publication. It is recommended that customers contact their distributor for information on the latest revision.

Copyright 2010 Komatsu
Printed in U.S.A.
Komatsu America Corp.

July 1992

Order the manual at mid-west-tech.com >

INTERNATIONAL

MODEL 100, 125 SERIES C AND E LOADERS;

TD-7, TD-8 SERIES C AND E DOZERS

CHASSIS


INDEX

This manual is divided into major sections covering various components of the machines listed above. These sections are also indexed by title with thumb index tabs as shown below and to the right. To use this manual, grasp the right-hand side of book between thumb and fingers. Bend book back and find the pages containing the corresponding section index tab. Section identification is also contained in the upper corner of each page.

SECTION		
	1 - SPECIFICATIONS	1
	2 - ELECTRICAL SYSTEM	2
	3 - COOLING SYSTEM	3
	4 - ENGINE	4
	5 - HYDRAULIC TORQUE CONVERTER	5
	6 - TRANSMISSION (GEAR DRIVE)	6
	7 - TRANSMISSION (POWER SHIFT)	7
	8 - STEERING SYSTEM	8
	9 - SPROCKET DRIVE	9
	10 - TRACK AND TRACK FRAME ASSEMBLY	10
	11 - EQUIPMENT HYDRAULIC SYSTEM	11
	12 - ADJUSTMENTS	12
	13 - GEARMATIC WINCH ADAPTER	13

PRINTED IN U.S.A.

MidWestTech | Komatsu 100, 125, TD-7, TD8 Series C, E Loader Dozer Service Manual |... Order the manual at mid-west-tech.com >



Illust. 1
Hydraulic Piping (Series C Power Shift Dozer Shown)

1. Hydraulic control valve.
2. Lift cylinders.
3. Hydraulic pump (mounted on torque converter).
4. Angle cylinders.
5. Tilt cylinder.
6. Blade.

Order the manual at mid-west-tech.com >