Poclain 160 C
Hydraulic Excavator

Service Manual

K18-440-34

CASE IH
AGRICULTURE

MidWestTech | Case Poclain 160 C Hydraulic Excavator Service Manual | Publication K18

Order the manual at mid-west-tech.com >

GENERAL DESCRIPTION 3
CHARACTERISTICS ..... 4 - 5
UPPERSTRUCTURE - UNDERCARRIAGE
- Upperstructure 6
- Undercarriage 7
- Swing gear 8

TRACK GROUP
- Tracks - Pads 9
- Rollers 10
- Reduction gear - Sprocket wheel 11
- Idler wheel 12
- Tensioner - shock-absorber 12

ENGINE 14
- Fuel circuit 14

AIR FILTER 15
HEAVY DUTY AIR FILTER 16
HYDRAULIC CIRCUIT
- Description ..... 18 - 21
- Operation ..... 22 - 29
- Diagram of low pressure system ..... 30 - 32


TANK AND FILTERS ..... 34 - 35
HIGH PRESSURE PUMP ..... 36 - 37
ENGINE/PUMP COUPLING 38
MODULATOR ..... 40 - 42
VALVE BANKS AND VALVES - ATTACHMENTS
- Fitted hydraulically-operated 4S27 valve bank ..... 44 - 45
- S27 inlet block ..... 46 - 48
- Hydraulically-operated S27 control valve 49
- Safety valve 50
- S27 outlet selector control valve 51
- Forced feed of stick cylinder 52
- Outlet block 53

VALVE BANKS AND VALVES - SWING - TRAVEL - OPTIONS
- Fitted T20 - P20 valve bank ..... 54 - 55
- Fitted T20 valve bank ..... 56 - 57
- P20 control valve ..... 58 - 59
- Inlet block 60
- Counterpressure valve 60
- Intermediate block - inlet block 61

ATTACHMENT CYLINDERS ..... 62 - 64
HIGH PRESSURE HYDRAULIC MOTOR ..... 66 - 67
TURNING JOINT 68
LOW PRESSURE PUMP ..... 69 - 70
LOW PRESSURE HYDRAULIC MOTOR 71
VENTILATED COOLER 72
LOW PRESSURE EMERGENCY PUMP 73
MANUAL CONTROL BLOCK 74
FOOT-OPERATED CONTROL BLOCK 75
LOW PRESSURE FLOW SELECTOR 76
COUNTERPRESSURE VALVE 77
LOW PRESSURE ELECTROVALVE 78
LOAD HOLDING SAFETY BLOCK ..... 80 - 83
PRESSURE - SETTING CHECK ..... 84 - 85
ELECTRIC CIRCUITS ..... 86 - 89
MOUNTING ATTACHMENTS ..... 90 - 91

MidWestTech | Case Poclain 160 C Hydraulic Excavator Service Manual | Publication K18

Order the manual at mid-west-tech.com >



Order the manual at mid-west-tech.com >