ILLUSTRATED PARTS LIST

KUBOTA

KH41

EXCAVATOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68511-75102	ASSY CYLINDER,DOZER	1				11	24.2
011	68511-71310	ASSY TUBE,CYLINDER	1				5.6	12.32
012	68511-71320	ASSY.ROD,PISTON	1				2.42	5.324
020	68511-71330	COVER,ROD	1				1.47	3.234
030	68721-71940	BUSH,PIN	2				0.18	0.396
040	68511-71380	WEARING	2				0.015	0.033
050	68511-71340	PISTON	1				0.5	1.1
060	68511-71350	PISTON B	1				0.4	0.88
070	06611-15010	NIPPLE,GREASE	1				0.01	0.022
080	06616-25010	NIPPLE,GREASE	1				0.008	0.0176
090	68721-71890	BUSH,ROD	1				0.05	0.11
100	68511-71370	GASKET,PISTON	1				0.015	0.033
110	04810-50650	O RING	1				0.002	0.0044
120	68051-91640	GASKET	1				0.002	0.0044
130	68721-71240	RING,BACK UP	1				0.002	0.0044
140	04811-50700	O RING	1				0.002	0.0044
150	68051-91590	SEAL,DUST	1				0.005	0.011
160	68511-71360	NUT	1				0.1	0.22
170	05511-50545	PIN,SPLIT	1				0.01	0.022
180	68511-91120	SEAL KIT	1			OPTION	0.025	0.055

MidWestTech | Kubota KH41 Excavator Parts Manual | Publication KH41 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68511-21300	ASSY WHEEL,IDLER	2				9.5	20.9
010	68511-94200	ASSY WHEEL,IDLER	2			RUBBER CRAWLER TYPE	10.35	22.77
020	68511-21340	WHEEL,IDLER	2				0	0
020	68511-94210	WHEEL,IDLER	2			RUBBER CRAWLER TYPE	7.2	15.84
030	08240-00001	BEARING,BALL	4				0.19	0.418
040	68741-21350	SEAL,FLOATING	4				0	0
050	68051-21330	SHAFT,WHEEL IDLER	2				0.558	1.2276
060	68511-21320	BRACKET	4				0	0
070	05411-00663	PIN,SPRING	2				0.009	0.0198
080	04811-00210	O RING	4				0.001	0.0022
090	68051-21390	WIRE	2				0.002	0.0044
100	68511-21410	YOKE	2				2.82	6.204
110	01133-61225	BOLT	8				0.037	0.0814
120	68721-21430	RETAINER,SPRING	2				1.065	2.343
130	68051-21420	SPRING	2				2	4.4
140	68721-94140	SPACER	2			RUBBER CRAWLER TYPE	0.3	0.66
150	68741-21420	NUT	2				0.04	0.088
160	05511-50435	PIN,SPLIT	2				0.004	0.0088
170	68511-21510	TUBE,CYLINDER	2				1.9	4.18
180	68511-21520	RAM	2				0.81	1.782
190	68371-21530	NIPPLE,CYLINDER	2	<=13950			0	0
190	68371-21533	NIPPLE,CYLINDER	2	>=13951	←		0	0
200	04724-00120	GASKET	2				0.002	0.0044
210	68511-21550	SEAL,ROD	2				0.002	0.0044
220	04810-00300	O RING	2				0	0
230	68511-21540	RING,BACK UP	2				0.001	0.0022

MidWestTech | Kubota KH41 Excavator Parts Manual | Publication KH41 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68518-41800	KIT SPONGE	1				1.6	3.52
020	68721-43710	SPONGE	1				0.08	0.176
030	68728-43730	SPONGE	1				0	0
040	68728-43740	SPONGE	1				0	0
050	68721-43750	SPONGE	1				0.018	0.0396
060	68728-43760	SPONGE	1				0	0
065	68728-43920	SPONGE	1				0	0
070	68728-43770	SPONGE	1				0	0
075	68728-43930	SPONGE	1				0	0
080	68721-43782	SPONGE	1				0.028	0.0616
090	68728-43790	SPONGE	1				0	0
100	68721-43802	SPONGE	2				0.044	0.0968
105	68511-43800	KIT SPONGE	1				0.55	1.21
110	68721-43812	SPONGE	1				0.102	0.2244
120	68721-43832	SPONGE	1				0.1	0.22
130	68721-43843	SPONGE	1				0.026	0.0572
140	68721-43850	SPONGE	1				0.046	0.1012
150	68721-43870	SPONGE	2				0.045	0.099
160	68721-43880	SPONGE	1				0.11	0.242
170	68721-43890	SPONGE	1				0.1	0.22
180	68511-43910	SPONGE	1				0.03	0.066
190	68511-43920	SPONGE	1				0.03	0.066
200	68511-43930	SPONGE	1				0.01	0.022
210	68511-43940	SPONGE	1				0.03	0.066

MidWestTech | Kubota KH41 Excavator Parts Manual | Publication KH41 Order the manual at mid-west-tech.com >