ILLUSTRATED PARTS LIST

KUBOTA

KH-61

EXCAVATOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68741-93470	ASSY BOOM	1	<=10438			0	0
010	68741-93473	ASSY BOOM	1	>=10439	←		100	220
020	68741-66524	BUSH	2				0.36	0.792
030	06616-25010	NIPPLE GREASE	1				0.008	0.0176
040	68741-66560	CAP	4				0.001	0.0022
050	68741-66540	PIN	1	<=10438			0	0
050	68741-66544	PIN	1	>=10439	←		3.79	8.338
060	01173-61201	BOLT	1				0.091	0.2002
070	02174-60120	NUT	2				0.01	0.022
080	68741-93183	PIN	1				2.18	4.796
090	01517-61025	STUD	1				0.02	0.044
100	02118-60100	NUT	2				0.006	0.0132
110	68741-67560	PIN	1				1.45	3.19
120	01173-61285	BOLT	1				0.08	0.176
130	02174-60120	NUT	2				0.01	0.022

MidWestTech | Kubota KH-61 Excavator Parts Manual | Publication KH-61 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68531-21110	FRAME TRUCK	1				0	0
010	90731-41210	FRAME TRUCK	1			RUBBER CRAWLER TYPE	0	0
020	68541-21143	COVER	2				0.23	0.506
030	01133-61220	BOLT	4				0.033	0.0726
040	68541-21150	COVER LH	1				4.4	9.68
050	68541-21160	COVER RH	1				4.43	9.746
060	04015-60120	WASHER PLAIN	4				0.022	0.0484
070	01133-61225	BOLT	4				0.037	0.0814
080	01370-11220	BOLT	4				0.033	0.0726
080	68541-21180	BOLT	4		↔		0.033	0.0726
090	68541-21170	COVER	1				0	0
100	04015-60100	WASHER PLAIN	4				0.015	0.033
110	01133-61025	BOLT	4				0.02	0.044
120	90741-41240	GUIDE UPPER	2			RUBBER CRAWLER TYPE	1.82	4.004
130	01133-61025	BOLT	8			RUBBER CRAWLER TYPE	0.02	0.044
140	04013-60100	WASHER PLAIN	8			RUBBER CRAWLER TYPE	0.003	0.0066

MidWestTech | Kubota KH-61 Excavator Parts Manual | Publication KH-61 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68533-46300	ASSY DOOR	1				36	79.2
020	68533-46310	DOOR	1				0	0
030	68733-46320	WINDOW	1				3.5	7.7
040	68733-46330	RUBBER Z	1				0.88	1.936
050	68733-46350	WINDOW	1				2.5	5.5
060	68733-46360	RUBBER Z	1				0.77	1.694
070	68285-46570	GRIP	1				0.085	0.187
080	03004-60616	SCREW WITH WASHER	4				0.01	0.022
090	03024-60512	SCREW WITH WASHER	4				0.002	0.0044
100	68285-46830	HANDLE	1				0.3	0.66
110	04512-60080	WASHER SPRING	2				0.002	0.0044
120	02014-60080	NUT	2				0	0
130	68733-46280	ASSY CATCH	1				0.53	1.166
140	68285-46610	BRACKET	1				0.14	0.308
150	03024-60508	SCREW WITH WASHER	1				0.005	0.011
160	68285-46120	HANDLE	1				0.095	0.209
170	03024-60510	SCREW WITH WASHER	3				0.01	0.022
180	68733-46370	COVER DOOR	1				0.59	1.298
190	68285-46660	CUSHION	1				0.055	0.121
200	68743-46400	ASSY LOCK DOOR	1				0.35	0.77
210	68743-46380	LOCK	1				0.1	0.22
220	68743-46390	LOCK	1				0.24	0.528
230	03024-60516	SCREW WITH WASHER	3				0.003	0.0066
240	68743-46290	GROMMET	1				0.03	0.066
250	68733-46670	RUBBER SEAL 2	1				0.95	2.09
260	68285-99910	KEY CABIN	1				0.02	0.044
270	68543-46810	STRIKER	1	>=11471			0.06	0.132
280	68543-46820	WASHER	2	>=11471			0.003	0.0066
290	03016-50820	SCREW	2	>=11471			0.008	0.0176

MidWestTech | Kubota KH-61 Excavator Parts Manual | Publication KH-61 Order the manual at mid-west-tech.com >