
Kubota



MINI EXCAVATOR

MODELES

KX101

s/n 55001-Up

SPARE PARTS CATALOG

07/2006

CE

MidWestTech | Kubota KX101 Excavator Parts Manual | Publication KX101 Parts Order the manual at mid-west-tech.com >

KX101 S/N 55001-Up

Table of contents

Description	Index
CRANKCASE	0001
OIL PAN	0002
PISTON CRANKSHAFT	0003
MAIN BEARING CASE	0004
CAMSHAFT	0005
CYLINDER HEAD	0006
VALVE ROCKER ARM	0007
CYLINDER HEAD COVER	0008
GEAR CASE	0009
ENGINE STOP LEVER	0010
NOZZLE HOLDER GLOW PLUG	0011
NOZZLE HOLDER COMPONENT PARTS	0012
SPEED CONTROL PLATE	0013
GOVERNOR	0014
INJECTION PUMP CAMSHAFT 1	0015
INJECTION PUMP COMPONENT PARTS	0016
INJECTION PUMP CAMSHAFT 2	0017
WATER FLANGE	0018
WATER PUMP	0019
FLYWHEEL STARTER	0020
STARTER COMPONENT PARTS	0021
STARTER COMPONENT PARTS	0022
DYNAMO	0023
DYNAMO COMPONENT PARTS	0024
ENGINE BRACKET	0025
AIR CLEANER INLET MANIFOLD	0026
MUFFLER EXHAUST MANIFOLD	0027
ACCEL LEVER	0028
FUEL PIPING	0029
FUEL TANK	0030
RADIATOR	0031
WATER PIPE	0032
BATTERY	0033
REGULATOR HORN	0034
SWITCH METER	0035
ELECTRICAL WIRING	0036
PUMP HOUSING	0037
GEAR PUMP COMPONENT PARTS	0038
HYDRAULIC PUMP COMPONENT PART	0039
DRIVE MOTOR COMPONENT PARTS 1	0040
DRIVE MOTOR COMPONENT PARTS 2	0041
SWIVEL MOTOR COMPONENT PARTS	0042
ROTARY JOINT	0043
OIL TANK	0044
CONTROL VALVE 1	0045
CONTROL VALVE 1 COMPONENT PA	0046
SPOOL SECTION TRAVEL RH	0047
SPOOL SECTION BOOM	0048
SPOOL SECTION BUCKET	0049
SPOOL SECTION	0050
SPOOL SECTION TRAVEL SPEED 2ND	0051
SPOOL SECTION TRAVEL LH	0052
SPOOL SECTION BOOM	0053
SPOOL SECTION ARM	0054
SPOOL SECTION S P	0055
SPACER SECTION	0056
CONTROL VALVE 3	0057
CONTROL VALVE 3 COMPONENT PA	0058
SPOOL SECTION SWIVEL	0059

MidWestTech | Kubota KX101 Excavator Parts Manual | Publication KX101 Parts

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	69788-94600	ASSY DOZER	1			1510MM	0	0
020	06616-25010	NIPPLE GREASE	2				0.008	0.0176
030	68741-74440	PIN	2	55064			1.6	3.52
030	69441-74440	PIN	2	55065	↔		0	0
040	01173-61285	BOLT	2				0.08	0.176
050	02174-60120	NUT	4				0.01	0.022
060	68161-74440	PIN	1	55064			1.51	3.322
060	69481-74440	PIN	1	55065	↔		0	0
070	01176-61090	BOLT	1				0.054	0.1188
080	02118-60100	NUT	2				0.006	0.0132
090	68741-75120	PIN	1	55064			1.62	3.564
090	69441-75120	PIN	1	55065	↔		0	0
100	01173-61295	BOLT	1				0.085	0.187
110	02174-60120	NUT	2				0.01	0.022

MidWestTech | Kubota KX101 Excavator Parts Manual | Publication KX101 Parts Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68391-17110	COVER GEAR CASE	1				8.5	18.7
020	68741-17135	CASE GEAR SWING	1				10.5	23.1
030	05012-01022	PIN STRAIGHT	2				0.014	0.0308
040	01133-61060	BOLT	2				0.04	0.088
050	01315-11020	BOLT HEX-SOC-HD	2				0.02	0.044
060	06331-35016	PLUG	1				0.04	0.088
070	04717-01600	WASHER WITH RUBBER	1				0.003	0.0066
080	68773-17190	KNOCK COLLAR	2				0.1	0.22
090	01173-61600	BOLT	7				0.165	0.363
100	04512-60160	WASHER SPRING	7				0.01	0.022
110	68391-17140	GAUGE OIL	1	55002			0.08	0.176
110	68391-17150	GAUGE OIL	1	55003	≠		0.02	0.044
120	04717-01600	WASHER WITH RUBBER	1				0.003	0.0066
130	68391-17160	PIPE	1	55002			0.42	0.924
130	68391-17162	PIPE	1	55003	≠		0.38	0.836
130	69761-17162	PIPE	1	55065	↔		0	0

MidWestTech | Kubota KX101 Excavator Parts Manual | Publication KX101 Parts Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68301-96200	KIT SPONGE	1				0	0
020	68301-96210	SPONGE	1				0.06	0.132
030	68301-96220	SPONGE	1				0.255	0.561
040	68301-96232	SPONGE	1				0.05	0.11
050	68311-44740	SEAL RUBBER	3				0.01	0.022
060	68301-96250	SPONGE	2	55375			0.01	0.022
060	69731-96250	SPONGE	2	55376	↔		0	0
070	68301-96260	SPONGE	1				0.05	0.11
080	68301-96270	SPONGE	1				0.02	0.044
090	68301-96280	SPONGE	1				0.1	0.22
100	68301-96290	SPONGE	1				0.04	0.088
110	68151-96260	SEAL RUBBER	1				0.007	0.0154
120	68151-96270	SEAL RUBBER	1				0.003	0.0066
130	68301-96312	SPONGE	1				0	0
140	68301-96322	SPONGE	1				0	0
150	68301-96330	SPONGE	1				0.03	0.066
160	68301-96340	SPONGE	2	55375			0.07	0.154
160	69731-96340	SPONGE	2	55376	↔		0	0
170	68301-96370	GROMMET	2				0.005	0.011
180	68301-96380	GROMMET	1				0.005	0.011
190	68301-96390	GROMMET	2				0.01	0.022

MidWestTech | Kubota KX101 Excavator Parts Manual | Publication KX101 Parts Order the manual at mid-west-tech.com >