
ILLUSTRATED PARTS LIST

KUBOTA

KX91-2

EXCAVATOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC101-38102	ASSY SUPPORT SEAT	1	<=11894			10.1	22.22
010	RC108-38200	ASSY SUPPORT SEAT	1	>=11895	≠		16.7	36.74
020	99999-99999	BLANK	0				0	0
030	08511-02020	BUSH	4				0.01	0.022
040	68748-53120	GROMMET	2				0.015	0.033
050	RC101-38160	COLLAR	2				0.009	0.0198
060	08511-01008	BUSH	4				0.002	0.0044
070	04013-60100	WASHER PLAIN	2				0.003	0.0066
080	05525-61000	PIN SNAP	2				0.002	0.0044
090	RC408-38142	SUPPORT SEAT	1	<=12301			0	0
090	RC408-38143	SUPPORT SEAT	1	>=12302	←		8	17.6
100	01135-61025	BOLT	8				0.04	0.088
110	RC101-38210	COVER SEAT SUPPORT	1				0.66	1.452
120	01222-50616	BOLT	3				0.005	0.011
130	04013-60060	WASHER PLAIN	2				0.001	0.0022
140	04015-60060	WASHER PLAIN	1				0.005	0.011
150	RC408-38150	COVER	1				1.04	2.288
160	01025-60616	BOLT	2				0.01	0.022
170	01123-60820	BOLT	3				0.015	0.033
180	RC108-38300	ASSY LEVER LOCK	1				0.2	0.44
190	99999-99999	BLANK	0				0	0
200	08511-01410	BUSH	2				0.005	0.011
210	52200-33550	SPRING BRAKE RETURN	1				0.01	0.022
220	04013-60140	WASHER PLAIN	1				0.01	0.022
230	04612-00140	CIR CLIP EXTERNAL	1				0.001	0.0022
240	RC101-38310	BRACKET LOCK	1				0.2	0.44
250	01133-61025	BOLT	2				0.02	0.044
260	04013-60100	WASHER PLAIN	2				0.003	0.0066
270	15272-67580	CLAMP CORD	1				0.021	0.0462

MidWestTech | Kubota KX91-2 Excavator Parts Manual | Publication KX91-2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC501-48303	KIT SPONGE	1			TELESCOPIC	0.163	0.3586
020	RC501-48290	SPONGE	1			TELESCOPIC	0.02	0.044
030	RC308-41500	KIT SPONGE	1				0.123	0.2706
040	RC301-41530	SPONGE	1				0.05	0.11
050	RC301-41550	SPONGE	1				0.05	0.11
060	RC301-41560	SPONGE	1				0.005	0.011
070	RC301-41580	SPONGE	1				0.005	0.011
080	RC101-41810	PLATE PARTITION FRA.	1				0.005	0.011
090	RC301-41820	PLATE PARTITION FRA.	1				0.1	0.22
100	RC101-41830	PLATE PARTITION FRA.	1				0.03	0.066
110	RC101-41840	PLATE PARTITION FRA.	1				0.035	0.077
120	RC408-41800	KIT SPONGE	1				2.5	5.5
130	RC408-41910	SPONGE	1				0.142	0.3124
140	RC408-41920	SPONGE	1				0.035	0.077
150	RC408-41940	SPONGE	1				0.05	0.11
160	RC408-41970	SPONGE	1	<=11737			0.023	0.0506
170	RC408-41980	SPONGE	1	<=11737			0.012	0.0264
180	RC408-41930	SPONGE	1				0.095	0.209
190	RC408-41950	SPONGE	1				0.072	0.1584
200	RC408-41960	SPONGE	1				0.069	0.1518
210	RC408-41990	SPONGE	1	<=11737			0.012	0.0264
220	RC101-41673	SPONGE	1				0.08	0.176
230	RC401-48303	KIT SPONGE	1				0.284	0.6248
240	RC401-48290	SPONGE	1				0.15	0.33
250	RC101-48370	SPONGE	2				0.025	0.055
260	RC101-48392	SPONGE	2				0.02	0.044
270	RC401-48270	SPONGE	1				0.04	0.088
280	RC501-48330	SPONGE	1			TELESCOPIC	0.014	0.0308
290	RC501-48260	SPONGE	1			TELESCOPIC	0.005	0.011

MidWestTech | Kubota KX91-2 Excavator Parts Manual | Publication KX91-2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC101-46205	ASSY DOOR	1				20.2	44.44
020	03016-60816	SCREW CSK-HD	6				0.008	0.0176
030	04414-50080	WASHER TOOTHED	6				0.001	0.0022
040	RC101-46260	U-BOLT	1				0.11	0.242
050	02114-60100	NUT	4				0.008	0.0176
060	RC101-46220	GLASS DOOR UPPER	1				4.9	10.78
065	RC101-45660	SEAL RUBBER DOOR	1				0.05	0.11
070	RC101-46230	GLASS DOOR LOWER	1				3.4	7.48
075	RC101-45670	SEAL RUBBER DOOR	1				0.02	0.044
080	RC101-46270	ASSY LOCK DOOR	1				0.385	0.847
090	03016-60616	SCREW CSK-HD	3				0.04	0.088
100	04414-50060	WASHER TOOTHED	3				0.001	0.0022
110	RC101-46280	ASSY HANDLE OUTER	1				0.364	0.8008
120	RC101-46290	PLATE HANDLE	1				0.035	0.077
130	03004-60616	SCREW WITH WASHER	2				0.01	0.022
140	RC101-43540	ASSY LOCK CYLINDER	1				0.12	0.264
150	RC101-46310	LEVER KEY	1				0.026	0.0572
160	02118-60100	NUT	1				0.006	0.0132
170	04512-60100	WASHER SPRING	1				0.002	0.0044
180	RC101-46390	ASSY HANDLE INNER	1				0.09	0.198
182	RC101-45710	HANDLE INNER	1				0.06	0.132
184	RC101-45720	COVER INNER HANDLE	1				0.015	0.033
186	03614-50412	SCREW TAPPING	1				0.002	0.0044
190	03004-60616	SCREW WITH WASHER	2				0.01	0.022
200	04012-50060	WASHER PLAIN	2				0.001	0.0022
210	RC101-46240	COVER DOOR	1				0.18	0.396
220	03004-60616	SCREW WITH WASHER	3				0.01	0.022
230	04012-50060	WASHER PLAIN	3				0.001	0.0022
240	RC101-46190	ASSY LOCK DOOR OPEN	1				1.38	3.036
250	RC101-46180	GUIDE DOOR OPEN	1				0.09	0.198
260	01125-60816	BOLT	6				0.01	0.022
270	RC101-46430	STOPPER	6				0.055	0.121
275	02114-60100	NUT	6				0.008	0.0176
280	RC101-46680	TRIM DOOR	1				0.83	1.826
290	RC101-46690	SEAL DOOR	1				0.015	0.033
300	RC101-46550	SEAL DOOR LOWER	2				0.001	0.0022

MidWestTech | Kubota KX91-2 Excavator Parts Manual | Publication KX91-2 Order the manual at mid-west-tech.com >