
ILLUSTRATED PARTS LIST

KUBOTA

KX91-3

EXCAVATOR



Kubota

Order the manual at mid-west-tech.com >

BUCKET CYLINDER AND COMPONENT PARTS(TELESCOPIC)

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC418-67900	ASSY CYLINDER BUCKET	1				20.08	44.176
020	RC418-71860	ASSY TUBE BUCKET	1				9.06	19.932
030	RC418-71990	BUSH	1				0.24	0.528
040	RC418-71870	ASSY ROD BUCKET	1				8.5	18.7
050	68351-67770	BUSH PIN	1				0.208	0.4576
060	RC411-71720	CYLINDER HEAD	1				1.19	2.618
070	RC101-71540	BUSH	1				0.052	0.1144
080	68111-92140	U-RING	1				0.02	0.044
090	RP401-71420	RING WIPER	1				0.015	0.033
100	68481-71260	O RING	1				0.003	0.0066
110	RB301-71550	RING BACK UP	1				0.001	0.0022
120	68871-93240	O RING	1				0.002	0.0044
130	RC411-71730	PISTON	1				0.85	1.87
140	68481-71840	ASSY RING SEAL	1				0.015	0.033
150	RB401-71470	RING SLIDE	2				0.009	0.0198
160	68493-67650	SCREW SET	1				0.003	0.0066
170	68493-67670	BALL	1				0.001	0.0022
180	RC418-71850	ASSY PIPE	1				0.82	1.804
190	01053-51016	BOLT	1				0.03	0.066
200	04012-50100	WASHER PLAIN	1				0	0
210	06616-25010	NIPPLE GREASE	1				0.008	0.0176
220	RC411-71760	KIT SEAL	1				0.056	0.1232
230	RC411-66780	SEAL DUST	2				0.008	0.0176

MidWestTech | Kubota KX91-3 Excavator Parts Manual | Publication KX91_3 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC411-41510	SPONGE	1				0.008	0.0176
020	RC411-41520	SPONGE	1	<=20372			0	0
020	RC411-41522	SPONGE	1	>=20373	←		0.001	0.0022
030	RC411-48920	SPONGE	1				0.018	0.0396
040	99999-99999	BLANK	0				0	0
050	RC411-43650	PLATE PARTITION	1				0.025	0.055
060	RC411-43660	SPONGE BONNET	1				0.135	0.297
070	RC411-43670	SPONGE BONNET	1				0.1	0.22
080	RC411-43680	SPONGE BONNET	1				0.1	0.22
090	RC411-43690	SPONGE BONNET	1				0.002	0.0044
100	RC411-43783	PLATE PARTITION	1				0.04	0.088
110	RP421-43830	PLATE PARTITION	1				0.07	0.154
120	RC411-43842	SPONGE BONNET	1				0.18	0.396
122	RC411-43392	SPONGE BONNET	1				0.07	0.154
124	RC411-43470	PLATE PARTITION	1				0.05	0.11
130	RC411-43852	SPONGE BONNET	1				0.05	0.11
140	RC411-43862	SPONGE BONNET	1				0.002	0.0044
150	RC411-43940	BAND SEAL	1				0.003	0.0066
160	RC411-43630	TRIM	1				0.19	0.418
170	RC411-43810	TRIM	1				0.24	0.528
180	RC411-43180	SPONGE BONNET	1				0.008	0.0176
190	RC411-41532	SPONGE	1				0.001	0.0022
200	RC411-43622	TRIM	1				0.34	0.748
210	RP421-43610	TRIM	1				0.17	0.374
220	RC411-48900	SPONGE	1				0.03	0.066
225	RC411-41590	SPONGE	1				0.016	0.0352
230	RC418-48730	ABSORBER SOUND	1			CABIN	0.08	0.176
240	RC411-48760	ABSORBER SOUND	1			CABIN	0.06	0.132
250	RC411-48952	SPONGE	1				0.008	0.0176
260	RC411-48962	SPONGE	1				0.004	0.0088
270	RC411-48972	SPONGE BONNET	1				0.011	0.0242
280	RC418-44290	NOISE ABSORBER	1				0.013	0.0286

MidWestTech | Kubota KX91-3 Excavator Parts Manual | Publication KX91_3 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC411-46103	ASSY GLASS FRONT	1				17.7	38.94
020	RC411-46112	GLASS FRONT UPPER	1				9.3	20.46
030	RC411-47410	SEAL	1				0.08	0.176
040	RC411-46152	ASSY ROLLER LH	1				0	0
050	RC411-46140	ROLLER	1				0.005	0.011
060	01123-60820	BOLT	3				0.015	0.033
070	RC411-46182	ASSY LATCH LH	1				0.28	0.616
080	RC411-46200	GRIP	1				0.005	0.011
090	01123-60816	BOLT	2	<=20671			0.01	0.022
090	01125-60820	BOLT	2	>=20672	↔		0.015	0.033
100	RC411-46162	ASSY ROLLER RH	1				0	0
110	RC411-46140	ROLLER	1				0.005	0.011
120	01123-60820	BOLT	3				0.015	0.033
130	RC411-46192	ASSY LATCH RH	1				0	0
140	RC411-46200	GRIP	1				0.005	0.011
150	01123-60816	BOLT	2				0.01	0.022
160	RC411-46132	GUARD LOWER	1				0.13	0.286
170	RC411-46140	ROLLER	2				0.005	0.011
180	68311-46570	GRIP	2				0.05	0.11
190	03034-50612	SCREW WITH WASHER	4				0.006	0.0132
200	RC411-46290	STOPPER	1				0.018	0.0396
210	RC411-46300	STOPPER	1				0.017	0.0374
220	03034-50616	SCREW WITH WASHER	4				0.006	0.0132
230	RC411-46310	STOPPER	1				0.015	0.033
240	03034-50512	SCREW WITH WASHER	1				0.004	0.0088
250	RC411-46090	PLATE ADJUST	1				0.012	0.0264
260	03056-60516	SCREW CSK-HD	2				0.024	0.0528
270	RC411-46320	STOPPER	1				0.021	0.0462
280	02054-60080	NUT	1				0.01	0.022
290	RC411-46330	ASSY GLASS FRONT	1				5	11
300	RC411-46350	SEAL	1				0.07	0.154
310	RC411-46260	SCREW WITH WASHER	2				0.007	0.0154
320	RC411-46270	GASKET	4				0.001	0.0022
330	RC411-46280	NUT	2				0.006	0.0132
340	RC411-46250	STOPPER	4				0.01	0.022
350	03034-50410	SCREW WITH WASHER	4				0.002	0.0044
360	RC411-46380	RUBBER STOPPER	2				0.033	0.0726
370	RC411-46360	TRIM UPPER FRONT	1				0.75	1.65
380	RC411-46370	TRIM LOWER FRONT	2				0.35	0.77

MidWestTech | Kubota KX91-3 Excavator Parts Manual | Publication KX91_3 Order the manual at mid-west-tech.com >