ILLUSTRATED PARTS LIST

KUBOTA

L175

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15222-01010	ASSY CRANK CASE	1				0	0
002	15103-94590	LABEL DRAIN	1				0.001	0.0022
003	15221-02314	LINER CYLINDER	2			HONE IINER AFTER INSERTING IN CRANKCASE	0	0
004	06311-75015	PLUG BELCH	3				0.002	0.0044
005	15221-03383	PLUG	3				0	0
006	15221-03392	PLUG	2				0	0
007	06311-75045	PLAG BELCH	1				0.026	0.0572
008	15221-33630	PLUG PIN	2				0.001	0.0022
009	15221-33640	PLUG	1				0.003	0.0066
010	05012-00408	PIN	2				0.001	0.0022
011	05012-00609	PIN	2				0.003	0.0066
012	05012-00612	PIN	2				0.003	0.0066
013	05012-01018	PIN	3				0.012	0.0264
014	15221-33650	PIN PIPE	1				0.004	0.0088
015	15221-72842	PIPE WATER 3	1				0	0
016	14412-73110	ASSY COCK DRAIN	1				0.09	0.198
017	15221-33610	PLUG	3				0.009	0.0198
018	15021-33660	GASKET	3				0.001	0.0022
019	15221-33752	PLAG	1				0	0
020	15109-33660	GASKET	1				0.001	0.0022
021	15221-04552	BOLT KNOCK	1				0	0
022	15021-33660	GASKET	1				0.001	0.0022
023	15221-33700	O-RING	1				0.001	0.0022
024	15221-36413	GAUGE OIL	1				0	0
025	04811-00050	O-RING	2				0.001	0.0022
026	15221-01613	COVER OIL	1				0	0
027	15221-01622	GASKET OIL COVER	1				0	0
028	01053-50816	BOLT	16				0.011	0.0242
029	04512-00080	WASHER LOCK	16				0	0
030	15221-33752	PLUG	1				0	0
031	15109-33660	GASKET	1				0.001	0.0022
032	34159-14183	ASSY HOUSING FLYWHEE	1				0	0
033	15103-94590	LABEL	1				0.001	0.0022
034	05012-01018	PIN	2				0.012	0.0264
035	31220-14172	COVER	1				0	0
036	01053-50812	BOLT	1				0.009	0.0198
037	04512-00080	WASHER LOCK	1				0	0
038	01073-51030	BOLT	11				0.028	0.0616
039	04512-00100	WASHER LOCK	11				0	0
040	15221-03024	ASSY HEAD CYLINDER	1				0	0
041	34150-18070	PLATE BAFFLE 2	1				0.045	0.099
042	15221-03373	PLUG	6	<=3439			0	0
042	15221-03373	PLUG	2	>=3440			0	0
043	15221-03493	PLUG	1				0	0
044	15131-01380	PLUG	2				0.001	0.0022
045	15221-13585	GUIDE INLET VALVE	2			REAM QUIDE AFTER INSERTING IN HEAD	0	0
046	15601-13560	GUIDE EXHAUST VALVE	2	>=10584			0	0
047	15221-01750	HOOK ENGINE	2				0.04	0.088

MidWestTech | Kubota L175 Tractor Parts Manual | Publication L175 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
048	01513-50816	STUD	2				0.009	0.0198
049	02056-00080	NUT	2				0	0
050	04512-00080	WASHER LOCK	2				0	0
051	15221-03450	BOLT CYLINDER HEAD	8				0	0
052	15221-03412	STUD CYLINDER HEAD	2				0	0
053	15221-03510	NUT CYLINDER HEAD	2				0.008	0.0176
054	15221-03540	WASHER FLAT	10				0.003	0.0066
055	15221-03310	GASKET CYLINDER HEAD	1				0	0
056	15221-03323	SHIM HEAD GASKET	1	<=1304			0	0
057	15221-63012	ASSY STARTER	1	<=1659		TO REFERENCE FIG.No.33	0	0
057	15221-63014	ASSY STARTER	1	>=1660		TO REFERENCE FIG.No.33	0	0
058	01173-51030	BOLT	1				0.023	0.0506
059	01517-51025	STUD	1				0	0
060	02176-50100	NUT	1				0.005	0.011
061	04512-50100	WASHER LOCK	2				0	0
062	15221-39012	SWITCH OIL	1				0	0
063	15221-32112	FILTER OIL 1	1				0	0
064	01053-50816	BOLT	1				0.011	0.0242
065	04512-00080	WASHER LOCK	1				0	0
066	04811-00140	O-RING	1				0.001	0.0022
067	31220-14293	PLUG 3	4				0	0
068	34150-27580	PLUG	3				0.001	0.0022

MidWestTech | Kubota L175 Tractor Parts Manual | Publication L175 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15222-23010	ASSY CRANK SHAFT	1				0	0
002	15131-01380	PLUG PIN	2				0.001	0.0022
003	15221-25010	ASSY FLYWHEEL	1				0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.003	0	0
005	15221-63823	GEAR RING	1				0	0
006	05012-00612	PIN	2				0.003	0.0066
007	15221-25160	BOLT FLYWHEEL	6				0.024	0.0528
008	15221-25172	WASHER FLYWHEEL	3				0	0
009	15221-21110	PISTON	2				0.45	0.99
010	15221-21050	ASSY RING PISTON	2				0.05	0.11
011	15221-21310	PIN PISTON	2				0	0
012	15221-21330	CIR-CLIP PISTON PIN	4				0.002	0.0044
013	15221-22010	ASSY CONNECTING ROD	2				0	0
014	15221-21980	BUSH PISTON PIN	2				0	0
015	15221-22142	BOLT CONNECTING ROD	4				0	0
016	15221-22170	WASHER ROD BOLT	2				0.01	0.022
017	15221-22310	METAL CRANK PIN	4				0	0
018	15221-23470	METAL CRANK PIN 1	1				0	0
019	15221-23480	METAL CRANK PIN 2	4				0	0
020	15221-23530	METAL SIDE 1	2				0	0
021	15221-23540	METAL SIDE 2	2				0	0
022	15222-07020	ASSY CASE MAIN BEARI	1				0	0
023	99999-99999	BLANK	0			ORDER BY REF.No.020	0	0
024	99999-99999	BLANK	0			ORDER BY REF.No.020	0	0
025	15221-04542	BOLT 1	4				0	0
026	15221-04573	WASHER 1	2				0	0
027	15221-04583	WASHER 2	2				0	0
028	15221-04360	GASKET	1				0	0
029	15221-04812	COVER BEARING	1				0	0
030	15221-04820	GASKET BEARING COVER	1				0	0
031	01053-50825	BOLT 1	8				0.014	0.0308
032	04512-50080	WASHER LOCK	8				0.001	0.0022
033	04012-50080	WASHER FLAT	8				0.001	0.0022
034	01053-50828	BOLT	8				0.014	0.0308
035	15221-04642	WASHER LOCK 1	1				0	0
036	15221-04652	WASHER LOCK 2	2				0	0
037	15221-04662	WASHER LOCK 3	1				0	0
038	15221-04460	SEAL OIL	1				0.06	0.132
039	15222-07010	ASSY CASE MAIN BEARI	1				0	0
040	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
041	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
042	15221-04562	BOLT 2	1				0	0
043	15221-04590	WASHER 3	1				0.005	0.011

MidWestTech | Kubota L175 Tractor Parts Manual | Publication L175 Order the manual at mid-west-tech.com >

CLUTCH PEDAL

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	32130-14302	ASSY DISK CLUTCH	1				0	0
002	32200-14509	ASSY PLATE PRESSURE	1				0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
004	32200-14520	SPRING PRESSURE	6				0.066	0.1452
005	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
006	32200-14540	LEVER RELEASE	3				0.05	0.11
007	32130-14560	PIN SPLIT	3				0.001	0.0022
008	32200-14570	BOLT LEVER	3				0.009	0.0198
009	32130-14580	NUT	3				0.003	0.0066
010	32130-14590	CAP PRESSURE SPRING	6				0.024	0.0528
011	32130-14622	SEAT LEVER	3				0	0
012	32130-14630	SPRING RETURN	3				0.006	0.0132
013	32130-14640	RIVET	6				0.001	0.0022
014	32130-14650	WASHER RELEASE YOKE	3				0.002	0.0044
015	05012-00614	RIN STRAIGHT	2				0.004	0.0088
016	01153-50816	BOLT	6				0.01	0.022
017	04512-50080	WASHER LOCK	6				0.001	0.0022
018	34150-14712	LEVER CLUTCH	1				0	0
019	31150-14727	FORK	1				0	0
020	31150-14784	KEY FORK	1				0	0
021	01153-50822	BOLT	1				0.011	0.0242
022	04512-50080	WASHER LOCK	1				0.001	0.0022
023	34150-14810	HUB CLUTCH RELEASE	1				0.28	0.616
024	06613-10010	NIPPLE GREASE	1				0.006	0.0132
025	32150-14820	BEARING THRUST BALL	1				0.2	0.44
026	34150-14842	SPRING	1				0	0
027	34150-15413	CASE PROPELLER SHAFT	1	<=12603			0	0
027	34150-15416	CASE PROPELLER SHAFT	1	>=12604			0	0
027	34150-15419	CASE PROPELLER SHAFT	1	>=15684			0	0
028	04811-50650	O RING	1				0.002	0.0044
029	09502-55210	SEAL OIL	1				0.025	0.055
030	01153-50830	BOLT	4				0	0
031	04512-50080	WASHER LOCK	4				0.001	0.0022
032	34150-15632	JOINT CLUTCH	1				0	0
033	05112-50822	PIN	1				0.01	0.022
034	04012-50080	WASHER FLAT	1				0.001	0.0022
035	05511-50215	PIN SPLIT	1	<=10553			0.001	0.0022
035	05511-50220	PIN SPLIT	1	>=10554			0.001	0.0022
036	34159-15643	ROD CLUTCH	1	<=12303			0	0
036	34209-15642	ROD CLUTCH	1	>=12304			0	0
036	34159-15644	ROD CLUTCH	1	>=14034			0	0
037	02172-50120	NUT	1				0.01	0.022
038	04013-50120	WASHER FLAT	1				0	0
039	05511-50425	PIN SPLIT	1				0.003	0.0066
040	34159-15700	ASSY PEDAL CLUTCH	1				1.3	2.86
041	32120-14752	BUSHING	2				0	0
042	06613-10675	NIPPLE GREASE	1				0.003	0.0066
043	34150-15843	SPRING	1				0	0
044	34159-15902	ASSY SPACER PEDAL	1				0	0
045	32240-15952	SPACER PEDAL	1				0	0
046	31220-15972	MARK SPACER	1				0	0
047	32170-15934	LABEL PEDAL A	1				0	0
048	33251-75104	SWITCH SAFETY	1	<=17523			0	0
048	34150-32240	SWITCH SAFETY	1	>=17524			0	0
049	34159-34590	NUT	1				0.011	0.0242

MidWestTech | Kubota L175 Tractor Parts Manual | Publication L175 Order the manual at mid-west-tech.com >

FUEL TANK

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	34150-35107	ASSY TANK FUEL	1	<=18523			0	0
001	34150-35109	ASSY TANK FUEL	1	>=18524			0	0
001	34159-35100	ASSY TANK FUEL	1	>=18524			5.6	12.32
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	10242-41353	FILTER	1	<=18523			0	0
003	13251-41352	FILTER	1	>=18524			0	0
004	31180-35230	CAP	1	<=11343			0	0
004	66591-54420	CAP	1	>=11344			0	0
004	34150-35223	CAP	1	>=18524			0	0
005	10211-41340	GASKET	1	<=18523			0.003	0.0066
005	34150-35230	GASKET	1	>=18524			0.01	0.022
006	34150-35260	PLUG	1	<=11343			0	0
006	34150-27590	PLUG	1	>=11344			0.04	0.088
006	06312-10010	PLUG	1	>=11494			0.007	0.0154
006	06311-21010	PLUG	1	>=11654			0	0
007	04714-00300	GASKET	1	<=11653			0.002	0.0044
007	04717-01000	WASHER SEAL	1	>=11654			0.001	0.0022
008	34150-35470	GAUGE FUEL	1				0	0
009	10013-41770	CLIP PIPE	2				0.005	0.011
010	34150-35276	SUPPORT FUEL TANK	1				0	0
011	34150-35284	STAY FUEL TANK RH	1	<=15923			0	0
011	34150-35286	STAY FUEL TANK RH	1	>=15924			0	0
012	34150-35290	STAY FUEL TANK LH	1				0.46	1.012
013	01222-50814	BOLT	13				0.009	0.0198
014	04512-50080	WASHER LOCK	13				0.001	0.0022
015	15221-43015	ASSY FILTER FUEL	1				0	0
016	15221-43210	COVER	1				0.25	0.55
017	15221-43080	ELEMENT	1	<=12043			0	0
017	15221-43170	CARTRIDGE FILTER	1	>=12044			0.3	0.66
018	14102-43283	PLUG DRAN	1				0	0
019	15108-43290	O RING	1				0.001	0.0022
020	99999-99999	BLANK	0			ORDER BY REF.No.015	0	0
021	99999-99999	BLANK	0			ORDER BY REF.No.015	0	0
022	34150-35810	SUPPORT FILTER	1				0.16	0.352
023	01120-50816	BOLT	2				0	0
024	01120-50820	BOLT	2				0	0
025	02114-50080	NUT	2				0.005	0.011
026	99999-99999	BLANK	0			ORDER BY REF.No.038	0	0
027	99999-99999	BLANK	0			ORDER BY REF.No.039	0	0
028	14301-42753	CLIP PIPE	4				0	0
029	17105-33682	GASKET	2				0	0
030	14111-42413	JOINT EYE	1				0	0
031	34150-35543	PIPE FUEL 3	1				0	0
032	10244-42320	CLAMP PIPE	2				0.001	0.0022
033	34150-34770	HOLDER DECOMP.WIRE	1				0.001	0.0022
034	66591-55300	HORN	1	>=15674			0.15	0.33
035	01050-50612	BOLT	2	>=15674			0.005	0.011
036	04512-50060	WASHER LOCK	2	>=15674			0	0
037	15221-87762	LABEL	1	>=10544			0	0
038	34150-35502	ASSY PIPE FUEL 1	1	>=10455			0	0
039	34150-35532	ASSY PIPE FUEL 2	1	>=10455			0	0
040	14121-41400	ASSY COCK FUEL	1	<=11653			0.09	0.198
040	31220-35403	ASSY COCK FUEL	1	>=11494			0	0
041	04711-00100	GASKET	3	>=11494			0.001	0.0022
042	34150-35554	BUSH FUEL TANK	1	>=14034			0	0

MidWestTech | Kubota L175 Tractor Parts Manual | Publication L175 Order the manual at mid-west-tech.com >