ILLUSTRATED PARTS LIST

KUBOTA

L185DT

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35110-85010	ASSY SEAT	1				0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	32140-18470	MARK,KUBOTA	1				0.002	0.0044
006	32160-18440	CUSHION	2				0.013	0.0286
007	34269-18400	ASSY SUSPENSION,SEAT	1	<=10695			0	0
007	35110-18400	ASSY SUSPENSION,SEAT	1	>=10696			4.3	9.46
007	35110-18400	ASSY SUSPENSION,SEAT	1	>=50001			4.3	9.46
008	99999-99999	BLANK	0			ORDER BY REF.No.007	0	0
009	99999-99999	BLANK	0			ORDER BY REF.No.007	0	0
010	35258-18430	ARM 1	1				0.67	1.474
011	99999-99999	BLANK	0			ORDER BY REF.No.007	0	0
012	34119-18450	SPRING,SEAT	2				0.117	0.2574
013	34269-18460	BOLT,ADJUSTING	1				0.075	0.165
013	35258-18460	BOLT,ADJUSTING	1				0.08	0.176
014	34269-18490	PIN	4				0.06	0.132
015	02118-50100	NUT	1				0.005	0.011
016	02116-50100	NUT	1				0.004	0.0088
017	04013-50100	WASHER,PLAIN	8				0	0
018	05511-50222	PIN,SPRIT	8				0.001	0.0022
019	01130-51020	BOLT	2				0	0
020	01130-51030	BOLT	2				0	0
021	35110-18460	SPACER	1				0.2	0.44
022	35110-18470	BOLT	2				0.012	0.0264
023	02114-50080	NUT	2				0.005	0.011
024	35110-99100	ASSY COVER,SEAT	1				0.52	1.144
025	35110-85050	EYE-LET	4			SERVICE PARTS	0.005	0.011
026	35110-85060	PROTECTOR	3			SERVICE PARTS	0.01	0.022
027	35258-18480	ROLLER	2				0.005	0.011
028	35320-18480	BRACKET,PLATE	1	>=52472		L185-3	0.22	0.484
029	03014-50616	BOLT	2	>=52472		L185-3	0.003	0.0066
030	02014-50060	NUT	2	>=52472		L185-3	0.003	0.0066
031	04512-50060	WASHER,SPRING	2	>=52472		L185-3	0	0
032	04012-50060	WASHER,PLAIN	2	>=52472		L185-3	0.001	0.0022

MidWestTech | Kubota L185DT Tractor Parts Manual | Publication L185DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	37650-43110	CASE,DIFF GEAR	1				6	13.2
002	06331-35012	PLUG	1				0.022	0.0484
003	04717-01200	WASHER,SEAL	1				0.002	0.0044
004	37650-43120	CASE,DIFF BEARING	1	<=10865			2.67	5.874
005	37650-43160	SHIM	4				0.002	0.0044
005	37650-43130	SHIM	4				0.005	0.011
006	37650-43170	SHIM	2				0.004	0.0088
006	37650-43140	SHIM	2				0.005	0.011
007	01173-51028	BOLT	8	<=10865			0.022	0.0484
008	04512-50100	WASHER,SPRING	8	<=10865			0	0
009	37150-26480	WASHER,SPRING	2	>=50001			0.016	0.0352
010	99999-99999	BLANK	1	<=52471		ORDER BY REF.No.036	0	0
010	99999-99999	BLANK	1	>=52472		ORDER BY REF.No.036	0	0
011	37650-43220	COLLAR,OIL SEAL	1				0.05	0.11
012	37650-43230	CASE,PINION BEARING	1				0.87	1.914
013	31220-22340	NUT	1				0.033	0.0726
014	37650-43280	SHIM	4				0.001	0.0022
014	37650-43270	SHIM	6				0.003	0.0066
015	04811-00240	O RING	1				0.001	0.0022
016	04811-50700	O RING	1				0.002	0.0044
017	08711-30305	BEARING,TAPER ROLLER	1				0.266	0.5852
018	08711-30205	BEARING,TAPER ROLLER	1				0.148	0.3256
019	09500-35528	SEAL,OIL	1				0.017	0.0374
020	01156-50822	BOLT	4				0.01	0.022
021	04512-50080	WASHER,SPRING	4				0.001	0.0022
022	37650-43310	CASE,DIFFERENTIAL	1	<=10005			0	0
022	37800-43310	CASE,DIFFERENTIAL	1	>=10006			2.11	4.642
022	37800-43310	CASE,DIFFERENTIAL	1	>=50001			2.11	4.642
023	37650-43320	PIN,SNAP	1				0.01	0.022
024	37650-43330	SHAFT,DIFF PINION	1				0.3	0.66
025	99999-99999	BLANK	0			ORDER BY REF.No.037	0	0
026	31220-26360	BUSH	2				0.015	0.033
027	31220-26390	WASHER,DIFF PINION	2				0	0
028	34150-26430	GEAR,DIFF SIDE RH	2				0	0
028	38440-44980	GEAR,DIFF SIDE RH	1				0	0
029	31220-26480	WASHER	2				0.015	0.033
029	31220-26490	WASHER	2				0.02	0.044
030	99999-99999	BLANK	0			ORDER BY REF.No.036	0	0
031	37650-43360	BUSH	1				0.039	0.0858
032	08101-06011	BEARING,BALL(6011)	1				0.376	0.8272
033	08101-06010	BEARING,BALL(6010)	1				0.262	0.5764
034	37650-43370	STOPPER	3	<=10865			0.015	0.033
035	34350-26250	BOLT	6	<=10865			0	0
035	37800-43870	BOLT	6	>=50001			0.026	0.0572
036	37800-43200	ASSY SPIRAL BEVEL	1				3.27	7.194
037	31220-26300	ASSY PINION,DIFFEREN	1				0.155	0.341
038	34150-26440	GEAR,DIFF SIDE LH	1				0	0
038	38180-26440	GEAR,DIFF SIDE LH	1				0.61	1.342

MidWestTech | Kubota L185DT Tractor Parts Manual | Publication L185DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	32270-36210	KEY,WOODRUFF	1	<=13843			0.001	0.0022
002	99999-99999	BLANK	1	<=13843		ORDER BY REF.No.001 ON FIG.No.051	0	0
003	99999-99999	BLANK	1	<=13843		ORDER BY REF.No.001 ON FIG.No.051	0	0
004	32270-36230	SEAL,OIL	1	<=10795			0.005	0.011
004	37150-36230	SEAL,OIL	1	>=10796			0.007	0.0154
005	99999-99999	BLANK	1	<=13843		NON SALE ORDER BY REF.No.016,017	0	0
006	99999-99999	BLANK	1	<=13843		ORDER BY REF.No.017	0	0
007	32270-36240	RING,SUPPORT	2	<=13843			0.005	0.011
008	32270-36250	RING,SEERING.	2	<=13843			0.001	0.0022
009	32270-36220	O RING	1	<=13843			0.001	0.0022
010	32270-36260	O RING	2	<=13843			0.001	0.0022
011	01311-10825	BOLT, HEX-SOC-HD	6	<=10795			0.02	0.044
012	99999-99999	BLANK	0			NON SALE ORDER BY REF.No.016,017	0	0
013	99999-99999	BLANK	1	<=13843		NON SALE ORDER BY REF.No.016,017	0	0
014	01156-50825	BOLT	6	<=13843			0.013	0.0286
015	04512-50080	WASHER,SPRING	6	<=13843			0.001	0.0022
016	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.051	0	0
017	37150-36200	ASSY BUSH, GEAR	1	<=13843			0.635	1.397
018	35110-76100	ASSY GEAR PUMP	1	>=13844			1.9	4.18
019	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.018	0	0
020	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.018	0	0
021	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
022	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
023	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
024	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
025	04810-50550	O RING	1	>=13844			0.002	0.0044
026	38180-76170	O RING	4	>=13844			0	0
027	04810-00050	O RING	1	>=13844			0.001	0.0022
028	01156-51030	BOLT	4	>=13844			0.02	0.044
029	04011-50100	WASHER,PLAIN	4	>=13844			0.002	0.0044
030	67211-76190	SEAL,OIL	1	>=13844			0	0
031	04611-00280	CIR-CLIP, INTERNAL	1	>=13844			0.002	0.0044
032	05811-00313	KEY,WOODRUFF	1	>=13844			0.001	0.0022
033	35180-36100	ASSY BUSH, GEAR	1	>=13844			0	0

MidWestTech | Kubota L185DT Tractor Parts Manual | Publication L185DT Order the manual at mid-west-tech.com >