ILLUSTRATED PARTS LIST

KUBOTA

L185F

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35110-85010	ASSY SEAT	1				0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	32140-18470	MARK,KUBOTA	1				0.002	0.0044
006	32160-18440	CUSHION	2				0.013	0.0286
007	34269-18400	ASSY SUSPENSION,SEAT	1	<=11024			0	0
007	35110-18400	ASSY SUSPENSION,SEAT	1	>=11025			4.3	9.46
007	35110-18400	ASSY SUSPENSION,SEAT	1	>=50001			4.3	9.46
008	99999-99999	BLANK	0			ORDER BY REF.No.007	0	0
009	99999-99999	BLANK	0			ORDER BY REF.No.007	0	0
010	35258-18430	ARM 1	1				0.67	1.474
011	99999-99999	BLANK	0			ORDER BY REF.No.007	0	0
012	34119-18450	SPRING,SEAT	2				0.117	0.2574
013	34269-18460	BOLT,ADJUSTING	1				0.075	0.165
013	35258-18460	BOLT,ADJUSTING	1				0.08	0.176
014	34269-18490	PIN	4				0.06	0.132
015	02118-50100	NUT	1				0.005	0.011
016	02116-50100	NUT	1				0.004	0.0088
017	04013-50100	WASHER,PLAIN	8				0	0
018	05511-50222	PIN,SPRIT	8				0.001	0.0022
019	01130-51020	BOLT	2				0	0
020	01130-51030	BOLT	2				0	0
021	35110-18460	SPACER	1				0.2	0.44
022	35110-18470	BOLT	2				0.012	0.0264
023	02114-50080	NUT	2				0.005	0.011
024	35110-99100	ASSY COVER,SEAT	1				0.52	1.144
025	35110-85050	EYE-LET	4			SERVICE PARTS	0.005	0.011
026	35110-85060	PROTECTOR	3			SERVICE PARTS	0.01	0.022
027	35258-18480	ROLLER	2				0.005	0.011
028	35320-18480	BRACKET,PLATE	1	>=55447		L185-3	0.22	0.484
029	03014-50616	BOLT	2	>=55447		L185-3	0.003	0.0066
030	02014-50060	NUT	2	>=55447		L185-3	0.003	0.0066
031	04512-50060	WASHER,SPRING	2	>=55447		L185-3	0	0
032	04012-50060	WASHER,PLAIN	2	>=55447		L185-3	0.001	0.0022

MidWestTech | Kubota L185F Tractor Parts Manual | Publication L185F Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	32270-36210	KEY,WOODRUFF	1	<=13843			0.001	0.0022
002	99999-99999	BLANK	1	<=13843		ORDER BY REF.No.001 ON FIG.No.051	0	0
003	99999-99999	BLANK	1	<=13843		ORDER BY REF.No.001 ON FIG.No.051	0	0
004	32270-36230	SEAL,OIL	1	<=11675			0.005	0.011
004	37150-36230	SEAL,OIL	1	>=11676			0.007	0.0154
005	99999-99999	BLANK	1	<=13843		NON SALE ORDER BY REF.No.016,017	0	0
006	99999-99999	BLANK	1	<=13843		ORDER BY REF.No.017	0	0
007	32270-36240	RING,SUPPORT	2	<=13843			0.005	0.011
008	32270-36250	RING,SEERING.	2	<=13843			0.001	0.0022
009	32270-36220	O RING	1	<=13843			0.001	0.0022
010	32270-36260	O RING	2	<=13843			0.001	0.0022
011	01311-10825	BOLT, HEX-SOC-HD	6	<=11675			0.02	0.044
012	99999-99999	BLANK	0			NON SALE ORDER BY REF.No.016,017	0	0
013	99999-99999	BLANK	1	<=13843		NON SALE ORDER BY REF.No.016,017	0	0
014	01156-50825	BOLT	6	<=13843			0.013	0.0286
015	04512-50080	WASHER,SPRING	6	<=13843			0.001	0.0022
016	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.051	0	0
017	37150-36200	ASSY BUSH, GEAR	1	<=13843			0.635	1.397
018	35110-76100	ASSY GEAR PUMP	1	>=13844			1.9	4.18
019	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.018	0	0
020	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.018	0	0
021	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
022	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
023	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
024	99999-99999	BLANK	1	>=13844		ORDER BY REF.No.033	0	0
025	04810-50550	O RING	1	>=13844			0.002	0.0044
026	38180-76170	O RING	4	>=13844			0	0
027	04810-00050	O RING	1	>=13844			0.001	0.0022
028	01156-51030	BOLT	4	>=13844			0.02	0.044
029	04011-50100	WASHER,PLAIN	4	>=13844			0.002	0.0044
030	67211-76190	SEAL,OIL	1	>=13844			0	0
031	04611-00280	CIR-CLIP, INTERNAL	1	>=13844			0.002	0.0044
032	05811-00313	KEY,WOODRUFF	1	>=13844			0.001	0.0022
033	35180-36100	ASSY BUSH, GEAR	1	>=13844			0	0

MidWestTech | Kubota L185F Tractor Parts Manual | Publication L185F Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35270-35100	ASSY TANK,FUEL	1				5.85	12.87
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	13251-41060	FILTER	1				0.01	0.022
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	34150-35230	GASKET	1				0.01	0.022
006	34150-35240	SPONGE	1				0.001	0.0022
007	34150-35180	GASKET	1				0.001	0.0022
008	34150-35470	GAUGE,FUEL	1				0	0
009	10013-41770	CLIP,PIPE	2				0.005	0.011
010	31220-35400	ASSY COCK,FUEL	1				0.11	0.242
011	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
012	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
013	32130-35430	WASHER	1				0.001	0.0022
014	04611-00140	CIR-CLIP,INTERNAL	1				0.001	0.0022
015	04811-00080	O RING	1				0.001	0.0022
016	05411-00330	PIN,SPRING	1				0.001	0.0022
017	37300-35550	BUSH,FUEL TANK	1				0.014	0.0308

MidWestTech | Kubota L185F Tractor Parts Manual | Publication L185F Order the manual at mid-west-tech.com >