ILLUSTRATED PARTS LIST

KUBOTA

L245DT

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0			ORDER BY REF.No.019	0	0
002	37800-43870	BOLT	8				0.026	0.0572
003	37150-26270	STOPPER	4				0.015	0.033
004	37150-26100	ASSY DIFFERENTIAL	1				4.9	10.78
005	37150-26510	CASE DIFFERENTIAL	1				0	0
006	31220-26280	KEY FEATHER	1				0.005	0.011
007	31220-26340	SHAFT DIFF PINION	1				0.31	0.682
008	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
009	31220-26360	BUSH	2				0.015	0.033
010	31220-26390	WASHER DIFF PINION	2				0	0
011	34150-26430	GEAR DIFF BEARING RH	1				0	0
011	38440-44980	GEAR DIFF BEARING RH	1	>=50001			0	0
012	34150-26440	GEAR DIFF BEARING LH	1				0	0
012	38180-26440	GEAR DIFF BEARING LH	1	>=50001			0.61	1.342
013	31220-26480	WASHER 1.5T	2				0.015	0.033
014	31220-26490	WASHER 1.6T	2				0.02	0.044
015	37150-26480	WASHER 1.7T	2			L245DT	0.016	0.0352
016	34150-26610	SHIFTER DIFF LOCK	1				0	0
017	34150-26520	WASHER PLAIN	8				0.005	0.011
018	31220-26300	ASSY PINION DIFFEREN	2				0.155	0.341
019	35110-22100	ASSY SPIRAL BEVEL	1				5.3	11.66

MidWestTech | Kubota L245DT Tractor Parts Manual | Publication L245DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	37650-43110	CASE DIFF GEAR	1				6	13.2
002	06331-35012	PLUG	1				0.022	0.0484
003	04717-01200	WASHER SEAL	1				0.002	0.0044
004	37650-43120	CASE DIFF BEARING	1	<=11580			2.67	5.874
005	37650-43160	SHIM	4				0.002	0.0044
005	37650-43130	SHIM	4				0.005	0.011
006	37650-43170	SHIM	2				0.004	0.0088
006	37650-43140	SHIM	2				0.005	0.011
007	01173-51028	BOLT	8				0.022	0.0484
008	04512-50100	WASHER SPRING	8	<=11580			0	0
009	37150-26480	WASHER SPRING	2				0.016	0.0352
009	37150-26480	WASHER SPRING	2	<=11580			0.016	0.0352
010	99999-99999	BLANK	1	<=61866		ORDER BY REF.No.036	0	0
010	99999-99999	BLANK	1	>=61867		ORDER BY REF.No.036	0	0
011	37650-43220	COLLAR OIL SEAL	1				0.05	0.11
012	37650-43230	CASE PINION BEARING	1				0.87	1.914
013	31220-22340	NUT	1				0.033	0.0726
014	37650-43280	SHIM	4				0.001	0.0022
014	37650-43270	SHIM	6				0.003	0.0066
015	04811-00240	O RING	1				0.001	0.0022
016	04811-50700	O RING	1				0.002	0.0044
017	08711-30305	BEARING TAPER ROLLER	1				0.266	0.5852
018	08711-30205	BEARING TAPER ROLLER	1				0.148	0.3256
019	09500-35528	SEAL OIL	1				0.017	0.0374
020	01156-50822	BOLT	4				0.01	0.022
021	04512-50080	WASHER SPRING	4				0.001	0.0022
022	37650-43310	CASE DIFFERENTIAL	1	<=10095			0	0
022	37800-43310	CASE DIFFERENTIAL	1	>=10096			2.11	4.642
022	37800-43310	CASE DIFFERENTIAL	1	>=50001			2.11	4.642
023	37650-43320	PIN SNAP	1				0.01	0.022
024	37650-43330	SHAFT DIFF PINION	1				0.3	0.66
025	99999-99999	BLANK	0			ORDER BY REF.No.037	0	0
026	31220-26360	BUSH	2				0.015	0.033
027	31220-26390	WASHER DIFF PINION	2				0	0
028	34150-26430	GEAR DIFF SIDE RH	2				0	0
028	38440-44980	GEAR DIFF SIDE RH	2	>=50001			0	0
029	31220-26480	WASHER	2				0.015	0.033
029	31220-26490	WASHER	2				0.02	0.044
030	99999-99999	BLANK	0			ORDER BY REF.No.038	0	0
031	37650-43360	BUSH	1				0.039	0.0858
032	08101-06011	BEARING BALL (6011)	1				0.376	0.8272
033	08101-06010	BEARING BALL (6010)	1				0.262	0.5764
034	37650-43370	STOPPER	3	<=11580			0.015	0.033
035	34350-26250	BOLT	6	<=11580			0	0
035	37800-43870	BOLT	6	>=50001			0.026	0.0572
036	37650-43200	ASSY SPIRAL BEVEL	1	<=60786			3.1	6.82
036	35250-43300	ASSY SPIRAL BEVEL	1	>=60787			3.2	7.04
037	31220-26300	ASSY PINION DIFFEREN	1				0.155	0.341

MidWestTech | Kubota L245DT Tractor Parts Manual | Publication L245DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	32270-36210	KEY WOODRUFF	1	<=27296			0.001	0.0022
002	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
004	32270-36230	SEAL OIL	1	<=10795			0.005	0.011
004	37150-36230	SEAL OIL	1	<=27296			0.007	0.0154
005	99999-99999	BLANK	0			NON SALE	0	0
005	99999-99999	BLANK	1	<=27296		ORDER BY REF.No.017	0	0
006	99999-99999	BLANK	0			ORDER BY REF.No.017	0	0
007	32270-36240	RING SUPPORT	2	<=27296			0.005	0.011
008	32270-36250	RING SEERING	2	<=27296			0.001	0.0022
009	32270-36220	O RING	1	<=27296			0.001	0.0022
010	32270-36260	O RING	2	<=27296			0.001	0.0022
011	01311-10825	BOLT HEX-SOC-HD	6	<=10795			0.02	0.044
012	99999-99999	BLANK	0			NON SALE	0	0
013	99999-99999	BLANK	0			ORDER BY REF.No.016	0	0
013	99999-99999	BLANK	1	<=27296		ORDER BY REF.No.016	0	0
014	01156-50825	BOLT	6	<=27296			0.013	0.0286
015	04512-50080	WASHER SPRING	6	<=27296			0.001	0.0022
016	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.052	0	0
017	37150-36200	ASSY BUSH GEAR	1	<=27296			0.635	1.397
018	35110-76100	ASSY GEAR PUMP	1	>=27297			1.9	4.18
019	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
020	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
021	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
022	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
023	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
024	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
025	04810-50550	O RING	1	>=27297			0.002	0.0044
026	38180-76170	O RING	4	>=27297			0	0
027	04810-00050	O RING	1	>=27297			0.001	0.0022
028	01156-51030	BOLT	4	>=27297			0.02	0.044
029	04011-50100	WASHER PLAIN	4	>=27297			0.002	0.0044
030	67211-76190	SEAL OIL	1	>=27297			0	0
031	04611-00280	CIR-CLIP INTERNAL	1	>=27297			0.002	0.0044
032	05811-00313	KEY WOODRUFF	1	>=27297			0.001	0.0022
033	35180-36100	ASSY BUSH GEAR	1	>=27297			0	0

MidWestTech | Kubota L245DT Tractor Parts Manual | Publication L245DT Order the manual at mid-west-tech.com >