ILLUSTRATED PARTS LIST

KUBOTA

L245F

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0			ORDER BY REF.No.019	0	0
002	37800-43870	BOLT	8				0.026	0.0572
003	37150-26270	STOPPER	4				0.015	0.033
004	37150-26100	ASSY DIFFERENTIAL	1				4.9	10.78
005	37150-26510	CASE DIFFERENTIAL	1				0	0
006	31220-26280	KEY FEATHER	1				0.005	0.011
007	31220-26340	SHAFT DIFF PINION	1				0.31	0.682
008	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
009	31220-26360	BUSH	2				0.015	0.033
010	31220-26390	WASHER DIFF PINION	2				0	0
011	34150-26430	GEAR DIFF BEARING RH	1				0	0
011	38440-44980	GEAR DIFF BEARING RH	1	>=50001			0	0
012	34150-26440	GEAR DIFF BEARING LH	1				0	0
012	38180-26440	GEAR DIFF BEARING LH	1	>=50001			0.61	1.342
013	31220-26480	WASHER 1.5T	2				0.015	0.033
014	31220-26490	WASHER 1.6T	2				0.02	0.044
015	37150-26480	WASHER 1.7T	2			L245DT	0.016	0.0352
016	34150-26610	SHIFTER DIFF LOCK	1				0	0
017	34150-26520	WASHER PLAIN	8				0.005	0.011
018	31220-26300	ASSY PINION DIFFEREN	2				0.155	0.341
019	35110-22100	ASSY SPIRAL BEVEL	1				5.3	11.66

MidWestTech | Kubota L245F Tractor Parts Manual | Publication L245F Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	32270-36210	KEY WOODRUFF	1	<=27296			0.001	0.0022
002	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.048	0	0
004	32270-36230	SEAL OIL	1	<=11675			0.005	0.011
004	37150-36230	SEAL OIL	1	<=27296			0.007	0.0154
005	99999-99999	BLANK	0			NON SALE	0	0
005	99999-99999	BLANK	1	<=27296		ORDER BY REF.No.017	0	0
006	99999-99999	BLANK	0			ORDER BY REF.No.017	0	0
007	32270-36240	RING SUPPORT	2	<=27296			0.005	0.011
008	32270-36250	RING SEERING	2	<=27296			0.001	0.0022
009	32270-36220	O RING	1	<=27296			0.001	0.0022
010	32270-36260	O RING	2	<=27296			0.001	0.0022
011	01311-10825	BOLT HEX-SOC-HD	6	<=11695			0.02	0.044
012	99999-99999	BLANK	0			NON SALE	0	0
013	99999-99999	BLANK	0			ORDER BY REF.No.016	0	0
013	99999-99999	BLANK	1	<=27296		ORDER BY REF.No.016	0	0
014	01156-50825	BOLT	6	<=27296			0.013	0.0286
015	04512-50080	WASHER SPRING	6	<=27296			0	0
016	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.052	0	0
017	37150-36200	ASSY BUSH GEAR	1	<=27296			0.635	1.397
018	35110-76100	ASSY GEAR PUMP	1	>=27297			1.9	4.18
019	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
020	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
021	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
022	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
023	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
024	99999-99999	BLANK	0			ORDER BY REF.No.033	0	0
025	04810-50550	O RING	1	>=27297			0.002	0.0044
026	38180-76170	O RING	4	>=27297			0	0
027	04810-00050	O RING	1	>=27297			0.001	0.0022
028	01156-51030	BOLT	4	>=27297			0.02	0.044
029	04011-50100	WASHER PLAIN	4	>=27297			0.002	0.0044
030	67211-76190	SEAL OIL	1	>=27297			0	0
031	04611-00280	CIR-CLIP INTERNAL	1	>=27297			0.002	0.0044
032	05811-00313	KEY WOODRUFF	1	>=27297			0.001	0.0022
033	35180-36100	ASSY BUSH GEAR	1	>=27297			0	0

MidWestTech | Kubota L245F Tractor Parts Manual | Publication L245F Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35270-35100	ASSY TANK FUEL	1				5.85	12.87
002	35270-35110	TANK FUEL	1				0	0
003	13251-41600	FILTER	1				0	0
004	34150-35220	CAP	1				0.042	0.0924
005	34150-35230	GASKET	1				0.01	0.022
006	34150-35240	SPONGE	1				0.001	0.0022
007	34150-35180	GASKET	1				0.001	0.0022
008	07935-05740	GAUGE FUEL	1				0	0
009	10013-41770	CLIP PIPE	2				0.005	0.011
010	31220-35400	ASSY COCK FUEL	1				0.11	0.242
011	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
012	99999-99999	BLANK	0			ORDER BY REF.No.010	0	0
013	32130-35430	WASHER	1				0.001	0.0022
014	04611-00140	CIR-CLIP INTERNAL	1				0.001	0.0022
015	04811-00080	O RING	1				0.001	0.0022
016	05411-00330	PIN SPRING	1				0.001	0.0022
017	37300-35550	BUSH FUEL TANK	1				0.014	0.0308

MidWestTech | Kubota L245F Tractor Parts Manual | Publication L245F Order the manual at mid-west-tech.com >