ILLUSTRATED PARTS LIST

KUBOTA

L295DT

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	37300-37110	CYLINDER HYD.	1	<=13752			0	0
010	35340-37110	CYLINDER HYD.	1	>=13753	↔		22.9	50.38
020	34260-37270	PIPE BREATHER	1	<=50873			0.03	0.066
020	35170-37270	PIPE BREATHER	1	>=50874	←		0.03	0.066
030	37150-37120	GASKET	1				0	0
040	01173-51240	BOLT	4				0.045	0.099
050	34260-37180	BOLT	2				0.115	0.253
060	01173-51295	BOLT	1				0.086	0.1892
070	01173-51201	BOLT	1				0.094	0.2068
080	01574-51240	STUD	2				0	0
090	04512-50120	WASHER SPRING	10				0	0
100	02176-50120	NUT	2				0.01	0.022
110	06311-35030	PLUG	1				0.058	0.1276
120	04717-01700	WASHER WITH RUBBER	1				0.003	0.0066
130	37300-37200	ASSY COVER HYD.CYL.	1				3.7	8.14
140	37150-36740	PLUG	1				0.025	0.055
150	04724-00100	GASKET	1				0.001	0.0022
160	34150-37250	COLLAR ADJUSTING	1				0.01	0.022
170	04611-00180	CIR-CLIP INTERNAL	1				0.001	0.0022
180	34150-37220	SCREW ADJUSTING	1				0.025	0.055
190	04810-00100	O RING	1				0.001	0.0022
200	09230-08164	SEAL OIL	1				0.001	0.0022
210	34150-37260	CIR-CLIP INTERNAL	1				0.001	0.0022
220	04012-50080	WASHER PLAIN	1				0.001	0.0022
230	34150-37230	GRIP	1				0.04	0.088
240	05411-00418	PIN SPRING	1				0.001	0.0022
250	37150-36730	PLUG	1				0.03	0.066
260	37150-36720	GASKET	1				0.01	0.022
270	04810-00140	O RING	1				0.001	0.0022
280	04811-51000	O RING	1				0.003	0.0066
290	04810-50800	O RING	1				0.002	0.0044
300	37300-37260	RING BACK UP	1				0.002	0.0044
310	01173-51240	BOLT	5				0.045	0.099
320	04512-50120	WASHER SPRING	5				0	0
330	35300-99270	ELBOW	1			ALGERIA	0.49	1.078
340	35300-99280	HOSE HYD.	1			ALGERIA	0.06	0.132
350	35340-99460	BRACKET JOINT	1			ALGERIA	0.3	0.66
360	35340-99470	U BOLT	1			ALGERIA	0.03	0.066
370	04512-50060	WASHER SPRING	2			ALGERIA	0	0
380	02014-50060	NUT	2			ALGERIA	0.003	0.0066
390	99999-99999	COUPLER FEMALE	1			ALGERIA LOCAL SUPPLY	0	0

MidWestTech | Kubota L295DT Tractor Parts Manual | Publication L295DT Order the manual at mid-west-tech.com >

DRAWBAR AND HITCH

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	37300-29710	FRAME DRAWBAR	1			SWINGING DRAWBAR	9.6	21.12
010	35300-29710	HITCH	1			FIXED DRAWBAR	6.7	14.74
020	01173-51430	BOLT	12			SWINGING DRAWBAR	0.052	0.1144
020	01173-51430	BOLT	8			FIXED DRAWBAR	0.052	0.1144
030	01173-51425	BOLT	4			FIXED DRAWBAR	0.047	0.1034
040	04512-50140	WASHER SPRING	12				0	0
050	37300-29720	LINK SUPPORT	2			SWINGING DRAWBAR	1.2	2.64
050	35300-29720	LINK SUPPORT	2			FIXED DRAWBAR	0.305	0.671
060	99553-78210	DRAWBAR	1				5.84	12.848
070	99533-78240	DRAWBAR	1				2.22	4.884
080	01173-51665	BOLT	2				0.117	0.2574
090	04512-50160	WASHER SPRING	2				0	0
100	02174-50160	NUT	2				0.022	0.0484
110	37300-29780	PIN JOINT	3			SWINGING DRAWBAR	0.31	0.682
110	34260-29720	PIN HITCH	1			FIXED DRAWBAR	0.4	0.88
120	37300-29790	PIN SNAP	3	<=12180		SWINGING DRAWBAR	0	0
120	70515-16330	PIN SPRING	3	>=12181	↔	SWINGING DRAWBAR	0.028	0.0616
120	70515-16330	PIN SPRING	1			FIXED DRAWBAR	0.028	0.0616
130	99533-78250	PIN	1				0.61	1.342
140	34150-37640	PIN SET	1				0.06	0.132

MidWestTech | Kubota L295DT Tractor Parts Manual | Publication L295DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	35340-85000	SUSPENSHION SEAT ADJ	1				14.3	31.46
020	35340-85010	ASSY SEAT	1				7.2	15.84
030	35340-18210	SEAT ADJUST RH	1				0.78	1.716
040	35340-18220	SEAT ADJUST LH	1				0.97	2.134
050	15111-72200	WASHER	8				0.013	0.0286
060	35340-18230	CUSHION	4				0.014	0.0308
070	35340-18240	CUSHION	4				0.004	0.0088
080	02372-50100	NUT	4				0.005	0.011
090	05511-52520	PIN SPLIT	4				0.001	0.0022
100	03004-50816	SCREW WITH WASHER	4				0.01	0.022
110	35340-18700	ASSY SUSPENTION SEAT	1				5.5	12.1
120	35340-18410	SUPPORT SEAT	1				12.7	27.94
130	35340-18420	SUPPORT SEAT	1				1.12	2.464
140	35258-18430	ARM	1				0.67	1.474
150	34269-18440	ARM	1				0.475	1.045
160	35170-18450	SPRING SEAT	2				0.165	0.363
170	35170-18460	BOLT ADJUST	1				0.07	0.154
180	34269-18490	PIN	4				0.06	0.132
190	02118-50100	NUT	1				0.005	0.011
200	02116-50100	NUT	1				0.004	0.0088
210	04013-50100	WASHER PLAIN	8				0	0
220	05511-50220	PIN SPLIT	8				0.001	0.0022
230	32160-18440	CUSHION	1				0.013	0.0286
240	35258-18480	ROLLER	2				0.005	0.011
250	35300-18460	SPACER SEAT FRONT	2				0.37	0.814
260	35300-18470	SPACER SEAT REAR	1				0.53	1.166

MidWestTech | Kubota L295DT Tractor Parts Manual | Publication L295DT Order the manual at mid-west-tech.com >