ILLUSTRATED PARTS LIST

KUBOTA

L345

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

TOP LINK BRACKET

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35300-41400	ASSY BRACKET TOP LIN	1				0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	37300-41450	BUSH	3				0.03	0.066
006	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
007	06613-10010	NIPPLE GREASE	2	<=10617			0.006	0.0132
007	06613-10010	NIPPLE GREASE	1	>=10001			0.006	0.0132
008	01173-51228	BOLT	6				0.036	0.0792
009	04512-50120	WASHER SPRING	6				0	0
010	37300-41310	ROD DRAFT CONTROL	1				0.07	0.154
011	37300-41320	ROD DRAFT CONTROL	1				0.04	0.088
012	66591-42410	TURNBUCKLE	1				0.046	0.1012
013	02114-50080	NUT	1				0.005	0.011
014	37300-41330	NUT	1				0.005	0.011
015	05122-50818	PIN JOINT	2				0.008	0.0176
016	04012-50080	WASHER PLAIN	2				0.001	0.0022
017	05511-50218	PIN SPLIT	2				0.001	0.0022
018	06613-20010	NIPPLE GREASE	1	<=10617			0.01	0.022
018	06613-20010	NIPPLE GREASE	2	>=10001			0.01	0.022

MidWestTech | Kubota L345 Tractor Parts Manual | Publication L345 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.52	0	0
002	37150-36580	SPRING	1				0.005	0.011
003	37150-36590	VALVE CHECK	1				0.015	0.033
004	04811-00090	O RING	1				0.001	0.0022
005	37150-36440	SEAT	1				0.035	0.077
006	37150-36450	SPRING	1				0.005	0.011
007	04811-00070	O RING	1				0.001	0.0022
008	37150-36630	RING BACK UP	1				0.001	0.0022
009	37150-36460	POPPET	1				0.005	0.011
010	04811-00150	O RING	2				0.001	0.0022
011	37150-36470	PLUG SEAT	1				0.04	0.088
012	37150-36480	VALVE UNLOADER	1				0.02	0.044
013	37150-36490	SPRING	1				0.005	0.011
014	37150-36510	PLATE	1				0.035	0.077
015	37150-36520	PLUG	1				0.043	0.0946
016	37150-36530	SPRING RETURN	1				0.01	0.022
017	37150-36540	PLATE	1				0.145	0.319
018	37150-36550	NUT	3				0.005	0.011
019	04811-00120	O RING	2				0.001	0.0022
020	37150-36560	PLATE LOCK	1				0.01	0.022

MidWestTech | Kubota L345 Tractor Parts Manual | Publication L345 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35340-45110	PUMP OIL PRESSURE 1	1				2.8	6.16
002	35340-36200	ASSY BUSH GEAR	1				0.655	1.441
003	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
005	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
006	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
007	35340-36230	SEAL OIL	1				0.01	0.022
008	35340-36110	BODY	1				0.75	1.65
009	35340-36140	FLANGE MOUNTING	1				0.69	1.518
010	35340-36260	SEAL BODY	2				0.005	0.011
011	35340-36220	RING GASKET L	2				0.001	0.0022
012	35340-36250	RING GASKET R	2				0.002	0.0044
013	35340-36240	SEAL BUSH	2				0.001	0.0022
014	35340-36310	PLATE CENTER	1				0.374	0.8228
015	04811-50300	O RING	1				0.001	0.0022
016	04512-50100	WASHER SPRING	4				0	0
017	35340-36330	BOLT	4				0.05	0.11
018	35340-45130	PLATE ADAPTER	1				0.66	1.452
019	35340-45140	COUPLING	1				0.032	0.0704
020	04811-50300	O RING	1				0.001	0.0022
021	35340-45150	STUD	4				0.01	0.022
022	02114-50080	NUT	4				0.005	0.011
023	04512-50080	WASHER SPRING	4				0	0
024	35340-45200	PUMP OIL PRESSURE 2	1				1.89	4.158
025	35340-45210	ASSY BUSH GEAR	1				0.56	1.232
026	99999-99999	BLANK	0			ORDER BY REF.No.025	0	0
027	99999-99999	BLANK	0			ORDER BY REF.No.025	0	0
028	99999-99999	BLANK	0			ORDER BY REF.No.025	0	0
029	99999-99999	BLANK	0			ORDER BY REF.No.025	0	0
030	35340-45250	SEAL OIL	1				0.005	0.011
031	35340-45260	BODY	1				0.76	1.672
032	32270-36260	O RING	2				0.001	0.0022
033	32270-36220	O RING	1				0.001	0.0022
034	32270-36250	RING SEARING	2				0.001	0.0022
035	32270-36240	RING SUPPORT	2				0.005	0.011
036	37150-36180	COVER	1				0.25	0.55
037	04512-50080	WASHER SPRING	6				0	0
038	01156-50825	BOLT	6				0.013	0.0286
039	04512-50080	WASHER SPRING	3				0	0
040	01156-50825	BOLT	3				0.013	0.0286
041	35340-45120	ASSY ADAPTER	1				0.75	1.65

MidWestTech | Kubota L345 Tractor Parts Manual | Publication L345 Order the manual at mid-west-tech.com >