ILLUSTRATED PARTS LIST

KUBOTA

L35

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
220	1A091-23540	METAL SIDE	2	>=3S0001	≠	STD	0.009	0.0198
220	19202-23970	METAL SIDE	2	<=3Q0483		+0.20mm	0.01	0.022
220	1A091-23970	METAL SIDE	2	>=3S0001	≠	+0.20mm	0.005	0.011
220	19202-23980	METAL SIDE	2	<=3Q0483		+0.40mm	0.01	0.022
220	1A091-23980	METAL SIDE	2	>=3S0001	≠	+0.40mm	0.005	0.011
230	19202-04140	SEAL OIL	1				0.015	0.033
240	07916-26940	KIT PISTON-RING	3			STD	0.87	1.914
240	07916-26950	KIT PISTON-RING	3			+0.50mm	0.68	1.496
250	07916-28070	KIT METAL ENGINE	1			STD	0.35	0.77
250	07916-28720	KIT METAL ENGINE	1			-0.20mm	0	0
250	07916-28722	KIT METAL ENGINE	1		←	-0.20mm	0.44	0.968
250	07916-28730	KIT METAL ENGINE	1			-0.40mm	0	0
250	07916-28732	KIT METAL ENGINE	1		←	-0.40mm	0.44	0.968

MidWestTech | Kubota L35 Tractor Parts Manual | Publication L35
Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32751-41310	COMP.BONNET	1	<=60599			0	0
010	32751-41314	COMP.BONNET	1	>=60600	←		4.62	10.164
020	30442-18625	CUSHION	4	<=60599			0.005	0.011
020	TA040-18620	CUSHION	4	>=60600	≠		0.01	0.022
030	34070-41630	CUSHION	2				0.005	0.011
040	01754-50820	BOLT FLANGE	2				0.015	0.033
045	02751-50080	NUT FLANGE	2				0.006	0.0132
050	01774-61020	BOLT FLANGE	2				0.022	0.0484
060	32480-18760	CAP PRE CLEANER	1				0.02	0.044
070	32751-41330	COVER RADIATOR	1				2.5	5.5
071	30400-94080	SPRING BONNET COVER	2				0.012	0.0264
072	30400-94092	SPRING BONNET COVER	2				0.015	0.033
073	05611-10612	RIVET	4				0.005	0.011
080	34550-41380	HOOK BONNET	1				0.04	0.088
090	02114-50080	NUT	1				0.005	0.011
100	04015-60080	WASHER PLAIN	1				0.01	0.022
110	32751-41160	SPONGE	1				0.026	0.0572
120	32751-41340	SPONGE	2				0.005	0.011
130	32751-41150	SPONGE	1				0.006	0.0132
140	32751-41410	COVER SIDE LH	1	<=50297			0	0
140	32751-41413	COVER SIDE LH	1	>=50298	←		3.95	8.69
150	32751-41420	COVER SIDE RH	1	<=50297			0	0
150	32751-41423	COVER SIDE RH	1	>=50298	←		3.65	8.03
160	32751-41440	SPONGE	1				0.01	0.022
170	32751-41470	SPONGE	1				0.005	0.011
180	01820-50835	BOLT KNOB	2				0.03	0.066
190	01820-50840	BOLT KNOB	2				0.03	0.066
200	35533-83300	CUSHION	4	<=60285			0.001	0.0022
200	32751-41490	CUSHION	4	>=60286	←		0.002	0.0044

MidWestTech | Kubota L35 Tractor Parts Manual | Publication L35 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	34070-47310	CUSHION	2				0.165	0.363
020	34070-47320	WASHER	2				0.1	0.22
030	01173-51660	BOLT	2				0.114	0.2508
040	04512-50160	WASHER SPRING	2				0	0
050	02176-50160	NUT	2				0.021	0.0462
060	32751-47400	STEP	1				0	0
060	32751-47404	STEP	1		↔		16.5	36.3
070	34070-47454	MAT	1				2.4	5.28
080	37410-42760	COVER PEDAL	1				0.025	0.055
090	30400-17980	RUBBER BLOCK	2				0.01	0.022
100	32751-47410	BRACKET STEP RH	1				1.9	4.18
110	34070-47420	BRACKET STEP LH	1				0.22	0.484
120	01133-51230	BOLT	6				0.04	0.088
130	01073-51030	BOLT	2				0.028	0.0616
140	34070-47490	CUSHION	2				0.005	0.011
150	02118-50100	NUT	2				0.005	0.011
160	T0070-15990	SUPPORT	1				0.12	0.264
170	01133-51020	BOLT	2				0.02	0.044
180	TA040-47470	STEP AID	1				0.86	1.892
190	01754-50812	BOLT FLANGE	4				0.01	0.022

MidWestTech | Kubota L35 Tractor Parts Manual | Publication L35 Order the manual at mid-west-tech.com >