
ILLUSTRATED PARTS LIST

KUBOTA

L355SS

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	19202-04040	ASSY CASE,MAIN BEARI	1				1.28	2.816
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	15521-04540	BOLT,BEARING CASE 1	8				0	0
005	15521-94010	WASHER,PLAIN	8				0.001	0.0022
006	15221-04360	GASKET,BEARING	1				0	0
007	19202-04810	COVER,BEARING	1				0.36	0.792
008	15221-04820	GASKET,COVER	1				0	0
009	01123-50825	BOLT	8				0.013	0.0286
010	01123-50828	BOLT	8				0.014	0.0308
011	19202-04460	SEAL,OIL	1				0.055	0.121
012	15521-04050	ASSY CASE,MAIN BEARI	1				0	0
013	99999-99999	BLANK	0			ORDER BY REF.No.012	0	0
014	99999-99999	BLANK	0			ORDER BY REF.No.012	0	0
015	15521-04060	ASSY CASE,MAIN BEARI	1				0	0
016	99999-99999	BLANK	0			ORDER BY REF.No.015	0	0
017	99999-99999	BLANK	0			ORDER BY REF.No.015	0	0
018	15411-04070	ASSY CASE,MAIN BEARI	1				1.25	2.75
019	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
020	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
021	15291-04560	BOLT 2	3				0.06	0.132
022	15521-94020	WASHER,PLAIN	3				0.004	0.0088

MidWestTech | Kubota L355SS Tractor Parts Manual | Publication L355SS Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35370-85010	ASSY SEAT	1				5.5	12.1
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	35370-18410	ASSY ADJUSTER,SEAT	1				2.65	5.83
006	35370-18420	ADJUSTER,SEAT	1				2.7	5.94
007	35260-18430	SUPPORT,SEAT	1				0.54	1.188
008	02112-50080	NUT	2				0.003	0.0066
009	02114-50080	NUT	4				0.005	0.011
010	04512-50080	WASHER,SPRING	2				0.001	0.0022
011	01133-51020	BOLT	4				0.02	0.044
012	35370-18440	SUPPORT,CUSHION	1				1.29	2.838
013	01133-51020	BOLT	2				0.02	0.044
014	01133-51035	BOLT	2				0.03	0.066
015	35260-18480	BRACKET,CUSHION	1				0.5	1.1
016	35260-18490	SHAFT,CUSHION	1				0.13	0.286
017	38240-18440	CUSHION	2				0.035	0.077
018	35260-18500	COLLAR	2				0.018	0.0396
019	04013-50100	WASHER,PLAIN	2				0	0
020	05511-50315	PIN,SPLIT	4				0.002	0.0044
021	66204-45980	SPRING,SEAT	2				0.1	0.22
022	04012-50080	WASHER,PLAIN	2				0.001	0.0022
023	38240-18470	PIN,SEAT	1				0.085	0.187
024	37150-18490	CUSHION	2				0.014	0.0308
025	05515-51000	PIN,SNAP	1				0	0

MidWestTech | Kubota L355SS Tractor Parts Manual | Publication L355SS Order the manual at mid-west-tech.com >

DRAFT CONTROL VALVE SECTION PARTS

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	37300-41100	ASSY VALVE,DRAFT CON	1				3.2	7.04
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	37300-41120	CAP	1				1.05	2.31
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	37300-41140	PLUG	1				0.098	0.2156
006	37300-41150	SPRING	1				0.01	0.022
007	04811-00180	O RING	1				0.001	0.0022
008	37300-41160	SHAFT	1				0.065	0.143
009	37300-41170	SHAFT	1				0.03	0.066
010	37300-41180	ARM	1				0.03	0.066
011	32240-36630	ARM	1				0.015	0.033
012	37300-41270	LINK	1				0.012	0.0264
013	04613-50050	RING,SNAP	1				0.001	0.0022
014	04811-00090	O RING	2				0.001	0.0022
015	05411-00518	PIN,SPRING	2				0.002	0.0044
016	04011-50140	WASHER,PLAIN	2				0.007	0.0154
017	37300-41280	WASHER,SPRING	2				0.005	0.011
018	02172-50140	NUT	2				0.01	0.022
019	37300-41290	GASKET	1				0.001	0.0022
020	04512-50080	WASHER,SPRING	3				0.001	0.0022
021	01150-50875	BOLT	2				0	0
022	04810-00160	O RING	2				0.001	0.0022
023	37300-41360	RING,SNAP	1				0.001	0.0022
024	01150-50870	BOLT	1				0	0

MidWestTech | Kubota L355SS Tractor Parts Manual | Publication L355SS Order the manual at mid-west-tech.com >