ILLUSTRATED PARTS LIST

KUBOTA

L3710DT/GST/HST

TRACTOR



Kubota

MidWestTech | Kubota L3710DT, L3710GST, L3710HST Tractor Parts Manual | Publicatio... Order the manual at mid-west-tech.com >

BRAKE ROD 1 [HST TYPE] [ROPS TYPE]
[EXCEPTE TYPE CABINE]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	34070-44810	ASSY LEVER BRAKE LH	1				0	0
020	34070-44890	BUSH	1				0.035	0.077
030	34070-44910	ASSY LEVER BRAKE RH	1				0	0
040	34070-44890	BUSH	1				0.035	0.077
050	34070-44870	SHAFT BRAKE LH	1				0.225	0.495
060	34070-44880	SHAFT BRAKE RH	1				0.22	0.484
070	04011-50200	WASHER PLAIN	2				0.015	0.033
080	04612-00200	CIR CLIP EXTERNAL	2				0.001	0.0022
090	34070-44800	ASSY ROD BRAKE	2				0.425	0.935
100	34070-44840	ROD BRAKE LOWER	2				0.13	0.286
110	34070-44460	ROD CLUTCH BRAKE	2				0.225	0.495
120	32350-28980	TURNBUCKLE	2				0.124	0.2728
130	02116-50100	NUT	2				0.004	0.0088
140	05122-51035	PIN JOINT	1				0.023	0.0506
150	05122-61028	PIN JOINT	3				0.02	0.044
160	04013-60100	WASHER PLAIN	4	<=50910			0.004	0.0088
160	04013-60100	WASHER PLAIN	3	>=50911			0.004	0.0088
165	TA240-56470	COLLAR BRAKE ROD	1	>=50911			0.013	0.0286
170	05511-50318	PIN SPLIT	4				0.001	0.0022

MidWestTech | Kubota L3710DT, L3710GST, L3710HST Tractor Parts Manual | Publicatio... Order the manual at mid-west-tech.com >

HYDRAULIC OUTLET BLOCK [HST TYPE]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA040-37500	ASSY BLOCK FRONT HYD	1	<=61504			1.545	3.399
010	TA250-37500	ASSY BLOCK FRONT HYD	1	>=70001	≠		1.535	3.377
010	TA250-37500	ASSY BLOCK FRONT HYD	1		↔		1.535	3.377
020	TA040-37520	SPOOL	1				0.067	0.1474
030	04810-06100	O RING	2				0.001	0.0022
030	04817-06100	O RING	2		←		0	0
040	04612-00140	CIR CLIP EXTERNAL	1				0.001	0.0022
050	05411-00320	PIN SPRING	1				0.001	0.0022
060	05411-00310	PIN SPRING	2				0.001	0.0022
070	06312-10030	PLUG	3				0.029	0.0638
080	31351-37910	PLUG	1				0.06	0.132
090	31351-37920	SPRING RELIEF	1				0.02	0.044
100	31351-37930	SEAT RELIEF VALVE	1				0.02	0.044
110	31351-37940	POPPET	1				0.005	0.011
120	31351-37950	SHIM	5			0.4mm	0.001	0.0022
120	31351-37960	SHIM	2			0.2mm	0.001	0.0022
120	31351-37970	SHIM	2			0.1mm	0.001	0.0022
130	04013-60050	WASHER PLAIN	2				0.001	0.0022
140	04811-10160	O RING	1				0.001	0.0022
150	TA040-37590	CUSHION	2				0.006	0.0132
160	01123-50828	BOLT	2				0.014	0.0308
170	TA040-37600	COLLAR	2				0.009	0.0198
180	04015-60080	WASHER PLAIN	2				0.01	0.022
190	TA240-56460	PIPE RETURN	1	<=61504			0.09	0.198
190	TA250-56460	PIPE RETURN	1	>=70001	≠		0	0
190	TA250-56462	PIPE RETURN	1	>=71652	←		0.48	1.056
200	01754-50608	BOLT FLANGE	1	<=61504			0.005	0.011
210	04811-00110	O RING	2	<=61504			0.001	0.0022
210	06015-51533	JOINT	1	>=70001	≠		0	0
220	TA240-55210	BRACKET HYD.BLOCK	1				0.94	2.068
230	06012-51533	JOINT PIPE	1	>=70001			0.066	0.1452
240	04811-00140	O RING	2	>=70001			0.001	0.0022
240	04817-00140	O RING	2		←		0	0

MidWestTech | Kubota L3710DT, L3710GST, L3710HST Tractor Parts Manual | Publicatio... Order the manual at mid-west-tech.com >

POSITION CONTROL LEVER [ROPS TYPE]

[EXCEPTE TYPE CABINE]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA040-36110	LEVER POSITION	1	<=71755		W/O DRAFT	0.276	0.6072
010	TA140-36110	LEVER POSITION	1	>=71756	≠	W/O DRAFT	0	0
020	05411-00525	PIN SPRING	1			W/O DRAFT	0.002	0.0044
030	TA040-36120	LEVER POSITION	1			W/O DRAFT	0.21	0.462
040	TA040-36130	TUBE LEVER	1	<=50024		W/O DRAFT	0	0
040	TA040-36132	TUBE LEVER	1	>=50025	←	W/O DRAFT	0.01	0.022
050	01754-50616	BOLT FLANGE	2			W/O DRAFT	0.006	0.0132
060	52300-32640	GRIP LEVER	1				0.04	0.088
070	TA140-47610	ASSY GUIDE HYD.LEVER	1				0.91	2.002
075	01754-50816	BOLT FLANGE	2				0.011	0.0242
080	01754-50812	BOLT FLANGE	5				0.01	0.022
090	34070-36130	STOPPER	1				0.015	0.033
100	01125-60816	BOLT	1	<=74854			0.01	0.022
100	01123-50816	BOLT	1	>=74855	←		0.011	0.0242
105	02751-50080	NUT FLANGE	1				0.006	0.0132
110	34070-36140	STOPPER	1	<=74854			0	0
110	34070-36140	STOPPER	1	>=74855	←		0	0
120	01820-50620	BOLT KNOB	1				0.015	0.033
130	04512-60060	WASHER SPRING	1				0.001	0.0022
140	31351-18860	WASHER	1				0.002	0.0044

MidWestTech | Kubota L3710DT, L3710GST, L3710HST Tractor Parts Manual | Publicatio... Order the manual at mid-west-tech.com >